

digital



Technical Documentation

SUMMER 1977

The description, pricing and availability of items in this catalog are subject to change without notice.

Table of Contents

HARDWARE MANUALS.....	1 - 11
SOFTWARE DOCUMENTATION.....	12 - 19
DOCUMENT ONLY KITS.....	20 - 23
SOURCE LISTINGS.....	24 - 25
DIAGNOSTIC KITS.....	26 - 33
ENGINEERING DRAWINGS.....	34 - 49

Introduction


THIS, THE FIRST EDITION OF THE TECHNICAL DOCUMENTATION CATALOG, LISTS THE MOST POPULAR HARDWARE AND SOFTWARE DOCUMENTATION IN AN EASY TO USE FORMAT. WE TRUST THIS CATALOG WILL SATISFY YOUR TOTAL NEEDS.

ALL OF THE AVAILABLE HARDWARE MANUALS ARE LISTED HERE. IF HOWEVER, YOU REQUIRE ADDITIONAL INFORMATION ON SOFTWARE, PLEASE CONTACT YOUR LOCAL OFFICE AND REQUEST A COPY OF THE **SOFTWARE COMPONENTS CATALOG**. THE SOFTWARE COMPONENTS CATALOG LISTS THE REMAINDER OF THE SOFTWARE PRODUCTS AND OFFERS INFORMATION ON REPLACEMENT SOFTWARE.

Ordering Instructions

- . PLACE YOUR ORDER THROUGH YOUR LOCAL DIGITAL OFFICE. THE BACK COVER OF THIS CATALOG LISTS THE CITIES WHERE DIGITAL OFFICES ARE LOCATED.
- . PLEASE PROVIDE THE FOLLOWING INFORMATION WITH YOUR PURCHASE:

1. BILL TO ADDRESS
2. SHIP TO ADDRESS
3. PURCHASE ORDER NUMBER
4. TAX INFORMATION
5. PARTIALS ACCEPTED
6. METHOD OF SHIPMENT
7. REQUIRED DELIVERY
8. QUANTITY REQUIRED
9. DIGITAL PART NUMBER
10. DESCRIPTION
11. PRICE
12. RENEGOTIABLE



Hardware Manuals

Please order by **PART NUMBER**.
The index code is for internal use
only.

The last two digits of the part
number on hardware manuals
indicate the type of manual. The
basic types are as follows:

IN	Installation and Acceptance
IP	Illustrated Parts Breakdown
LK	Layout
MM	Maintenance Manual
OP	Operators Manual
SP	Site Preparation
TM	Training Manual

PART NO	TITLE	INDEX CODE	PRICE
99H038	138/139 ANALOG-DIGITAL CONVERTER MAINT MANUAL	H-138/139	E
99H039	139E ANALOG MULTIPLEXER MAN	H-139E	E
99H042	342 SYMBOL GENERATOR MAINT MAN	H-342	E
99H034	34D OSCILLOSCOPE DISPLAY INSTRUCTION MANUAL	08-16AA-D	G
EK9728IP	54-9728 REGULATOR BOARD IPB	EK-9728-IP-002	I
94I105	854/854B-C POWER CONTROLLER IPB	854/854B-C-IPB-1	I
94I110	860 A,B,C,D, POWER CONTROLLER IPB	860 A B C D-IPB-1	I
EK00861IP	861 A,B,C POWER CONTROLLER MAINT MANUAL	00-H861A-A-D	E
EK861IP	861 A,B,C,D,E,F POWER CONTROLLER IPB	EK-861-IP-002	I
EK861ABMM	861 A,B,C,D,E,F POWER CONTROLLER MAINTENANCE MANUAL	EK-861AB-MM-002	E
EK8A400IP	8A400 12 BIT COMPUTER IPB	EK-8A400-IP-001	I
EK8A420IP	8A420 12 BIT COMPUTER IPB	EK-8A420-IP-001	I
EK8A500IP	8A500 12 BIT COMPUTER IPB	EK-8A500-IP-001	I
EK8A600IP	8A600 12 BIT COMPUTER IPB	EK-8A600-IP-001	I
EK8A620IP	8A620 12 BIT COMPUTER IPB	EK-8A620-IP-001	I
EK8A800IP	8A800 12 BIT COMPUTER IPB	EK-8A800-IP-001	I
EK8A820IP	8A820 12 BIT COMPUTER IPB	EK-8A820-IP-001	I
47H050	AA11-D D-A SUBSYSTEM MANUAL	11-HAAC-D	F
46H065	AA50 D-A CONVERTER MAINT MAN	08-HRAA-D	H
47H076	AD01-D A-D CONVERSION SUBSYSTEM MANUAL	11-HADDA-D-D	F
EKADV11OP	ADV11-A, KWV11A, AAV11-A, DRV11 USERS MANUAL		E
EKAD11KOP	AD11-K ANALOG TO DIGITAL CONVERTER USER MANUAL (LAB DATA)		E
15H110	AD15 ANALOG SUBSYSTEM MAINT MANUAL VOLI	15-H3AB-D	E
47H095	AFC11 LOW LEVEL DIFFERENTIAL ANALOG MULTIPLEXER MANUAL	11-HAFCA-B-D	H
46H096	AFC8 LOW-LEVEL DIFFERENTIAL ANALOG MULTIPLEXER MAINT MAN	08-HAFCA-C-D	H
99H115	AF01 A-D CONVERTER MULTIPLEXER MAINT MANUAL	00-16AB-D	E
EKAM11KTM	AM11-K MULTIPLE GAIN MULTIPLEXER USERS MANUAL	EK-AM11K-TM-001	E
84H550	AR-11 USERS GUIDE	11-HARUG-B-D	F
EKBALLFIP	BA11-F MOUNTING BOX IPB	EK-BA11F-IP-002	I
EKBALLKIP	BA11-K MOUNTING BOX IPB	BA11K-IPB-1	I
EKBALLKMM	BA11-K MOUNTING BOX MANUAL	EK-BA11K-MM-002	F
EKBALLLMM	BA11-L MOUNTING BOX MAINT MAN	EK-BA11L-MM-PRE	F
EKOBA8CIP	BA8-C CHASSIS ASSEMBLY IPB	EK-OBA8C-IP-001	I
EKBL01AMM	BL01 AC LINE MONITOR MAINT MAN	EK-BL01A-MM-002	E
EKBM792TM	BM792 READ-ONLY MEMORY AND MR11-DB BOOTSTRAP LOADER MAN	EK-BM792-TM-004	F
EKBM873TM	BM873 RESTART/LOADER MANUAL	EK-BM873-TM-005	G
EKBSR00OP	BSR USERS MANUAL	EK-BSR00-OP-002	C
68H110	CB11 TEL PLANT INTERFACE MAN	11-HBTLA-A-D	F
EKOC11TM	CD11 CARD READER SYSTEM MANUAL	EK-OC11-TM-002	F
EKOOC18IP	CL8 UNIT ASSEMBLY IPB	EK-OOC18-IP-001	I
EKOOC18OP	CL8 USERS GUIDE	EK-OOC18-OP-001	F
EKTY011OP	CLASS AD-11 SYSTEM USERS GUIDE VERSION 3 (TMS-11)	EK-TY011-OP-001	H
99H058	COMPUTER SITE PREPARATION HDBK	00-ICSPA-A-D	C
99H145	CR03B CARD READER SYSTEM INSTRUCTION MANUAL	09-H2CA-D	E
94I120	CR04-A-B-C-D CARD READER DOCUMENTATION M-200 IPB	CR04ABCD-IPB-1	I
94I124	CR04E/F CARD READER DOCUMENTATION M-1000 IPB	CR04E/F IPB-1	I
EKOCR11TM	CR11/CM11 CARD READER SYSTEM MANUAL	EK-OCR11-TM-001	H
94I128	CRO4H/J CARD READER DOCUMENTATION M-1200 IPB	CRO4H/J-IPB-1	I
EKDA11FMM	DA11-F UNIBUS WINDOW MAINT MANUAL	EK-DA11F-MM-001	E
05V156	DATA PRODUCTS MODEL 2230 LINE PRINTER MANUAL (LP05) VOL I		I

PART NO	TITLE	INDEX CODE	PRICE
05V157	DATA PRODUCTS MODEL 2230 LINE PRINTER MANUAL (LP05) VOL II		I
EKDB11ATM	DB11-A BUS REPEATER MANUAL	EK-DB11A-TM-002	F
99H165	DB88/98/99 INTERPROCESSOR BUFFER SYSTEM	89-HOAA-D	E
68H120	DC08 TELEGRAPH LINE SUBSYSTEM OPTION MAINT MANUAL	11-HDC8A-A-D	F
EKODC11TM	DC11 ASYNCHRONOUS LINE INTERFACE MANUAL (DECCOMM)	EK-ODC11-TM-004	F
EKOK01AIN	DECKIT01-A ASSEMBLY & INSTALLATION MANUAL	EK-K01A-IN-001	F
EKKT11DIN	DECKIT11-D ASSEMBLY AND INSTALLATION MANUAL	EK-HKITD-IN-001	F
EKOK11FIN	DECKIT11-F ASSEMBLY & INSTALLATION MANUAL	EK-K 11F-IN-001	E
EKOK11HIN	DECKIT11-H ASSEMBLY AND INSTALLATION MANUAL (LOGIC)	EK-OK11H-IN-001	E
EKOK11MIN	DECKIT11-M ASSEMBLY AND INSTALLATION MANUAL (LOGIC)	EK-OK11M-IN-002	F
EKDECNTBD	DECNET SUPPORT MANUAL BINDER		-
EKDECNTV1	DECNET SUPPORT MANUAL (VOL 1)		E
EKDECNTV2	DECNET SUPPORT MANUAL (VOL 2)		E
EKDECNTV3	DECNET SUPPORT MANUAL (VOL 3)		E
EKOVT5XOP	DECScope USERS MANUAL (CROSS PRODUCTS)	EK-OVT5X-OP-001	E
EKTY80AOP	DECSET-8000 CLASS AD STORAGE-8000 SYS USERS GUIDE VOL3	EK-TY80A-OP-001	C
EKTY808PR	DECSET-8000 DRIVER MARKUP MANUAL AND UPDATE NOTICE	EK-TY808-PR-001	C
EKTY800OP	DECSET-8000 SYSTEM USERS GUIDE VOLUME 1 (TYPESET)	EK-TY800-OP-002	E
EKVT204OP	DECSET-8000 VT20 TERMINAL USERS GUIDE VOL IV	EK-VT204-OP-002	E
63H020	DECSYSTEM-10 LAYOUT KIT	10-KITB-D	I
99H173	DECTAPE 552 INSTRUCTION MANUAL	H-552	E
99H175	DECTAPE CONTROL 550 INSTR MAN	H-550	F
EKTY801OP	DECWIRE-8000 SYSTEM USERS GUIDE	EK-TY801-OP-001	F
EKDF11BMM	DF11-BA/DF11-BB MODEM MAINT MANUAL	EK-DF11B-MM-002	E
99H182	DF32 DISK FILE & CONTROL OPT INSTALLATION INSTRUCTIONS-8I	8I-HDFAA-A-D	E
99H183	DF32 DISK FILE & CONTROL OPT INSTALLATION INSTRUCTIONS-8L	8L-HDFAA-B-D	E
99H179	DF32 DISK FILE + CONTROL OPT INSTALLATION INSTR LINC 8	L8-HDFAA-A-D	E
99H185	DF32 DISK FILE + CONTROL OPT INSTALLATION INSTRUCTIONS-8S	8S-HDFAA-A-D	E
99H072	DF32 DISK FILE AND CONTROL MAINT MANUAL	08-IDFB-D	F
99H181	DF32 DISK FILE AND CONTROL INSTALLATION INSTRUCTIONS-PDP8	08-HDFAA-D	E
EKODF32MM	DF32 TIMING TRACK WRITER MAINTENANCE MANUAL	EK-ODF32-MM-001	H
89H055	DF32D,E DISK FILE + CONTROL MAINT MANUAL	8E-HDFDE-B-D	E
EKDF32DIP	DF32D/E DEC DISK IPB	DF32D/E-IPB-2	I
EKDFC11MM	DFC11-A EIA LEVEL CONVERTER/ CLOCK RECOVERY MODULE MAINT MA	EK-DFC11-MM-002	F
EKODH11MM	DH11 ASYNCHRONOUS 16-LINE MULTIPLEXER MAINT MANUAL	EK-ODH11-MM-002	F
05V182	DIABLO SYSTEMS SERIES 30 DISK DRIVE MAINT MANUAL JUNE 1972	D3140-171	I
EKODJ11MM	DJ11 ASYNCHRONOUS 16-LINE MULTIPLEXER MAINT MAN	EK-DJ11-MM-003	F
EKODL11TM	DL11 ASYNCHRONOUS LINE INTERFACE MANUAL	EK-ODL11-TM-003	H
EKDL11WMM	DL11-W SERIAL LINE UNIT/REAL-TIME CLOCK OPTION M.M. (PRELIM)	EK-DL11W-MM-PRE	E
99H190	DM01 DATA MULTIPLEXER MAINT MANUAL	08-18AA-D	E
EKDM11ATM	DM11 ASYNCHRONOUS 16-LINE SINGLE-SPEED MULTIPLEXER MANUAL	EK-DM11A-TM-002	H
EKDM11BTM	DM11-BB MODEM CONTROL OPTION MANUAL	EK-DM11B-TM-002	F

PART NO	TITLE	INDEX CODE	PRICE
EKDMCMPMM	DMC11 IPL MICROPROCESSOR MAINTENANCE MANUAL (PRELIM)	EK-DMCMP-MM-001	G
EKDMCLUMM	DMC11 IPL SYNCHRONOUS LINE UNIT MAINT MANUAL	EK-DMCLU-MM-001	F
EKODN11TM	DN11 AUTOMATIC CALLING UNIT INTERFACE MANUAL (DDP)	EK-ODN11-TM-002	I
05V218	DOCUMENTATION M200 CARD READER (AUGUST 1974)		I
05V230	DOCUMENTATION OM200 CARD READER (FEBRUARY 1972)		I
99H193	DP01A DATA COMMUNICATIONS CHANNEL MAINT MANUAL	08-18BA-D	H
68H160	DP11A SYNCHRONOUS LINE INTERFACE MANUAL	11-HDPAA-C-D	H
EKODQ11MM	DQ11 NPR SYNCHRONOUS LINE INTERFACE MANUAL (DECCOMM)	EK-ODQ11-MM-002	H
EKDR11BTM	DR11-B/DA11-B MANUAL	EK-DR11B-TM-004	K
EKDR11CTM	DR11-C GENERAL DEVICE INTERFACE MANUAL	EK-DR11C-TM-004	E
EKDR11KMM	DR11-K INTERFACE USERS GUIDE AND MAINTENANCE MANUAL	EK-DR11K-MM-00/1	F
EKDR11LOP	DR11-L/DR11-M GENERAL-PURPOSE UNIBUS INTERFACE USERS MANUAL	EK-DR11L-OP-001	F
EKDR8EDOP	DR8-ED GENERAL-PURPOSE INPUT INTERFACE USERS MANUAL	EK-DR8ED-OP-001	F
EKDRV1BOP	DRV11-B GENERAL PURPOSE DMA INTERFACE USERS MANUAL	EK-DRV1B-OP-001	C
EKDRV11OP	DRV11-P FOUNDATION MODULE USERS MANUAL (LOGIC)	EK-DRV11-OP-001	C
EKODS11TM	DS11 MULTIPLE LINE SYNCHRONOUS INTERFACE MANUAL VI	EK-DS11-TM-002	H
EKDS310IP	DS310 DEC DATASYSTEM IPB	EK-DS310-IP-001	I
EKODU11MM	DU11 SINGLE LINE PROGRAMMABLE SYNCHRONOUS INTERFACE MAINT M	EK-ODU11-MM	E
EKDUPL1MM	DUP-11 BIT SYNCHRONOUS INTERFACE MAINT MANUAL (PRELIM)	EK-DUPL1-MM-001	E
EKODV11MM	DV11 SYNCHRONOUS MULTIPLEXER MAINT MANUAL	EK-ODV11-MM-001	F
EKDX11BMM	DX11-B SYSTEM 360/370 CHANNEL TO PDP-11 UNIBUS INTERFACE MM	EK-DX11B-MM-001	I
EKODZ11MM	DZ11 ASYNCHRONOUS MULTIPLEXER MAINT MANUAL (PRELIM)	EK-ODZ11-MM-PRE	E
EKOFPL1MM	FP11-B FLOATING-POINT PROCESSOR MAINT MANUAL	EK-OFPL1-MM-003	J
EKFP11CMM	FP11-C FLOATING-POINT PROCESSOR MAINT MANUAL (11/70)	EK-FP11C-MM-001	F
15H120	FP15 FLOATING POINT PROCESSOR MAINT MANUAL VOL I	15-HQFA-D	H
74H250	FP12A FLOATING POINT PROCESSOR USERS MANUAL	12-HFPPA-A-D	F
EKFPP8AMM	FPP8-A MAINTENANCE MANUAL		G
94I150	GT40 GRAPHIC TERMINAL IPB	GT40-IPB-1	I
EKH7070IP	H7070 POWER SUPPLY IPB	EK-H7070-IP-001	I
EKOH720TM	H720 POWER SUPPLY AND MOUNTING BOX MANUAL (PDP-11)	EK-OH720-TM-003	J
EKOH721IP	H721 POWER SUPPLY IPB	H721-IPB-1	I
19H135	H740D POWER SUPPLY MAINTENANCE MANUAL	11-H740A-1-D	F
EKH740DIP	H740D/DA POWER SUPPLY IPB	EK-H740D-IP-002	I
EKOH742IP	H742 POWER SUPPLY IPB	H742-IPB-1	I
EKH7420IP	H7420 POWER SUPPLY IPB	EK-H7420-IP-001	I
EKOH744IP	H744 REGULATOR IPB	H744-IPB-1	I
EKOH745IP	H745 REGULATOR IPB	H745-IPB-1	I
EKOH746IP	H746 REGULATOR IPB	H746-IPB-1	I
EKOH750IP	H750 POWER SUPPLY IPB	EK-H750-IP-002	I
EKOH754IP	H754 REGULATOR IPB	H754-IPB-1	I
EKOH765IP	H765 POWER SUPPLY IPB	H765-IPB-1	I
EKH9300IP	H9300 CHASSIS ASSEMBLY IPB	EK-H9300-IP-001	I
19H110	HARDWARE MANUAL SET	11-H5SPK-A-D	F
EKICR11MM	ICR11 INDUSTRIAL CONTROL SUBSYSTEM REMOTE MAINT MANUAL	EK-ICR11-MM-001	F
EKICS11MM	ICS-11 INDUSTRIAL CONTROL SUBSYSTEM MAINT MANUAL	EK-ICS11-MM-003	F
EKOICS8MM	ICS-8 INDUSTRIAL CONTROL SUBSYSTEM MAINT MANUAL	EK-OICS8-MM-001	F

PART NO	TITLE	INDEX CODE	PRICE
46H225	IDACS8-A INDUSTRIAL DATA ACQUISITION + CONTROL MAINT MAN	Ø8-HIDCA-A-D	F
14H235	INDUSTRIAL 14 MAINT MANUAL	14-HIMMA-A-D	K
14H245	INDUSTRIAL 14 SYSTEM MANUAL	14-HSMAA-A-D	K
EKOVT14ØP	INDUSTRIAL 14 VT14 USERS MANUA	EK-VT14-OP-ØØ2	K
EKICSACOD	INDUSTRIAL CONTROL SUBSYSTEM	EK-ISCAC-OD-ØØ1	A
	AC OPTION DESCRIPTIONS		
EKOKA11TM	KA11 PROCESSOR MANUAL	EK-KA11-TM-ØØ2	L
99H32Ø	KA8L HIGH SPEED PERFORATED TAPE READER & CONTROL OPTION	8L-D2BA-D	E
EKKB11AMM	KB11-A CENTRAL PROCESSOR UNIT MAINT MANUAL	EK-KB11A-MM-ØØ4	J
EKKB11BTM	KB11-B PROCESSOR MANUAL (11/7Ø)	EK-KB11B-TM-ØØ1	J
EKKB11CTM	KB11-C PROCESSOR MANUAL (PDP-11/7Ø)	EK-KB11C-TM-ØØ1	H
99H325	KB8I GENERAL I/O INTERFACE OPTION DESCRIPTION	8I-HODA-D	E
19H165	KC11 PROCESSOR MANUAL (LP11A, KF11A)	11-HKCB-D	L
EKOKC8AIP	KC8A CONSOLE IPB	EK-OKC8A-IP-ØØ1	I
EKKC8EAIP	KCBEA/EC CONSOLE IPB	KC8EA/EC-IPB-1	I
94I156	KC8FL CONSOLE IPB	KC8FL-IPB-1	I
94I16Ø	KC8ML/M CONSOLE IPB	KC8ML/M IPB-1	I
EKKD11AMM	KD11-A PROCESSOR MAINTENANCE MANUAL	EK-KD11A-MM-ØØ1	F
EKKD11BMM	KD11-B PROCESSOR MAINTENANCE MANUAL	EK-KD11B-MM-ØØ1	F
EKKD11DTM	KD11-D PROCESSOR MANUAL (PRE)	EK-KD11DTM-PRE	F
EKKD11ETM	KD11-E PROCESSOR MANUAL (PDP-11/34) (PRELIM)	EK-KD11E-TM-PRE	F
99H33Ø	KD8L DATA BREAK OPTION FUNCTIONAL DESCRIPTION	8L-HOAA-D	J
99H34Ø	KEØ9A EXTENDED ARITHMETIC ELEMENT INSTRUCTION MANUAL	Ø9-I2AA-D	H
EKKEl1ATM	KEl1-A EXTENDED ARITHMETIC ELEMENT MANUAL	11-HKEA-D	J
EKKEl1BMM	KEl1-B ARITHMETIC UNIT MAINTENANCE MANUAL	EK-KEl1B-MM-ØØ1	F
EKKEl1ETM	KEl1-E & KEl1-F INSTRUCTION SET OPTIONS MANUAL	EK-KEl1E-TM-ØØ2	F
99H342	KE8I EXTENDED ARITHMETIC ELEMENT	8I-HOCA-D	E
99H35Ø	KFØ9A AUTOMATIC PRIORITY INTERRUPT INSTRUCTION MANUAL	Ø9-15AA-D	F
99H345	KGØ9B MEMORY EXTENSION CONTROL MAINT MANUAL	Ø9-11AA-D	E
EKKG11ATM	KG11-A EXCLUSIVE-OR AND CRC BLOCK CHECK MANUAL	EK-KG11-A TM ØØ2	H
EKKL8ØAOP	KL8-A USERS MANUAL	EK-KL8ØA-OP-ØØ1	E
99H6Ø5	KP8I POWER FAILURE OPTION FUNCTION DESCRIPTION		E
99H355	KP8L POWER FAILURE OPTION FUNCTIONAL DESCRIPTION	8L-DOBA-D	E
EKKT11CMM	KT11-C,CD MEMORY MANAGEMENT UNIT MAINT MANUAL	EK-KT11C-MM-ØØ5	I
EKKT11DTM	KT11-D MEMORY MANAGEMENT OPTION MANUAL	EK-KT11D-TM-ØØ2	F
99H358	KT8I TIME SHARING OPTION	8I-H8NA-D	E
99H364	KWØ9L LINE FREQUENCY INTERNAL CLOCK MANUAL	9L-H8AA-D	H
EKKW11KOP	KW11-K DUAL PROGRAMMABLE REAL TIME CLOCK USER MANUAL (LDP)	EK-KW11K-OP-ØØ1	C
EKKW11LTM	KW11-L LINE TIME CLOCK MANUAL	EK-KW11L-TM-ØØ2	E
EKKW11PMM	KW11-P PROGRAMMABLE REAL-TIME CLOCK MANUAL (ETCH REV F & UP)	EK-KW11P-MM-ØØ3	F
EKKW11WTM	KW11-W WATCHDOG TIMER MANUAL	EK-KW11W-TM-ØØ1	E
99H365	KXØ9A MEMORY PROTECTION OPTION INSTRUCTION MANUAL	Ø9-11BA-D	E
19H229	KY11-C PROGRAMMER S CONSOLE MANUAL	11-HYAC-D	G
EKKY11JIP	KY11-J CONSOLE IPB	KY11J-IPB-1	I
94I167	KY11-K CONSOLE IPB	KY11K-IPB-1	I
EKLA18ØIP	LA18Ø DECPRINTER I IPB	EK-LA18Ø-IP-ØØ1	I
EKLA18ØMM	LA18Ø DECPRINTER I MAINTENANCE MANUAL	EK-LA18Ø-MM-ØØ1	H

PART NO	TITLE	INDEX CODE	PRICE
EKLA18ØOP	LA18Ø DECPRINTER I USERS MANUAL (CROSS PRODUCTS)	EK-LA18Ø-OP-ØØ2	E
94I176	LA3Ø DECWRITER IPB	LA3Ø-IPB-2	I
99H174	LA3Ø DECWRITER MAINT MANUAL	ØØ-LA3Ø-DD	E
EKOLA35IP	LA35 DECWRITER II IPB	EK-OLA35-IP-ØØ1	I
EKLA365OP	LA35/36 USERS MANUAL	EK-LA365-OP-ØØ2	E
EKOLA36IP	LA36 DECWRITER II IPB	EK-OLA36-IP-ØØ4	I
EKOLA36MM	LA36 DECWRITER II MAINTENANCE MAN	EK-OLA36-MM-ØØ1	K
EK2LA36MM	LA35/36 MAINTENANCE MANUAL VI		I
EKLAØØ8OP	LA8 USER S GUIDE	EK-LAØØ8-OP-ØØ1	C
84H56Ø	LAB-8/E MAINT MANUAL	LB-H8EMM-B-D	J
EKLAV11OP	LAV11 USERS MANUAL (PRELIM)	EK-LAV11-OP-ØØ1	C
EKLAXXNOP	LAXX-NW,NX,NY/LA18Ø BUFFERED SERIAL INTERFACE USERS MANUAL	EK-LAXXN-OP-ØØ1	C
19H25Ø	LC11 DECWRITER SYSTEM MAINT MANUAL	11-HLCB-D	H
99H415	LIGHT PEN 37Ø INSTRUCTION MAN	H-37Ø	F
99H425	LINC8 ADJUSTMENT PROCEDURE MAN	L8-HGZA-D	I
94I182	LKØ2 KEYBOARD IPB	LKØ2-IPB-1	I
94I183	LKØ3 KEYBOARD IPB	LKØ3-IPB-1	I
EKLKØ3AIP	LKØ3A KEYBOARD IPB	EK-LKØ3A-IP-ØØ1	I
EKOLK11TM	LK11 PUSHBUTTON OPTION TECHNICAL MANUAL (LDP)	EK-OLK11-TM-ØØ1	C
94I185A	LK4Ø KEYBOARD IPB	LK4Ø-IPB-2	I
99H43Ø	LPØ8 LINE PRINTER INTERFACE MANUAL	Ø8-HRLB-D	E
EKOLP11TM	LP11/LS11/LA11 LINE PRINTER MANUAL	EK-OLP11-TM-ØØ6	F
15H13Ø	LP15C LINE PRINTER CONTROL MAINT MANUAL	15-H2LA-D	E
15H133	LP15F LINE PRINTER CONTROL MAINT MANUAL	15-H1LB-D	E
EKLPCØ1MM	LPCØ1 UNIVERSAL INTERFACE MAINTENANCE MANUAL	EK-LPCØ1-MM-ØØ2	E
EKLPC11MM	LPC11 PHOTOCOMP INTERFACE MAINT MANUAL (TYPESET-11)	EK-LPC11-MM-ØØ1	C
EKLPD11MM	LPD11 INTERFACE MAINTENANCE MANUAL (TYPESET)	EK-LPD11-MM-ØØ1	F
22H18Ø	LPD8 CONTROL INTERFACE MAINT MANUAL	Ø8-HLPDA-A-D	F
EKLPS11OP	LPS-11 LAB PERIPHERAL SYSTEM USERS GUIDE	EK-LPS11-OP-ØØ3	H
EKLPS11MM	LPS11-S LABORATORY PERIPHERAL SYSTEM MAINT MANUAL	EK-LPS11-MM-ØØ2	H
EKLSI11TM	LSI-11,PDP-11/Ø3 USERS MANUAL	EK-LSI11-TM	F
99H435	LT19 MULTI-STATION TERMINAL CONTROL MANUAL	Ø9-H2AB-D	F
99H195	LT33 TELETYPE UNPACKING AND INSTALLATION PROCEDURES	ØØ-HLTTA-A-D	E
EKOLVØ8OP	LV8/LV12/LV11 PRINTER/PLOTTER USERS GUIDE (LAB DATA)	EL-OLVØ8-OP-ØØ1	E
EKM785ØMM	M785Ø PARITY CONTROLLER MAINTENANCE MANUAL (PRE)	EK-M785Ø-MM	E
EKM93Ø1MM	M93Ø1 BOOTSTRAP TERMINATOR MAINTENANCE MANUAL	EK-M93Ø1-MM-PRE	E
99H45Ø	MC8L MEMORY EXTENSION CONTROL OPTION FUNCTIONAL DESCRIPTION	8L-D4BA-D	E
EKME11LTM	ME11-L CORE MEMORY SYSTEM MANUAL	EK-ME11L-TM-ØØ2	F
EKOME15MM	ME15 CORE MEMORY MAINT MANUAL	15-HMEMA-A-D	F
EKMFL1UUMM	MF11-U/UP CORE MEMORY SYSTEMS MAINT MAN	EK-MF11U-MM-ØØ3	G
EKMFL1WMM	MF11-W/WP CORE MEMORY SYSTEM MAINT MANUAL	EK-MF11W-MM-ØØ1	F
EKMFL15UMM	MF15-U CORE MEMORY MAINTENANCE MANUAL	EK-MF15U-MM-ØØ1	E
EKMFL15WMM	MF15-W CORE MEMORY SYSTEM MAINT MANUAL	EK-MF15W-MM-ØØ1	F
EKOMJ11MM	MJ11 MEMORY SYSTEM MAINTENANCE MANUAL (11/7Ø)	EK-MJ11-MM-ØØ1	G
EKMM11CTM	MM11-C/CP CORE MEMORY MANUAL (INCLUDES MM11-B/BP) (PRELIM)	EK-MM11C-TM-PRE	E
EKMM11DTM	MM11-D/DP CORE MEMORY MANUAL	EK-MM11D-TM-ØØ1	F
19H323	MM11-F CORE MEMORY MANUAL	11-HMFA-D	J

PART NO	TITLE	INDEX CODE	PRICE
EKMM11STM	MM11-S,MF11-L AND MF11-LP CORE MEMORY SYSTEMS MANUAL	EK-MM11S-TM-004	E
EKMM11ETM	MM11E CORE MEMORY MANUAL	EK-MM11E-TM-002	J
99H470	MP09C MEMORY PARITY OPTION MAINT MANUAL	09-HIAA-D	F
89H290	MR8F 1K PROM (PRELIM) MAINT MANUAL	8E-HR2B-D-MR8F	C
EKMS11AMM	MS11-A,B,C MEMORY SYSTEMS MAINT MANUAL	EK-MS11A-MM-006	F
EKMS11EMM	MS11-E-J MOS MEMORY MAINT MAN	EK-MS11E-MM-001	E
EKMSV11OP	MSV11-C USERS MANUAL		E
15H145	MX15 MEMORY BUS MULTIPLEXER MAINT MANUAL VOL I	15-H2XB-D	E
EKNC11ATM	NC11-A CAMERA INTERFACE FOR A GAMMA-11 SYSTEM MANUAL (LOGIC	EK-NC11A-TM-001	E
22H570	PA611 READER/PUNCH CONTROL MAINT MANUAL (TYPESET-11)	11-HTPAA-B-D	K
99H505	PA68A READER/PUNCH CONTROL INSTRUCTION MANUAL	08-19AA-D	E
99H255	PC04 HIGH-SPEED PERFORATED TAPE READER/PUNCH MAINT MANUAL	00-HGPA-D	E
94I250	PC04 PAPER TAPE READER/PUNCH IPB	PC04-IPB-2	I
99H265	PC04/PC05 PAPER TAPE READER/ PUNCH (FEED-HOLE STROBED) MAN	00-HPCAA-C-D	E
EKOPC11TM	PC11 HIGH SPEED READER/PUNCH & CONTROL MANUAL	EK-PC11-TM-003	G
EKPD111IN	PDL-11 INSTALLATION MANUAL (LAB DATA)	EK-PDL11-IN-001	E
EKPDM70MM	PDM70 PROGRAMMABLE DATA MOVER USERS/MAINT MANUAL	EK-PDM70-MM-003	F
94H285	PDM70 TESTER(KP20)MAINT MAN	FS-HPDMT-A-D	F
89H575	PDP 8F INSTALLATION PROC	08-HIPAA-A-D	A
99H640	PDP 8S MAINTENANCE MANUAL	F-87S	K
EKFS003IN	PDP-11 FAMILY FIELD INSTALLATION & ACCEPTANCE PROCEDURE	EK-FS003-IN-PRE	C
EKWIRETIN	PDP-11 WIRE TROUGH INSTALLATION MANUAL	EK-WIRET-IN-001	C
EK11004MM	PDP-11/04 SYSTEM MAINTENANCE GUIDE (PRELIM)	EK-11004-MM-001	C
EK11004OP	PDP-11/04 USERS GUIDE (PRE)	EK-11004-OP-PRE	F
EK11005TM	PDP-11/05 11/10 COMPUTER MANUAL	EK-11005-TM-003	J
94I275A	PDP-11/05 16 BIT COMPUTER IPB (10 1/2)	11/05(10-5)-IPB-2	I
EK11005ED	PDP-11/05 NC,ND DISASSEMBLY PROCEDURE	EK-11/05-ED-001	F
EK1105STM	PDP-11/05-S 11/10-S SYSTEM MANUAL	EK-1105S-TM-003	F
EK1105SIP	PDP-11/05-S 16 BIT COMPUTER IPB	11/05S-IPB-1	I
EK11015TM	PDP-11/15 SYSTEM MANUAL	EK-11015-TM-001	K
EK11020TM	PDP-11/20 SYSTEM MANUAL		H
EK11034MM	PDP-11/34 SYSTEM MAINTENANCE GUIDE (PRE)	EK-11034-MM-001	C
EK11034OP	PDP-11/34 USERS GUIDE (PRE) PRELIMINARY)	ED-11034-OP-PRE	F
94I276	PDP-11/35 16 BIT COMPUTER IPB (BASIC)	PDP-11/35-IPB-1	I
EK11035TM	PDP-11/35(BA11-DA,DB 10 1/2 IN MOUNTING BOX) SYSTEM MANUAL	EK-11035-TM-001	F
EK1103SIP	PDP-11/35-S 16 BIT COMPUTER IPB	11/35S-IPB-1	I
EK1135STM	PDP-11/35-S SYSTEM MANUAL	EK-1135S-TM-002	E
EK11040IP	PDP-11/40 16 BIT COMPUTER IPB (BASIC)	PDP11/40-IPB-1	I
EK11040TM	PDP-11/40-11/35 (21 INCH CHAS SYSTEM MANUAL	EK11040-TM-002	F
EK11MOSTM	PDP-11/45 11/50 MOS MEMORY TROUBLESHOOTING GUIDE	EK-11MOS-TM-002	F
EK1104SIP	PDP-11/45 16 BIT COMPUTER BASIC IPB	PDP11/45-IPB-1	I
EK11001HR	PDP-11/45 MAINTENANCE REFERENCE MANUAL	EK-11001-HR-001	C
EK11045MM	PDP-11/45,11/50,11/55 SYSTEM MAINT MANUAL	EK-11045-MM-005	J


PART NO	TITLE	INDEX CODE	PRICE
EK11050IP	PDP-11/50 16 BIT COMPUTER BASIC IPB	PDP11/50-IPB-1	I
EK11070IP	PDP-11/70 16 BIT COMPUTER (BASIC) IPB	EK-11/70/IP-001	I
EK11070MM	PDP-11/70 MAINTENANCE & INSTALLATION MANUAL (PRELIMINARY)	EK-11070-MM-PRE	E
EK11E050P	PDP-11/E/05 MINISYSTEM USERS GUIDE	EK-11E05-OP-001	E
72H405	PDP-12 INSTALLATION AND MAINT MANUAL V2	12-HR2B-D	E
72H425	PDP-12 MAINT MANUAL VOL 1 PRINCIPLES OF OPERATION	12-HR1B-D	I
EK14001MM	PDP-14 MAINTENANCE MANUAL	EK-14001-MM-002	F
15H148	PDP-15 INDUSTRIAL CONTROL SYS MAINT MANUAL VOL 1	15-H2QA-D	E
15H150	PDP-15 INSTALLATION MANUAL	15-H2AB-D	E
15H160	PDP-15 MODULE MANUAL	15-H2EB-D	I
15H163	PDP-15 OPERATORS GUIDE	15-H2CB-D	F
EK15XVMOP	PDP-15 XVM SYSTEMS REFERENCE MANUAL	15-H2DC-D	H
16H005	PDP-16M MAINT MANUAL	16-HMMA-A-D	E
99H515	PDP-8 DB08 INTERPROC DATA BUFFER MAINT MANUAL	08-H8PA-D	H
99H518	PDP-8 MAGNETIC TAPE CONTR 57A ENGINEERING DRAWINGS	H57A	I
99H523	PDP-8 MAINTENANCE MANUAL	F-87A	L
99H525	PDP-8 MULTIPLEXER SUBSYSTEM MAINT MANUAL	08-H6AA-D	H
EK8A002MM	PDP-8/A MINIPROCESSOR USERS MANUAL	EK-8A002-MM-001	J
EK8A001OP	PDP-8/A OPERATORS HANDBOOK	EK-8A001-OP-002	F
EKPDP8E1P	PDP-8/E 12 BIT COMPUTER IPB	PDP8E-IPB-1	I
EK8E002MM	PDP-8/E/F/M INTERNAL BUS OPTIONS MAINT MANUAL VOL 2		J
89H490	PDP-8/E/F/M MAINTENANCE MANUAL VOLUME 2	EK-8E002-MM-005	J
89H550	PDP-8/E/F/M MAINTENANCE MANUAL VOLUME 1	8E-HMM1A-D-D	J
EK8E003MM	PDP-8/E/F/M MAINTENANCE MANUAL VOLUME 3	EK-8E003-MM-004	J
94I259A	PDP-8/F 12 BIT COMPUTER (12) IPB	PDP8F(12)-IPB-2	I
EK08F151P	PDP-8/F 12 BIT COMPUTER (15) IPB	PDP8F(15)-IPB-2	I
EKPDP8I1P	PDP-8/I 12 BIT COMPUTER IPB	PDP8I-IPB-1	I
99H565	PDP-8/I CM8I CARD READER	8I-HICA-D	E
99H567	PDP-8/I DC08 TELEGRAPH LINE SYSTEM OPTION		H
99H568	PDP-8/I DC08F MODEM INTERFACE CONTROL	8I-H80A-DNF	H
99H569	PDP-8/I DC08H AUTOMATIC CALL UNIT CONTROL	8I-H801-DH	H
99H755	PDP-8/I HIGH SPEED PAPER TAPE PUNCH OPTION FUNCTIONAL DESCR	8I-H2CA-D	E
99H600	PDP-8/I MAINTENANCE MANUAL V1	8I-HRIA-D	J
99H603	PDP-8/I TRAINING DRAWINGS VOL		E
99H604	PDP-8/I TRAINING DRAWINGS VOL II		E
EKPDP8L1P	PDP-8/L 12 BIT COMPUTER IPB	PDP8L-IPB-1	I
99H614	PDP-8/L BA08 PERIPHERAL EXPAND	8L-H8AA-D	E
99H615	PDP-8/L BA08 PERIPHERAL EXPAND OPT INSTALLATION INSTRUCTIONS	8L-I8AA-D	E
99H618	PDP-8/L DC02 MULTI-DATA CONTRO MAINT MANUAL	8L-H2CB-D	J
EKPDP8M1P	PDP-8/M 12 BIT COMPUTER (12) IPB	PDP8M(12)-IPB-2	I
94I265A	PDP-8/M 12 BIT COMPUTER (15) IPB	PDP8M(15)-IPB-2	I
94I256	PDP-8/A 12-BIT COMPUTER IPB IPB	EK-8A000-IP-001	I
99H715	PDP-9 34H OSCILLOSCOPE DISPLAY INSTRUCTION MANUAL	09-16AA-D	E
99H720	PDP-9 DM09A ADAPTER/MULTIPLEXE MAINT MANUAL	09-19AB-D	F
99H740	PDP-9 SYSTEM ADJUSTMENT MANUAL	9A-HOAA-D	E

PART NO	TITLE	INDEX CODE	PRICE
99H75Ø	PDP-9/L PCØ9C HIGH SPEED PAPER TAPE READER & PUNCH MAINT MAN	9L-H2AB-D	F
Ø5V572	PERTEC MODEL D2ØØØ DISK MEMORY DRIVE OPER SERVICE MANUAL	1Ø2524	I
Ø5V578	PERTEC POWER SUPPLY MODEL 9ØØØ OPER & SERVICE MANUAL 1971	1Ø2534	I
EKPMKØ1MM	PMKØ1 PROCESSOR MAINTENANCE KIT MAINT MANUAL	EK-PMKØ1-MM-ØØ2	E
94I284	PR68A/B PAPER TAPE READER IPB	PR68A/B-IPB-1	I
94I288	PR68D/DA PAPER TAPE READER IPB	PR68D/DA-IPB-1	I
94I292	PR68E PAPER TAPE READER IPB	PR68E-IPB-1	I
EKDQ11ØP	PROGRAMMING THE DQ11 NPR SYNCHRONOUS INTERFACE MANUAL	EK-DQ11-OP-ØØ1	F
99H815	RCØ9 DISK CONTROL MAINT MANUAL	Ø9-15BA-D	E
19H458	RC11 DISK CONTROL MANUAL	11-HRCB-D	K
EKT11EDOP	REPORTERS AND EDITORS GUIDE TO THE VT2Ø AND TYPESET-11	EK-T11ED-OP-ØØ1	H
99H29Ø	RFØ8 DISK CONTROL AND RSØ8 DISK MAINT MANUAL	Ø8-HIEA-DA	H
99H818	RFØ9/RSØ9 DECDISK SYSTEM MAINT MANUAL V2	Ø9-H9ZA-D	J
EKORF11TM	RF11/RS11 DECDISK SYSTEM MANUAL	EK-ORF11-TM-ØØ4	K
15H18Ø	RF15/RSØ9 DECDISK MAINT MANUAL VOL I	15-H2IC-D	F
EKRJPØ4MM	RJPØ4 MOVING HEAD DISK SUBSYSTEM MAINT MANUAL	EK-RJPØ4-MM-ØØ3	F
EKRJPØ5MM	RJPØ5/Ø6 MOVING HEAD DISK SUBSYSTEM MAINT MANUAL	EK-RJPØ5-MM-ØØ1	F
EKRJSØ4MM	RJSØ4/RJSØ3 FIXED-HEAD DISK SYSTEM MAINT MANUAL	EK-RJSØ4-MM-ØØ2	E
94I315	RKØ5 DISK DRIVE IPB	RKØ5-IPB-2	I
EKORKØ5MM	RKØ5 DISK DRIVE MAINTENANCE MANUAL	EK-ORKØ5-MM-ØØ4	E
EKRK5JFMM	RKØ5/RKØ5J/RKØ5F DISK DRIVE MAINTENANCE MANUAL		E
EKRKØ5XMM	RKØ5-EXERCISER MAINTENANCE MANUAL (CROSS PRODUCTS)	EK-RKØ5X-MM-ØØ2	E
EKORKØ6IP	RKØ6 DISK DRIVE IPB		I
EKRK11CTM	RK11-C MOVING HEAD DISK DRIVE CONTROLLER MANUAL	EK-RK11C-TM-ØØ4	K
EKRK11DMM	RK11-D & RK11-E MOVING HEAD DISK DRIVE CONTROLLER MANUAL	EK-RK11D-MM-ØØ2	F
EKRK611OP	RK611/RKØ6 DISK SUBSYSTEM USERS MANUAL (CROSS)	EK-RK611-OP-ØØ1	F
99H315	RK8 DISK SYSTEM MAINT MANUAL	ØØ-HRKB-D	H
99H824	RMØ8 SERIAL DRUM SYSTEM INSTRUCTION MANUAL	Ø8-15AA-D	I
99H825	RMØ9 SERIAL DRUM SYSTEM INSTRUCTION MANUAL	Ø9-15CA-D	E
EKRPO2TMM	RPØ2/Ø3 TESTOR MANUAL	EK-RPØ2T-MM-ØØ1	E
EKORPØ4MM	RPØ4 DEVICE CONTROL LOGIC MAINT MANUAL	EK-ORPØ4-MM-ØØ1	E
EKORPØ4IN	RPØ4 DISK DRIVE INSTALLATION MANUAL	EK-ORPØ4-IN-ØØ1	E
EKORPO4IP	RPØ4 DISK PACK DRIVE IPB	RPØ4-IPB-1	I
EKRPO56IP	RPØ5/Ø6 677-Ø1.51 DISC DRIVE ILLUSTRATED PARTS CATALOG	EK-RPØ56-IP-ØØ1	E
EKRPO5MTM	RPØ5/Ø6 677-Ø1/51 DEC DISK STORAGE DRIVES LOG MAN 5Ø&6ØHZ	EK-RPØ5M-TM-VØ1	E
EROØØ12TM	RPØ5/Ø6 677-Ø1/51 DEC DISC STORAGE DRIVES TECH MAN VOL 1	EK-RPØ56-TM-ØØ1	H
EKRPO56MM	RPØ5/RPØ6 DEVICE CONTROL LOGIC MAINTENANCE MANUAL	EK-RPØ56-MM-ØØ1	E
EKRPl1CMM	RP11-C DISK PACK DRIVE CONTROLLER MAINT MANUAL	EK-RP11C-MM-ØØ3	E
EKRPl1EMM	RP11-E DISK PACK DRIVE CONTROLLER MAINT MANUAL	EK-RP11E-MM-ØØ1	F
EKRPl1EIN	RP11-E/RPRØ2 INSTALLATION MANUAL	EK-RP11E-IN-ØØ2	G
EKORP15MM	RP15 DISK PACK CONTROL MAINT MANUAL VOL 1	EK-ORP15-MM-ØØ1	J
EKRPRØ2IP	RPRØ2 66Ø-1 DISC DRIVE ILLUSTRATED PARTS CATALOG	EK-RPRØ2-IP-VØ1	F

PART NO	TITLE	INDEX CODE	PRICE
EKRPR02TM	RPR02 660-1 DISC PACK DRIVE TECHNICAL DESCRIPTION MANUAL	EK-RPR02-TM-VO1	C
EKRPR02MM	RPR02 660-1 DISC STORAGE DRIVE MAINTENANCE MANUAL	EK-RPR02-MM-VO1	F
EKRPR02LS	RPR02 660-A DISC PACK DRIVE LOGIC AND SCHEMATIC MANUAL	EK-RPR02-LS-VO1	F
EKRS03IP	RS03 DECDISK IPB	EK-RS03-IP-002	I
99H329	RS03 DECDISK SERVICE MANUAL	00-HRS3-A-D	F
EKORS04IP	RS04 DECDISK IPB	EK-RS04-IP-002	I
EKORS04SV	RS04 DECDISK SERVICE MANUAL	EK-RS04-SV-002	F
94H320	RS08 TIMING TRACK WRITER MAINT MANUAL	FS-HRS8B-A-D	E
94H322	RS09 TIMING TRACK WRITER MAIN MANUAL	FS-HRSAA-A-D	E
EKORS64IP	RS64 DISK FILE IPB IPB	RS64-IPB-2	I
99H332	RS64 DISK FILE MAINT MANUAL	00 HRS64-E-D	F
94H324	RS64 TIMING TRACK WRITER MAINT MANUAL	FS-HRSMM-A-D	E
58H125	RT01 DEC-LINK DATA TERMINAL MAINT MANUAL	00-HQRC-D	J
EKRT02AMM	RT02-A 30 CHARACTER KEYBOARD REMOTE TERMINAL MAINT MANUAL	EK-RT02A-MM-003	F
58H135	RT02-8 FULL KEYBOARD ALPHANUMERIC TERMINAL MAINT MANUAL	00-HRTBA-A-D	E
EKRT02CMM	RT02-C BADGE READER TERMINAL OPTION DESCRIPTION	EK-RT02C-MM-001	F
EKRT02FTM	RT02-F ALPHANUMERIC DISPLAY DATA TERMINAL OPT DESCRIPTION	EK-RT02F-TM-001	F
EKRWP04MM	RWP04 MOVING HEAD DISK SUBSYSTEM MANUAL	EK-RWP04-MM-001	E
EKRWP56MM	RWP05/RWP06 MOVING HEAD DISK SUBSYSTEM MAINT MANUAL	EK-RWP56-MM-001	H
EKRWS04MM	RWS04 FIXED-HEAD DISK SUBSYSTEM MAINT MANUAL	EK-RWS04-MM-001	F
EKORX01IOP	RX01 FLOPPY DISK IPB	EK-RX01-IP-001	I
EKORS08IP	RX08 DISK MEMORY IPB	RS08-IPB-1	I
EKORX01MM	RX8/RX11 FLOPPY DISK SYSTEM MAINT MANUAL (PRELIM)	EK-ORX01-MM-PRE2	G
EKRXV11OP	RXV-11 USERS MANUAL	EK-RXV11-OP-001	C
99H835	SERIAL DRUMS 250/251 INSTRUCTION MANUAL V2	08-152A-D	F
EKTY811SP	SITE PREPARATION KIT (TYPESET-8 & 11)	EK-56811-SP-001	F
EKSESUGOP	STORAGE & EDIT SYSTEM USERS GUIDE	EK-SESUG-OP-005	F
EKOTAl1MM	TA-11 CASSETTE SYSTEM MAINT MANUAL	EK-OTAl1-MM-002	G
EKTY804PR	TABS-8 ACCOUNTS PAYABLE SYSTEM MANUAL (TYPESET-8)	EK-TY804-PR-001	F
EKTY806PR	TABS-8 GENERAL LEDGER PACKAGE (TYPESET-8)	EK-TY806-PR-002	F
99H846	TC02 DECTAPE CONTROL MAINT MAN	09-13CA-D	H
99H850	TC08 DECTAPE CONTROLLER MAINT MANUAL	08-H3DA-D	H
EKOTC11TM	TC11 DECTAPE SYSTEM MANUAL	11-HTCB-D	L
15H186	TC15 DECTAPE CONTROL MAINT MANUAL	15-H2KB-D	H
15H188	TC59 MAGNETIC TAPE CONTROL INSTRUCTION MANUAL VOL 1	9A-13BC-D	F
99H845	TC01 TAPE CONTROL UNIT INSTRUCTION MANUAL	08-13AB-D	H
EKTJU16MM	TJU16 MAGNETIC TAPE SUBSYSTEM MAINT MANUAL	EK-TJU16-MM-002	F
EKOTM02IP	TM02 FORMATTER IPB	EK-TM02-IP-001	I
EKTMA11TM	TMA11 DECMAGTAPE SYSTEM	EK-TMA11-TM-002	F
EKTMB11MM	TMB11/TS03 DECMAGTAPE SYSTEM MAINT MANUAL (TMB11-M SYSTEM)	EK-TMB11-MM-001	J
EKTMS11MT	TMS-11 MAGTAPE BACKUP SYSTEM MANUAL		A
EKTMS11PR	TMS-11 MARKUP MANUAL (TYPESET)	EK-TMS11-PR-004	F
EKT11SYOP	TMS-11 SYSTEM MANAGERS AND USERS GUIDE (TYPESET)	EK-T11SY-OP-001	F
EKTR79FMM	TR79-FA DECMAGTAPE (1600 CPI) MAINT MANUAL	EK-TR79F-MM-001	E

PART NO	TITLE	INDEX CODE	PRICE
EKOTS03CC	TS03 DECMAGTAPE TRANSPORT CUSTOMER CARE SHEET (PDP-11)	EK-OTS03-CC-001	A
EKT3TM8MM	TS03/TM8E DECMAGTAPE SYSTEM MAINT MAN (CROSS)	EK-T3TM8-MM-001	J
EKOTU10TM	TU10 DECMAGTAPE MASTER SYSTEM MANUAL	EK-OTU10-TM-001	F
EKOTUIOTIP	TU10 DECMAGTAPE IPB	TU10-IPB-2	I
EKOTU10MM	TU10 DECMAGTAPE MAINTENANCE MANUAL	EK-OTU10-MM-006	F
EKDTU10MM	TU10D DECMAGTAPE MAINTENANCE MANUAL (CROSS PRODUCTS)	EK-DTU10-MM-002	F
EKOTU16IP	TU16 DECMAGTAPE IPB	EK-TU16-IP-001	I
EKOTU16MM	TU16/TM02 TAPE DRIVE SYSTEM MAINTENANCE MANUAL	EK-OTU16-MM-002	F
99H410	TU30 TAPE TRANSPORT MAIN MAN	00-TU30-D	H
EKOTU56IP	TU56 DECTAPE IPB	EK-0TU56-IP-003	I
99H429	TU56 DECTAPE TRANSPORT MAINT MANUAL	00-HTU56-D-D	E
94I371	TU60 CASSETTE TAPE TRANSPORT IPB	TU60-IPB-2	I
99H434	TU60 DECASSETTE TAPE TRANSPORT MAINT MANUAL	00-HTU60-C-D	H
EKTWU16MM	TWU16 MAGNETIC TAPE SUBSYSTEM MAINT MANUAL (11/70)	EK-TWU16-MM-PRE	F
EKERVR30P	TYPESET-11 ERROR MESSAGES MANUAL VERSION 3	EK-ERVR3-OP-001	H
EKTY011PR	TYPESET-11 MARKUP MANUAL AND ADDENDUM	EK-TY011-PR-004	F
EKTYNEGMM	TYPESET-8 SYSTEMS-NEGATIVE LOGIC MAINT MANUAL (TYPESET-8)	EK-TYNEG-MM-001	E
EKOUC15MM	UC15 UNICHANNEL 15 SYSTEM MAINT MANUAL	15-HUCMA-B-D	F
EKICSTSMM	UDC/ICS TESTER UTILIZATION & MAINT MANUAL	EK-ICSTS-MM-001	E
46H745	UDC8 MAINTENANCE MANUAL *	08-HZDC-D	F
05V600	VERSATEC M-LVOL-03 OPERATIONS AND MAINT MANUAL (JAN 1973)		I
22H495	VIP DISPLAY AD PROGRAM MARKUP MANUAL (TYPESET-8)	08-HVIPA-A-D	F
94I420	VR14 CRT DISPLAY IPB	VR14-IPB-2	J
EKOVR14OP	VR14/VR17 CRT DISPLAY MONITOR USERS MANUAL	EK-OVR14-OP-005	E
EKOVR48TM	VR48 TABLE AND SCOPE ASSEMBLY TECHNICAL MANUAL (LAB DATA)	EK-OVR48-TM-001	C
EKOVR48IP	VR48 TABLE/SCOPE IPB	EK-OVR48-IP-001	I
EKOVS60MP	VS60 MAINTENANCE PLAN (CROSS)	EK-OVS60-MP-001	A
EKOVS60IP	VS60 VECTORING SYSTEM IPB	EK-OVS60-IP-001	I
EKVS01IP	VSV01 GRAPHICS DISPLAY IPB		I
15H193	VT04/VT07 GRAPHIC DISPLAY CONSOLE MAINT MANUAL VOL I	15-H2GB-D	F
EKOUT05IP	VT05 ALPHANUMERIC DISPLAY TERMINAL IPB	VT05-IPB-2	I
EKOUT05MM	VT05 ALPHANUMERIC DISPLAY TERMINAL MAINT MANUAL	EK-VT05-MM-005	H
EKOVT05HR	VT05 ALPHANUMERIC DISPLAY TERMINAL REFERENCE MANUAL	EK-VT05-HR-002	E
EKOVT11TM	VT11 GRAPHIC DISPLAY PROCESSOR MANUAL (LAB DATA)	EK-OVT11-TM-001	F
15H199	VT15 GRAPHIC PROCESSOR MAINT MANUAL VOL I	15-HVT15-B-D	F
EKOVT20OP	VT20 OPERATORS GUIDE & ADDENDA SHEET (TYPESET)	EK-OVT20-OP-001	F
94I450A	VT40 16 BIT COMPUTER IPB IPB	VT40-IPB-2	I
EKOVT48IP	VT48 PROCESSOR IPB	EK-OVT48-IP-001	I
EKOVT50TM	VT50 SYSTEM MANUAL (CROSS PROD	EK-OVT50-TM-002	E
EKOVT50IP	VT50 SERIES COPIER IPB		I
EKOVT5COP	VT50-SERIES COPIER USERS MANUAL (CROSS PRODUCTS)	EK-OVT5C-OP-003	C
EKOVT52IP	VT52 DECScope IPB	EI-OVT52-IP-001	I
EKOVT52MM	VT52 DECScope MAINTENANCE MANNAL (CROSS)	EK-OVT52-MM-001	K

PART NO	TITLE	INDEX CODE	PRICE
EKVT55ETM	VT55-E,F,H,J DECGRAPHIC SCOPE USERS MANUAL	EK-OVT55-TM-001	E
EKOVT61OP	VT61 USERS MANUAL (CROSS)	EK-OVT61-OP-001	F
99H538	VW01 WRITING TABLE MAINT MANUAL VI	00-H4AA-D	E
EK15XVMOP	XVM SYSTEM REFERENCE MANUAL (PDP-15)	EK-15XVM-OP-001	H
EK15XVMMM	XVM SYSTEMS MAINTENANCE MANUAL VOLUME 1 (PDP-15)	EK-15XVM-MM-001	H



Software Documentation

Documentation for the most popular software products is listed in this section. If you require information on replacement software or if your particular product is not listed here, please contact your local office for assistance.

TITLE	PART NUMBER	PRICE
HANDBOOKS		
4K ASSEMBLERS PAL III/MACRO-8	DEC-08-LAS4A-A-D	E
8K BASIC	DEC-08-LBSMA-A-D	F
APL-20 REFERENCE MANUAL	DEC-20-LARMA-A-D	F
BASIC USER'S GUIDE	DEC-20-LBMAA-A-D	F
COBOL REFERENCE MANUAL	DEC-20-LCRMA-A-D	G
COBOL UTILITIES MANUAL	DEC-20-LCUMA-A-D	F
ERROR DETECTION, RECOVERY, & REPORTING	EK-SEDRR-RF-002	F
FOCAL-8	DEC-08-LFL8A-A-D	F
FORTRAN REFERENCE MANUAL	DEC-20-LFRMA-A-D	F
FORTRAN/SABR	DEC-08-LFTNA-A-D	E
INTRODUCTION TO PROGRAMMING	DEC-08-XINPA-A-D	A
MICROCOMPUTER HANDBOOK	EB-06583-76	E
PAL 8 ASSEMBLER	DEC-08-LAS8A-A-D	E
PDP-11 PERIPHERALS HANDBOOK, 1976	EB-05961-76	E
PDP-11 PROGRAMMING FUNDAMENTALS HNDBK	DEC-11-EPGFA-A-D	C
PDP-11 SOFTWARE HANDBOOK	EB-05360-75	C
PDP-11/04,05,10,35,40,45 PROCES HNDBK	EB-05138-76	C
PDP-11/04,34,45,55 PROCESSOR HANDBOOK	EB-A5138-76	C
PDP-11/20/15,R20 PROCESSOR HNDBK,1972	EB-01855-71	C
PDP-11/34 USER'S GUIDE	EB-05710-76	C
PDP-11/70 PROCESSOR HANDBOOK	EB-04588-75	C
PDP-8 FAMILY COMMONLY USED UTILITY	DEC-8I-RZPA-D	D
ROUTINES		
PDP-8 PROGRAMMING MANUAL	DEC-08-EPRGA-A-D	C
PROCESS I/O SOFTWARE HANDBOOK	EB-05435-75	C
SMALL COMPUTER HANDBOOK (8E,8M,8F)	EB-02546-73	C
SMALL COMPUTER HANDBOOK (8I,8L)	EB-A1983-72	C
WRITING FOR THE READER HANDBOOK	DEC-00-XWRDA-A-D	B

REFERENCE CARDS		
COBOL-11 REFERENCE CD	DEC-11-LCRCA-B-D	10 @ C
DECGRAPHIC-11 GT SERIES REFERENCE CD	EH-02784-73	10 @ C
GAMMA-11 F/B REFERENCE CD	DEC-11-MGCSA-B-D	10 @ C
LAB-APPLICATIONS-11 PROGRAM REF CD	DEC-11-ALRCA-C-D	10 @ C
LSI-11/PDP-11/03 PROGRAMMING REF CD	EK-04779-75	10 @ C
MUMPS-11 REFERENCE CDS	DEC-11-MMPCA-D-D	10 @ C
PDP-11 POCKET REFERENCE CD	EH-04786-75	10 @ C
PDP-11 PROGRAMMING REFERENCE CD	EH-S1046-76	10 @ C
PDP-8 POCKET REFERENCE CD	EH-03533-74	10 @ C
RSX-11M POCKET REFERENCE CD	DEC-11-OMPRA-A-D	10 @ C
RT-11 SYSTEM REFERENCE CD	DEC-11-ORRCA-D-D	10 @ C

BASIC/CAPS-11		
BASIC-11 LANGUAGE REFERENCE MANUAL	DEC-11-LIBBA-B-D	F
BASIC/CAPS-11 USER'S MANUAL	DEC-11-LIBCA-A-D	E
GETTING STARTED WITH BASIC/CAPS-11 DOC	DEC-11-OTBIA-B-D	Z

BASIC/PTS		
BASIC/PTS USER'S MANUAL	DEC-11-LPTBA-A-D	E
BASIC/PTS USER'S MANUAL CHANGE NOTICE	DEC-11-LPTBA-A-DN3	Z
GETTING STARTED WITH BASIC/PTS DOC	DEC-11-LBINA-C-D	Z

BASIC/RT-11		
BASIC/RT-11 LANGUAGE REF MAN	DEC-11-LBACA-E-D	F
BASIC/RT-11 RELEASE NOTES	DEC-11-LBRNA-B-D	Z
RT-11 SYSTEM GENERATION MANUAL	DEC-11-ORGMA-A-D	F

BASIC/RT-11 EXTENSIONS		
BASIC-11 V01 EXTENSIONS USER'S GUIDE	DEC-11-LBEPa-A-D	F
BASIC-11 V01 GRAPHICS EXTENSIONS	DEC-11-LBGaA-A-D	F
USER'S GUIDE DOC		

CAPS-8		
CAPS-8 GETTING ON THE AIR PACKAGE	DEC-8E-OCGAA-A-D	Z
CT PROGRAMMING SYSTEM-8	DEC-8E-OCASA-B-D	H

CAPS-11		
CAPS-11 USER'S GUIDE DOC	DEC-11-OTUGA-A-D	F
XXDP USER'S MANUAL	MDEC-11-DZQXA-I-D	F

TITLE	PART NUMBER	PRICE
COBOL-11		
COBOL-11 USER'S GUIDE DOC	DEC-11-LCUGA-B-D	F
COBOL-11 INSTALLATION GUIDE DOC	DEC-11-LCIDA-B-D	Z
COBOL-11 REFERENCE MANUAL	DEC-11-LCOBA-C-D	F
PDP-11 SORT REFERENCE MANUAL	DEC-11-USTMA-B-D	E
CORAL-66		
CORAL-66 INSTALLATION GUIDE	DEC-11-LCIAA-B-D	F
CORAL-66 LANGUAGE REF MAN & USER'S GUIDE DOC	DEC-11-LCRUA-A-D	F
CORAL-66 WITH FPP SUPPORT		
CORAL-66 WITH FPP INSTALLTION	DEC-11-LCDIA-A-D	F
CORAL-66 RELEASE NOTES DOC	DEC-11-LCRNA-A-D	Z
CORAL-66 RELEASE NOTES DOC ADDN	DEC-11-LCRNA-A-DN1	Z
CTS-5000/E (RSTS/E) RPGII		
RPGII LANGUAGE REFERENCE MANUAL	DEC-11-LRPGA-D-D	F
RPGII USER'S GUIDE DOC	DEC-11-OPRGA-B-D	F
SORT REFERENCE MANUAL	DEC-11-USTMA-B-D	F
DECNET-11D		
DECNET-11 USER'S GUIDE & PROGRAMMER'S REFERENCE MANUAL WITH ADDENDUM	DEC-11-OPGRA-A-D	G
RSX-11 DECNET/IAS PROGRAMMER'S GUIDE & REFERENCE MANUAL RELEASE NOTES DOC	DEC-11-OIDRA-A-D	F
DECNET-11M		
DECNET-11 USER'S GUIDE & PROGRAMMER'S REFERENCE MANUAL WITH ADDENDUM	DEC-11-OPGRA-A-D	G
DECNET-11S		
DECNET-11 USER'S GUIDE & PROGRAMMER'S REFERENCE MANUAL	DEC-11-OPGRA-A-D	G
DECNET-11 USER'S GUIDE & PROGRAMMER'S REFERENCE MANUAL ADDENDUM	DEC-11-OPGRA-A-DN2	Z
DECNET/IAS		
RSX-11 DECNET IAS PROGRAMMER'S GUIDE & REFERENCE MANUAL RELEASE NOTES	DEC-11-OIDRA-A-D	F
DECNET-11 USER'S GUIDE & PROGRAMMER'S REFERENCE MANUAL	DEC-11-OPGRA-A-D	G
DECNET-11 USER'S GUIDE & PROGRAMMER'S REFERENCE MANUAL ADDENDUM	DEC-11-OPGRA-A-DN1	Z
DMS-5000		
DMS-5000 USER'S GUIDE	DEC-11-ORDUA-A-D	F
DOS/BATCH		
DOS/BATCH HANDBOOK	DEC-11-ODBHA-A-D	I
DOS/BATCH SYSTEM MANAGER'S GUIDE	DEC-11-OSMGC-B-D	F
FOCAL-GT		
FOCAL-GT/RT MANUAL	DEC-11-GGTMA-B-D	F
FOCAL-11 USER'S MANUAL	DEC-11-LFOCA-F-D	F
FOCAL-11 USER'S MANUAL ADDENDUM	DEC-11-LFOCA-F-DN1	Z
FOCAL/PTS		
FOCAL-11 USER'S MANUAL	DEC-11-LFOCA-F-D	F
FOCAL-11 USER'S MANUAL ADDENDUM	DEC-11-LFOCA-F-DN1	Z
FOCAL/RT-11		
FOCAL-11 USER'S MANUAL	DEC-11-LFOCA-F-D	F
FOCAL-11 USER'S MANUAL ADDENDUM	DEC-11-LFOCA-F-DN1	Z

TITLE	PART NUMBER	PRICE
FORTRAN IV PLUS		
FORTRAN IV PLUS INSTALLATION GUIDE DOC	DEC-11-LFPGB-C-D	F
FORTRAN IV PLUS OTS REFERENCE MANUAL	DEC-11-LFPOA-A-D	F
FORTRAN IV PLUS USER'S GUIDE DOC	DEC-11-LFPUA-B-D	F
FORTRAN IV PLUS USER'S GUIDE DOC ADDEN	DEC-11-LFPUA-B-DN1	Z
PDP-11 FORTRAN LANG REF MAN	DEC-11-LFLRA-C-D	F
FORTRAN RT-11		
PDP-11 FORTRAN LANGUAGE REFERENCE MAN	DEC-11-LFLRA-C-D	F
RT-11 FORTRAN RELEASE NOTES	DEC-11-LFRNA-A-D	Z
RT-11 SYSTEM GENERATION MANUAL	DEC-11-ORGMA-A-D	F
RT-11/RSTS/E FORTRAN IV USER'S GUIDE	DEC-11-LRRUA-A-D	F
VT55 PROGRAMMING MANUAL	AA-4949A-TC	F
FORTRAN/RT-11 EXTENSIONS		
DECGRAPHIC-11 FORTRAN REF MAN	DEC-11-GFRMA-A-D	F
FORTRAN/RT-11 EXTENSIONS MANUAL	DEC-11-LRTEA-C-D	F
PDP-11 FORTRAN LANGUAGE REFERENCE MAN	DEC-11-LFLRA-C-D	F
RT-11 FORTRAN RELEASE NOTES	DEC-11-LFRNA-A-D	Z
RT-11 SYSTEM GENERATION MANUAL	DEC-11-ORGMA-A-D	F
RT-11 SYSTEM GENERATION MANUAL ADDENDUM	DEC-11-ORGMA-A-DN1	Z
FORTRAN/RT-11 GRAPHICS EXTENSIONS	DEC-11-LFGMA-A-D	F
USER'S GUIDE		
RT-11/RSTS/E FORTRAN IV USERS GUIDE	DEC-11-LRRUA-A-D	F
FORTRAN RT-11 & RT-11		
PDP-11 FORTRAN LANGUAGE REFERENCE MAN	DEC-11-LFLRA-C-D	F
RT-11 FORTRAN RELEASE NOTES	DEC-11-LFRNA-A-D	Z
RT-11 SYSTEM GENERATION MANUAL	DEC-11-ORGMA-A-D	F
RT-11 SYSTEM GENERATION MANUAL ADD	DEC-11-ORGMA-A-DN1	Z
RT-11/RSTS/E FORTRAN IV USER'S GUIDE	DEC-11-LRRUA-A-D	F
RT-11 DOCUMENTATION DIRECTORY	DEC-11-ORDDA-A-D	Z
RT-11 SOFTWARE SUPPORT MANUAL	DEC-11-ORPGA-B-D	F
RT-11 SYSTEM MESSAGE MANUAL	DEC-11-ORMEA-A-D	F
RT-11 SYSTEM REFERENCE MANUAL	DEC-11-ORUGA-C-D	I
GAMMA-11 F/B		
GAMMA-11 OPERATOR'S GUIDE DOC	DEC-11-MGOGA-A-D	G
GAMMA-11 SYSTEM REFERENCE MANUAL	DEC-11-MGRMA-A-D	F
IAS		
IAS DOCUMENTATION DIRECTORY DOC	DEC-11-OIDDA-B-D	Z
IAS EDITING UTILITIES REF MAN	DEC-11-OIEUA-A-D	F
IAS EDITING UTILITIES REF MAN ADD	DEC-11-OIEUA-A-DN1	Z
IAS EXECUTIVE REF MAN VOL-1	DEC-11-OIE1A-A-D	F
IAS EXECUTIVE REF MAN VOL-1 ADDENDUM	DEC-11-OIE1A-A-DN1	Z
IAS EXECUTIVE REF MAN VOL-2	DEC-11-OIE2A-A-D	F
IAS EXECUTIVE REF MAN VOL-2 ADDENDUM	DEC-11-OIE2A-A-DN1	Z
IAS SYSTEM GENERATION GUIDE DOC	DEC-11-OISGA-B-D	F
IAS SYSTEM MANAGEMENT GUIDE DOC	DEC-11-OISMA-B-D	G
IAS SYSTEM RELEASE NOTES	DEC-11-OISRA-C-D	Z
IAS TASK BUILDER REFERENCE MANUAL	DEC-11-OITBA-A-D	F
IAS TASK BUILDER REFERENCE MANUAL ADD	DEC-11-OITBA-A-DN1	Z
IAS USER'S GUIDE DOC	DEC-11-OIUGA-B-D	F
IAS/RSX-11 I/O OPERATIONS REF MAN	DEC-11-OIORA-B-D	G
IAS/RSX-11 MACRO-11 REFERENCE MANUAL	DEC-11-OIMRA-B-D	F
IAS/RSX-11 ODT REFERENCE MANUAL	DEC-11-OIODA-A-D	F
IAS/RSX-11D DEVICE HANDLERS REF MAN	DEC-11-OIHRA-B-D	F
IAS/RSX-11D GUIDE TO WRITING A DEVICE	DEC-11-OIDHA-A-D	I
HANDLER TASK DOC		
IAS/RSX-11D GUIDE TO WRITING A DEVICE	DEC-11-OIDHA-A-DN1	Z
HANDLER TASK DOC ADDENDUM		
IAS/RSX-11D GUIDE TO WRITING DEVICE	DEC-11-OIDHA-A-DN2	Z
HADNLER TASK DOC ADDENDUM		
PDP-11 PRESERVATION UTILITY (PRESRV)	DEC-11-UPRMA-B-D	F
USER'S GUIDE		
RSX-11D DIAGNOSTICS REFERENCE MANUAL	DEC-11-OXLDA-B-D	F
RSX-11D DIAGNOSTICS REFERENCE MANUAL	DEC-11-OXLDA-B-DN1	Z
ADDENDUM		
RSX-11D FORTRAN SPECIAL SUBROUTINES	DEC-11-LFSMA-B-D	F
REFERENCE MANUAL		

TITLE	PART NUMBER	PRICE
IAS/RSX BASIC		
BASIC-11 LANGUAGE REFERENCE MANUAL	DEC-11-LIBBB-A-D	F
IAS/RSX BASIC INSTALLATION GUIDE	DEC-11-LIBJA-B-D	F
IAS/RSX BASIC INSTALLATION GUIDE ADD	DEC-11-LIBJA-B-DN1	Z
IAS/RSX BASIC USER'S GUIDE	DEC-11-LIBIA-B-D	F
IAS/RSX-11 FORTRAN IV		
IAS/RSX-11 FRTRN IV INSTALLATION GUIDE	DEC-11-LFIGA-B-D	F
IAS/RSX-11 FRTRN IV USER'S GUIDE DOC	DEC-11-LMFUA-C-D	F
PDP-11 FRTRN LANGUAGE REFERENCE MANUAL	DEC-11-LFLRA-C-D	F
ICCN-11/14		
ICCN-11/14 INDUSTRIAL COMPUTER CONTROL- LER'S NETWORKS PROGRAMMER'S REF MAN	DEC-11-ICPMA-A-D	F
LAB-8/E MASS STORAGE SYSTEM		
SOFTWARE SYSTEM USER'S MANUAL	DEC-8E-ALUMA-B-D	E
LAB-APPLICATIONS-11 (RT-11)		
LAB-APPLICATIONS-11 MODULE MANUAL	DEC-11-ALMMA-A-D	G
LAB-APPLICATIONS-11 PROGRAM MANUAL	DEC-11-ALPMA-A-D	G
LAB-APPLICATIONS-11 RELEASE NOTES	DEC-11-ALRNA-A-D	Z
MUMPS-11		
MUMPS-11 RELEASE NOTES DOC	DEC-11-MMGSA-B-D	F
INTRODUCTION TO MUMPS-11 LANGUAGE DOC	DEC-11-MMLTA-C-D	F
INTRODUCTION TO MUMPS-11 DOC ADDENDUM	DEC-11-MMLTA-C-DN1	Z
MUMPS-11 LANGUAGE REFERENCE MANUAL	DEC-11-MMLMA-D-D	F
MUMPS-11 LANGUAGE REF MAN ADDEN	DEC-11-MMLMA-D-DN1	Z
MUMPS-11 OPERATOR'S GUIDE DOC	DEC-11-MMOPA-E-D	F
PDP-11 PRESERVATION UTILITY USER'S GUIDE (PRESRV) DOC	DEC-11-UPRMA-B-D	F
MUMPS-11 PROGRAMMER'S GUIDE DOC	DEC-11-MMPGA-E-D	F
MUMPS-11 DISK SAVE & COMPRESS DOC	DEC-11-OIRUA-A-D	F
MUX200/RSX		
MUX200/RSX SYSTEM MANAGER'S GUIDE DOC	DEC-11-CXSMA-A-D	F
MUX200/RSX RELEASE NOTES & SAMPLE PROCEDURES DOC	DEC-11-CXRNA-A-D	F
MUX200/RSX USER'S GUIDE DOC	DEC-11-CXUGA-A-D	F
MU BASIC/RT-11		
BASIC-11 LANGUAGE REFERENCE MANUAL	DEC-11-LIBBA-B-D	F
MU BASIC USER'S MANUAL	DEC-11-LIBRA-A-D	E
MU BASIC/RT-11 SYS INSTAL GUIDE	DEC-11-LIBMA-A-D	E
MU BASIC/RT-11 SYS INSTAL GUIDE ADD	DEC-11-LIBMA-A-DN1	Z
EDUCATIONAL CLASSIC		
CLASSIC PRIMER, A SELF TEACHING GUIDE	DEC-08-ECPGA-B-D	F
CLASSIC USER'S REFERENCE GUIDE	DEC-08-ECUGA-B-D	F
CLASSIC INSTALLATION & MAINT GUIDE	DEC-08-ECIMA-B-D	I
OS/8, OS/12		
OS/8 GETTING ON THE AIR PACKAGE	DEC-S8-OSGAB-B-D	Z
OS/8 HANDBOOK VERSION 3C	DEC-S8-OSHBA-A-D	E
OS/8 HANDBOOK ADDENDUM #1	DEC-S8-OSHBA-A-DN1	Z
OS/8 HANDBOOK ADDENDUM #2	DEC-S8-OSHBA-A-DN2	Z
OS/8 HANDBOOK ADDENDUM #3	DEC-S8-OSHBA-A-DN3	Z
OS/8 V3C RELEASE NOTES	DEC-S8-OSRNA-A-D	Z
OS/8 SOFTWARE SUPPORT MANUAL	DEC-S8-OSSMB-A-D	F
OS/8, OS/12 EXTENSION		
OS/8 HANDBOOK	DEC-S8-OSHBA-A-D	E
OS/8 HANDBOOK ADDENDUM	DEC-S8-OSHBA-A-DN1	Z
OS/8 MARK SENSE BATCH USER MANUAL	DEC-S8-OBUGA-A-D	E

TITLE	PART NUMBER	PRICE
OS/8, OS/12 FORTRAN IV		
OS/8 HANDBOOK	DEC-S8-OSHBA-A-D	E
OS/8 HANDBOOK ADDENDUM	DEC-S8-OSHBA-A-DN1	Z
OS/8,OS/12 FORTRAN IV SOFTWARE SUPPORT MANUAL	DEC-S8-LFSSA-A-D	F
OS/8,OS/12 FORTRAN IV PLOTTER ROUTINES		
OS/8 FORTRAN IV V3C PLOTTER ROUTINES	DEC-S8-LPLMA-A-D	E
PEAK-11		
PEAK-11 OPERATOR'S GUIDE	DEC-11-OPOGA-A-D	F
PEAK-11 PROGRAMMER'S MANUAL	DEC-11-OPPGA-A-D	F
PDL/RT-11		
PDL V01 OPERATOR'S GUIDE DOC	DEC-11-OPUGA-D-D	F
PDL V01 PROGRAMMER'S GUIDE	DEC-11-APLMA-B-D	F
PDP8-E EXTENDED		
PDP-8 POCKET REFERENCE CD (2)	EH-03533-74	10 @ C
INTRODUCTION TO PROGRAMMING	DEC-08-XINPA-A-D	A
PDP-8 FAMILY COMMONLY USED UTILITY ROUTINES	DEC-08-RZPA-D	E
4K ASSEMBLERS PAL III/MACRO-8	DEC-08-LAS4A-A-D	E
SELF STARTING BINARY LOADER (PDP8E, 8M,8F ONLY)	DEC-08-XBINA-B-D	E
REMOTE-11 V01		
REMOTE-11 MANUAL	DEC-11-ARMMA-A-D	F
RSTS/E		
BASIC-PLUS LANG MAN	DEC-11-ORBPB-B-D	G
PDP-11 ROLLIN UTILITY PROGRAM DOC	DEC-11-OR0AA-B-D	E
RSTS/E DOC DIRECTORY DOC	DEC-11-ORDAA-B-D	Z
RSTS/E POCKET GUIDE	DEC-11-ORFCA-A-D	W
RSTS/E PRGM MAN	DEC-11-ORPMA-B-D	G
RSTS/E RELEASE NOTES	DEC-11-ORINCA-A-D	Z
RSTS/E SYSGEN MAN	DEC-11-ORGNA-B-D	G
RSTS/E SYS MANAGERS GDE	DEC-11-ORSMD-B-D	F
RSTS/E SYS USER'S GUIDE	DEC-11-ORSUB-A-D	G
RSTS/E TEXT EDITOR MANUAL	DEC-11-UTEMA-A-D	F
RSTS/E RUNOFF USER'S GUIDE	DEC-11-URUNA-B-D	E
RSTS/E F4		
PDP-11 FRTRN LANGUAGE REFERENCE MANUAL	DEC-11-LFLRA-C-D	F
RSTS/E FORTRAN IV UTILITIES MANUAL	DEC-11-LRUMA-A-D	F
RT-11/RSTS/E FORTRAN IV USER'S GUIDE	DEC-11-LRRUA-A-D	F
RSTS/E 2780		
2780 REMOTE COMPUTER SYSTEMS INSTALLATION NOTES DOC	DEC-11-CCDNA-A-D	F
RSTS/E 2780 RCS USER'S GUIDE DOC	DEC-11-ORJEA-A-D	Z
RSX-11D		
RSX-11D BATCH REFERENCE MANUAL	DEC-11-0XBRA-C-D	E
RSX-11D EXECUTIVE REFERENCE MANUAL	DEC-11-0XERA-B-D	E
RSX-11D EXECUTIVE REFERENCE MAN ADD	DEC-11-0XERA-B-DN1	Z
RSX-11D EXECUTIVE REFERENCE MAN ADD	DEC-11-0XERA-B-DN2	Z
PDP-11 FORTRAN LANGUAGE REFERENCE MAN	DEC-11-LFLRA-C-D	F
PDP-11 PRESERVATION UTILITY (PRESRV) USER'S GUIDE	DEC-11-UPRMA-B-D	F
IAS/RSX-11 DISK SAVE & CPRS USR GD	DEC-11-OIRUA-A-D	F
IAS/RSX-11 FORTRAN IV USER'S GUIDE DOC	DEC-11-LMFUA-C-D	F
IAS/RSX-11 I/O OPERATIONS REF MAN	DEC-11-OIORA-B-D	G
IAS/RSX-11 MACRO-11 REFERENCE MANUAL	DEC-11-OIMRA-B-D	F
IAS/RSX-11 ODT REFERENCE MANUAL	DEC-11-OIODA-A-D	F
IAS/RSX-11D DEVICE HANDLERS REF MAN	DEC-11-OIHRA-B-D	F

TITLE	PART - NUMBER	PRICE
IAS/RSX-11D GUIDE TO WRITING A DEVICE HANDLER TASK DOC	DEC-11-OIDHA-A-D	I
IAS/RSX-11D GUIDE TO WRITING A DEVICE HANDLER TASK DOC ADDENDUM	DEC-11-OIDHA-A-DN1	Z
IAS/RSX-11D GUIDE TO WRITING A DEVICE HANDLER TASK DOC ADDENDUM	DEC-11-OIDHA-A-DN2	Z
RSX-11D RELEASE NOTES DOC	DEC-11-oxRNA-E-D	Z
RSX-11D DIAGNOSTICS REFERENCE MANUAL	DEC-11-oxLDA-B-D	F
RSX-11D DIAGNOSTICS REFERENCE MAN DOC	DEC-11-oxLDA-B-DN1	Z
RSX-11D DOCUMENTATION DIRECTORY DOC	DEC-11-oxUGA-D-D	Z
RSX-11D FORTRAN SPECIAL SUBROUTINES REFERENCE MANUAL	DEC-11-LFSMA-B-D	F
RSX-11D SYSTEM MANAGER'S GUIDE DOC	DEC-11-oxSMA-C-D	F
RSX-11D SYSTEM GENERATION REFERENCE MAN	DEC-11-oxDIA-E-D	F
RSX-11D SYSTEM TEST PROCEDURES MANUAL	DEC-11-oxSTA-C-D	E
RSX-11D SYSTEM TEST PROCEDURES MAN ADD	DEC-11-oxSTA-C-DN1	Z
RSX-11D TASK BUILDER REFERENCE MANUAL	DEC-11-oxDLA-D-D	E
RSX-11D TASK BUILDER REFERENCE MAN ADD	DEC-11-oxDLA-D-DN1	Z
RSX-11D USER'S GUIDE DOC	DEC-11-oxDUA-B-D	G
RSX-11D USER'S GUIDE DOC ADDENDUM	DEC-11-oxDUA-B-DN1	Z
RSX-11 UTIL PROCEDURES MAN	DEC-11-oxMDA-A-D	F
RSX-11D UTILITY PROGRAM PROCEDURES DOC	DEC-11-oxUPA-B-D	G
RSX-11D UTILITY PROGRAM PROCEDURES DOC ADDENDUM	DEC-11-oxUPA-B-DN1	Z
RSX-11D 278Ø		
278Ø RELEASE NOTES DOC	DEC-11-CDRNA-A-D	Z
278Ø REMOTE COMPUTER SYSTEMS INSTALLATION NOTES DOC	DEC-11-CCDNA-A-D	F
278Ø REMOTE COMPUTER SYSTEMS OPERATOR'S GUIDE DOC	DEC-11-CRCSA-A-D	F
278Ø REMOTE COMPUTER SYSTEMS OPERATOR'S GUIDE DOC ADDENDUM	DEC-11-CRCSA-A-DN1	Z
278Ø REMOTE COMPUTER SYSTEMS OPERATOR'S GUIDE DOC ADDENDUM	DEC-11-CRCSA-A-DN2	Z
278Ø REMOTE COMPUTER SYSTEMS OPERATOR'S GUIDE DOC ADDENDUM	DEC-11-CRCSA-A-DN3	Z
SAMPLE PROCEDURE FOR RSX-11D 278Ø & RSX-11M 278Ø	DEC-11-OSPRA-A-D	Z
RSX-11D PICTURE BOOK		
RSX-11D PICTURE BOOK USER'S MANUAL	DEC-11-GPDMA-A-D	E
RSX11M		
RSX11M/RSX11S DOC DIRECTORY	DEC-11-OMUGA-C-D	Z
INTRODUCTION TO RSX11M DOC	DEC-11-OMIEA-B-D	F
RSX11M SYS GEN MAN	DEC-11-OMGIA-C-D	G
RSX11M EXECUTIVE REF MAN	DEC-11-OMERA-C-D	F
IAS/RSX11 MACRO-11 REF MAN	DEC-11-OIMRA-B-D	F
RSX11M TASK BUILDER REF MAN	DEC-11-OMTBA-C-D	F
RSX11M I/O DRIVERS REF MAN	DEC-11-OMDRA-C-D	G
IAS/RSX11M I/O OP REF MAN	DEC-11-OIORA-B-D	G
RSX11 UTIL PROC MAN	DEC-11-oxMDA-A-D	G
RSX11M OPERATOR'S PROC MAN	DEC-11-OMOGA-C-D	F
IAS/RSX11 ODT REF MAN	DEC-11-OIODA-A-D	F
RSX11M GDE WRITING I/O DRVR DOC	DEC-11-OMWDA-C-D	F
RSX11M USER MODE DIAGNOSTICS REF MAN	DEC-11-OMUMA-A-D	F
RSX11M ERROR LOGGING REF MAN	DEC-11-OMELA-B-D	F
IAS/RSX11 DISKSAVE & CPRS USER'S GDE	DEC-11-OIRUA-A-D	F
PDP-11 PSVTN UTIL (PRESRV) USER'S GDE	DEC-11-UPRMA-B-D	F
RSX-11M 278Ø		
278Ø REMOTE COMPUTER SYSTEMS INSTALLATION NOTES DOC	DEC-11-CCDNA-A-D	F
278Ø REMOTE COMPUTER SYSTEMS OPERATOR'S GUIDE DOC	DEC-11-CRCSA-A-D	F
278Ø REMOTE COMPUTER SYSTEMS OPERATOR'S GUIDE DOC ADDENDUM	DEC-11-CRCSA-A-DN1	Z
278Ø REMOTE COMPUTER SYSTEMS OPERATOR'S GUIDE DOC ADDENDUM	DEC-11-CRCSA-A-DN2	Z

TITLE	PART NUMBER	PRICE
2780 REMOTE COMPUTER SYSTEMS OPER- ATOR'S GUIDE DOC ADDENDUM	DEC-11-CRCSA-A-DN3	Z
SAMPLE PROCEDURE FOR RSX-11D 2780 & RSX-11M 2780	DEC-11-OSPRA-A-D	Z
RSX-11M/FORTRAN IV GRAPH EXT		
DECGRAPH-11 F REF MAN	DEC-11-GFRMA-A-D	F
FORTTRAN/RT-11 EXTENSIONS MANUAL	DEC-11-LRTEA-C-D	F
VT55 PROGRAMMER'S MANUAL	AA-4949A-TC	F
RSX-11S		
IAS/RSX-11 I/O OPERATIONS REFERENCE MAN	DEC-11-OIORA-B-D	G
IAS/RSX-11 ODT REFERENCE MANUAL	DEC-11-OIODA-A-D	F
RSX-11M EXECUTIVE REFERENCE MANUAL	DEC-11-OMERA-C-D	F
RSX-11M GDE TO WRITING AN I/O DRIVER MANUAL	DEC-11-OMWDA-C-D	F
RSX-11M I/O DRIVERS REFERENCE MANUAL	DEC-11-OMDRA-C-D	G
RSX-11M OPERATOR'S PROCEDURES MANUAL	DEC-11-OMOGA-C-D	F
RSX-11M SYSTEM GENERATION MANUAL	DEC-11-OMGIA-C-D	F
RSX-11M TASK BUILDER REFERENCE MANUAL	DEC-11-OMTBA-C-D	F
RSX-11S SYSTEM GENERATION & INSTAL- LATION GUIDE	DEC-11-OSGIA-B-D	F
RT-11		
RT-11 DOCUMENTATION DIRECTORY DOC	DEC-11-ORDDA-A-D	Z
RT-11 SOFTWARE SUPPORT MANUAL	DEC-11-ORPGA-B-D	F
RT-11 SYSTEM GENERATION MANUAL	DEC-11-ORGMA-A-D	F
RT-11 SYSTEM MESSAGE MANUAL	DEC-11-ORMEA-A-D	F
RT-11 SYSTEM REFERENCE MANUAL	DEC-11-ORUGA-C-D	I
RT-11 SYSTEM RELEASE NOTES	DEC-11-ORNRA-A-D	Z
RT-11/2780		
2780 REMOTE COMPUTER SYSTEMS INSTAL- LATION NOTES	DEC-11-CCDNA-A-D	F
2780 REMOTE COMPUTER SYSTEMS OPER- ATOR'S GUIDE	DEC-11-CRCSA-A-D	F
2780 REMOTE COMPUTER SYSTEMS OPER- ATOR'S GUIDE ADDENDUM	DEC-11-CRCSA-A-DN4	Z
RT-11 SCIENTIFIC SUBROUTINE		
RT-11 SCIENTIFIC SUBROUTINE PKG MAN	DEC-11-ARSMA-A-D	F
SORT-11		
PDP-11 SORT-11 INSTALLATION GUIDE DOC	DEC-11-USIGA-A-D	Z
PDP-11 SORT REFERENCE MANUAL	DEC-11-USTMA-B-D	F
TOPS-20		
REFERENCE MANUAL, HARDWARE ADDENDUM	DEC-10-XSRMA-A-D -DN1	H Z
DEC-SYS-20 MACRO ASSEMBLER REF MANUAL	DEC-10-LMRMA-A-D	F
GETTING STARTED WITH BATCH	DEC-20-OBGSA-A-D	F
DECSYS-20 BATCH OPERATORS GUIDE ADDENDUM	DEC-20-OBOGA-A-D -DN1	F Z
DECSYS-20 BATCH REFERENCE MANUAL ADDENDUM	DEC-20-OBRMA-A-D -DN1	F Z
DECSYS-20 MONITOR CALLS REF MANUAL ADDENDUM	DEC-20-OMRMA-A-D -DN1	F Z
DECSYS-20 MONITOR CALLS USERS GUIDE	DEC-20-OMUGA-A-D	F
DECSYS-20 SYS MANAGERS GUIDE	DEC-20-OSMGA-B-D	F
DECSYS-20 OPERATORS GUIDE	DEC-20-OTPGA-B-D	G
DECSYS-20 USERS GUIDE ADDENDUM	DEC-20-OUGAA-A-D -DN1	G Z
ACCOUNTING SYS SPECIFICATIONS	DEC-20-UASSA-A-D	F
DECSYS-20 EDIT USERS GUIDE	DEC-20-UEUGA-A-D	F
DECSYS-20 LINK REFERENCE MANUAL	DEC-20-ULRMA-A-D	F

TITLE	PART NUMBER	PRICE
DECSYS-20 MAKLIB FUNCTIONAL SPECIF	DEC-20-UMKLA-A-D	F
GETTING STARTED WITH RUNOFF	DEC-20-URGSA-A-D	F
GETTING STARTED WITH DECSYS-20	DEC-20-XGSAA-A-D	F
UN1004/RSX		
UN1004/RSX RELEASE NOTES & SAMPLE PRO-	DEC-11-CXNRA-B-D	F
CEDURES DOC		
UN1004/RSX USER'S GUIDE DOC	DEC-11-CXRGA-B-D	F
WPS-8		
WPS-8 REFERENCE GUIDE	EK-TY8TM-RC-001	G
WPS-8 REFERENCE MANUAL	EK-TY8SR-RM-001	F
WPS-8 TUTORIAL MANUAL	EK-TY8TM-TM-001	F
XVM/RSX		
XVM/RSX SYSTEM MANUAL	DEC-XV-IRSMA-B-D	F



Document Only Kits

For your ordering convenience,
documentation for selected software
products is offered in kit form.

PART NUMBER	Title	PRICE
PDP 8 DOCUMENTATION ONLY KITS		
QF310-GZ	<u>COS-310 V02 Documentation Kit</u> - COS-300/310 System Reference Manual - COS-300/310 System Reference Card - COS-300 Introduction To DIBOL - Software Product Description 5.98.3 - DEC Supplies & Accessory Catalog	*
QF015-GZ	<u>OS/8 V3C Documentation Kit</u> - Software Product Description 4.1.7 - OS/8 Getting On The Air Package - OS/8 Handbook - Addendum To OS/8 Handbook DN1, DN2, DN3 - OS/8 V3C Release Notes - OS/8 V3C Software Support Manual	*
QF207-GZ	<u>PDP-8/A Starter Kit</u> - Introduction To Programming - OS/8 Handbook With Addendum PDP-8 Pocket Reference Card	*
QF201-GZ	<u>PDP-8 Basic Books</u> - 4K Assemblers PAL III/MACRO-8 - PAL-8 Assembler - 8K Basic - FOCAL-8 Manual - FORTRAN/SABR	*
QF205-GZ	<u>PDP-8E Introductory Documentation Kit</u> - Introduction To Programming - Self Starting Binary Loader - PDP-8 Family Commonly Used Utility Routines - Small Computer Handbook (8E, 8F, 8M) - PDP-8 Pocket Reference Card	*
QF204-GZ	<u>PDP-8 Introductory Documentation Kit</u> - 4K Assemblers PAL III/MACRO-8 - Introduction To Programming - PDP-8 Family Commonly Used Utility Routines - Small Computer Handbook (8I, 8L)	*
QS100-GZ	<u>Programming Documentation Kit</u> - PDP-8 Programming - PDP-11 Programming Fundamentals	*
QF202-GZ	<u>Small Computer Handbook And Reference Cards For PDP-8E, F & M</u> - Small Computer Handbook (8E, 8F, 8M) - PDP-8 Pocket Reference Card	*
QF203-GZ	<u>Small Computer Handbook And Reference Cards For PDP-8I & 8L</u> - Small Computer Handbook (8I, 8L) - PDP-8 Pocket Reference Card	*
PDP 11 DOCUMENTATION ONLY KITS		
QJ910-GZ	<u>BASIC CAPS-11 Documentation Kit</u> - BASIC-11 Language Reference Manual - BASIC/CAPS-11 User's Manual - Getting Started With BASIC/CAPS-11 - Software Product Description 11.5.1	*
QJ180-GZ	<u>CAPS-11 V1-2 Documentation Kit</u> - CAPS-11 User's Guide - Software Product Description 11.1.1 - CAPS-11 System Installation Notes - XXDP Users Manual	*
QP010-GZ	<u>COBOL-11 V02 Documentation Kit</u> - COBOL-11 Installation Guide - COBOL-11 Language Reference Manual - COBOL-11 Reference Card - COBOL-11 User's Guide - PDP-11 Sort reference Manual - Software Product Description 12.40.	*
QP500-GZ	<u>CTS-500/E V02 Documentation</u> DMS-500 User's Guide - Software Product Description 13.6.0 - Software Product Description 13.5.0 - RSTS-11 Special Interest Group Form - RSTS/E V06A-02 Documentation Kit	*
QP680-GZ	<u>DECNET-11D V1.1 Documentation Kit</u> - DECNET-11 User's Guide And Programmer's Reference Manual With Addendum - RSX-11D DECNET-11 Release Notes - Software Product Description 10.70.2	*
QJ681-GZ	<u>DECNET-11M V01.1 Documentation Kit</u> - DECNET-11 User's Guide And Programmer's Reference Manual With Addendum - DECNET User Letter - RSX-11M/S DECNET Release Notes - Software Product Description 10.75.3	*
QJ691-GZ	<u>DECNET-11S V01.1 Documentation Kit</u> - DECNET-11 User Guide and Programmer's Reference Manual With Addendum - DECNET User Letter - RSX-11M/S DECNET Release Notes - Software Product Description 10.74.3	*

PART NUMBER	Title	PRICE
QJ928-GZ	<u>Everything You Need To Know About RT-11/BASIC/FORTRAN</u> - BASIC/RT-11 Language Reference Manual - BASIC/RT-11 Release Notes - PDP-11	
QR680-GZ	<u>DECNET/IAS V1.1 DOCUMENTATION KIT - RSX-11</u> DECNET IAS Programmer's Guide & Reference Manual Release Notes - User's Guide & Programmer's Reference Manual with Addendum - FORTRAN Language Reference Manual - RT-11 FORTRAN Release Notes - RT-11/RSTS/E FORTRAN IV Users Guide - Fortran/RT-11 Extensions Manual - RT-11 Documentation Directory - RT-11 System Generation Manual With Addendum - RT-11 System Message Manual - RT-11 System Release Notes - RT-11 Software Support Manual With Addendum - RT-11 System Reference Card - RT-11 System Reference Manual With Two Addendum	*
QP100-GZ	<u>FORTTRAN IV Plus V02-05 Documentation Kit - PDP-11</u> FORTRAN Language Reference Manual - FORTRAN IV-Plus Installation Guide - FORTRAN IV Plus OTS Reference Manual - FORTRAN IV Plus User's Guide With Addendum - Software Product Description 14.50.5	*
QJ720-GZ	<u>GAMMA-11 V7A Documentation Kit - GAMMA-11 F/B</u> Reference Card - GAMMA-11 System Reference Manual With Two Addendums - GAMMA-11 User Letter - PDP-11 Rollin Utility Program - Software Product Description 15.5.0	*
QJ240-GZ	<u>IAS/RSX Basic V02 Documentation Kit - Basic-11</u> Language Reference Manual - IAS/RSX Basic User's Guide - IAS/RSX Basic Installation Guide with Addendum - Software Product Description 14.67.2	*
QP230-GZ	<u>IAS/RSX-11 FORTRAN IV VOIC Documentation Kit -</u> Software Product Binder - IAS/RSX-11 FORTRAN IV Installation Guide - PDP-11 FORTRAN Language Reference Manual - IAS/RSX-11 FORTRAN IV User's Guide - Software Product Description 14.63.1 PDProgramming Card	*
QR300-GZ	<u>IAS V1.1 Documentation - DEC Software Product User</u> Survey - Software Product Binder - RSX-11D FORTRAN Special Subroutines Reference Manual - IAS Documentation Directory - IAS/RSX-11D Guide To Writing A Device Handler Task With Addendum - IAS Executive Reference Manual VOL-I with Addendum - IAS Executive Reference Manual VOL-II with Addend - IAS Editing Utilities Reference Manual With Addendum - IAS/RSX-11D Device Handlers Reference Manual With Addendum - IAS/RSX-11 MACRO-11 Reference Manual - IAS/RSX-11 SX-11 I/O Operations Reference Manual - IAS/RSX-11 DISKSAVE & CPRS USRGD - IAS System Generation Guide - IAS System Management Guide - IAS Task Builder Reference Manual With Addendum - IAS User's Guide - RSX-11D Diagnostic Reference Manual - DECUS Special Interest Group Form - PDP-11 Preservation Utility (PRESRV) User's Guide - Software Product Description 14.65.2 - IAS Divider Set (One Package) - IAS Spine Set (One Package) - PDP-11 Programming Card - IAS V01.1 Software Dispatch Kit	*
QJ940-GZ	<u>Laboratory-Applications-11 (RT U2B) Documentation</u> Kit - Laboratory Applications-11 Module Manual - Laboratory Applications-11 Program Manual - Laboratory Applications-11 Program Card - Laboratory Applications-11 Release Notes V03 - Software Product Description 15.35.3	*
QJ921-GZ	<u>MU BASIC/RT-11 V01 Documentation Kit - BASIC 11</u> Language Reference Manual - MU BASIC/RT-11 System Installation Guide With Addendum - MU Basic User's Manual - Software Product Description 12.20.1	*


PART NUMBER	Title	PRICE
QJ820-GZ	<u>MUMPS-11 V4 Documentation Kit</u> - Getting Started With MUMPS-11 - MUMPS-11 Language Reference Manual - Introduction To MUMPS-11 Language - MUMPS-11 Operator's Guide - MUMPS-11 Programmer's Reference Card - MUMPS-11 Programmer's Guide - PDP-11 Preservation Utility (PRESRV) User's Guide - Software Product Description 15.1.3	*
QJ104-GZ	<u>PDP-11/04/05/10/35/40/45 Programming Documentation Kit</u> - PDP-11/04/05/10/35/40/45 Processor Handbook 1975-76 - PDP-11 Programming Card	*
QJ103-GZ	<u>PDP-11/70 Programming Documentation Kit</u> - PDP-11/70 Processor Handbook - PDP-11 Programming Card	*
QJ101-GZ	<u>PDP-11 System Documentation Kit</u> - FPMP-11 - PDP-11 Papertape System (Checkout Pkg.) - PDP-11 Papertape Software Handbook - PDP-11 /04/05/10/35/40/45 Processor Handbook 1975-76 - PDP-11 Programming Card	*
QS100-GZ	<u>Programming Documentation Kit</u> - PDP-8 Programming - PDP-11 Programming Fundamentals	*
QJ400-GZ	<u>RSTS-11 Comprehensive Documentation Kit</u> - Basic-Plus Language Manual - PDP-11 Rollin Utility Program - RSTS-11 System Manager's Guide - RSTS-11 System User's Guide - Software Product Description 13.2.1	*
QR435-GZ	<u>RSTS/E FORTRAN IV V01C Documentation Kit</u> - PDP-11 FORTRAN Language Reference Manual - RT-11/RSTS/E FORTRAN IV Users Guide - RSTS/E FORTRAN IV Utilities Manual - RSTS/E Sysgen Manual - Software Product Description 12.41.3	*
QR430-GZ	<u>RSTS/E V6B Documentation</u> - BASIC-Plus Language Manual - RSTS/E V6B Cover Letter - RSTS/E DOC Directory - RSTS/E Pocket Guide - RSTS/E Sysgen Manual - PDP-11 Rollin Utility Program - RSTS/E Programming Manual - RSTS/E System Managers Guide - RSTS/E System Users Guide - RSTS/E Runoff User's Guide - RSTS/E Text Editor Manual - Software Product Description 13.1.7 - RSTS-ecial Interest Group Form - RSTS/E V6B Dispatch Kit	*
QJ580-GZ	<u>RSX11D V6.2 Documentation</u> - DEC Software Product User Survey - Software Product Binder - PDP-11 FORTRAN Language Reference Manual - RSX-11D FORTRAN Special Subroutines Reference Manual - IAS/RSX-11 FORTRAN IV User's Guide - IAS/RSX-11D Guide To Writing A Device Handler Task With Addendum - IAS/RSX-11D Device Handlers Reference Manual With Addendum - IAS/RSX-11 MACRO-11 Reference Manual - IAS/RSX-11 ODT Reference Manual - IAS/RSX-11 I/O Operations Reference Manual - IAS/RSX11 DISKSAVE & CPRS USRGD - RSX-11D BATCH Reference ManuSX-11D System Generation Reference Manual - RSX-11D Task Builder Reference Manual - RSX-11D User's Guide - RSX-11D Executive Reference Manual - RSX-11D Executive Reference Manual Addendum - RSX-11D Diagnostic Reference Manual - RSX-11 Utility Procedures Manual - RSX-11D System Release Notes - DECUS Special Interest Group Form - RSX-11D System Manager's Guide - RSX-cumentation Directory - RSX-11D Utility Program Procedures Manual - RSX-11D Utility Program Procedures Manual Addendum - PDP-11 Preservation Utility (PRESRV) User's Guide - Software Product Description 14.55.3 - RSX- 11D Divider Set (17) - RSX-11D Spine Set (5) - PDP-11 Programming Card - RSX-11D System Test Procedures Manual	*

PART NUMBER

Title

PRICE

QJ628-GZ	<u>RSX11M V3 Documentation</u> - RSX-11M Divider Set (18) - Software Product Binder - IAS/RSX-11 MACRO-11 Reference Manual - IAS/RSX-11 ODT Reference Manual - IAS/RSX-11 I/O Operations Reference Manual - IAS/RSX11 DISKSAVE & CPRS USRGD - RSX-11M I/O Drivers Reference Manual RSX-11M Error Logging Reference Manual - RSX-11M Executive Reference Manual - RSX-11M System Generation Manual - Introduction To RSX-11M Executive - RSX-11M Operator's Procedures Manual - RSX-11M Pocket Reference Card - RSX-11M Task Builder Reference Manual - RSX-11M/ RSX-11S Documentation Directory - RSX11M User Mode Diagnostic Reference Manual - RSX-11M Guide To Writing An I/O Driver - RSX-11 Utility Procedures Manual - DECUS Special Interest Group Form - PDP-11 Preservation Utility (PRESRV) - User's Guide - Software Product Description 14.35.5 - Software Dispatch Feb. 1977 - RSX-11M/RSX-11S Release Notes	*
QJ642-GZ	<u>RSX11S V02 BL17 Documentation</u> - IAS/RSX-11 ODT Reference Manual - IAS/RSX-11 I/O Operations Reference Manual RSX-11M I/O Drivers Reference Manual - RSX-11M Executive Reference Manual - RSX-11M System Generation Manual - RSX-11M Operats Procedures Manual - RSX-11M/ RSX-11S Release Notes - RM Task Builder Reference Manual - RSX-11M Guide To Writing ADriver - RSX-11S SYSGEN & INSTL Installation Guide - Software Product Description 9.21.3	*
QJ925-GZ	<u>RT11 FORTRAN IV VIC Documentation Kit</u> - PDP-11 FORTRAN Language Reference Manual - RT-11 FORTRAN Release Notes - RT-11/RSTS/E FORTRAN IV Users Guide - RT-11 System Generation Manual With Addendum - Software Product Description 12.10.5	*
QJ003-GZ	<u>RT-11 V02C Documentation Kit</u> - RT-11 Documentation Directory - RT-11 System Generation Manual With Addendum - RT-11 System Message Manual - RT-11 System Release Notes - RT-11 Software Support Manual With Addendum - RT-11 System Reference Card - RT-11 System Reference Manual With Two Addendum - Software Product Description 12.1.6	*
QP600-GZ	<u>SORT-11 V01 Documentation Kit</u> - PDP-11 SORT Installation Guide - PDP-11 SORT Reference Manual - Software Product Descrn 12.7.0	*
PDP 15 DOCUMENT ONLY KITS		
QM070-GZ	<u>XVM/RSX VIB Documentation Kit</u> - XVM/RSX System Manual with Addendum - Software Product Description 19.2.2	*
QM060-GZ	<u>XVM/DOS V1A DOCUMENTATION KIT</u> - VPI5A Graphics Software Manual - VT15 Graphics Software Manual - Fortran IV Operating Environment Manual - Focal Language Manual - Macro Assembler Language Manual- Mac11 Assembler Language Manual - Boss User's Manual - User's Guide & Master Index - Keyboard Command Guide - User's Manual - System Manual - System Installation Guide with Addendum - Correction Notice - Chain Execute Utility Manual - DDT Utility Manual - EDIT/EDITVP/EDITVP Utility Manual - Linking Loader Utility Manual - MTDUMP Utility Manual - PIP Utility Manual - PATCH Utility Manual - SRCCOM Utility Manual - SGEN Utility Manual - STRAN Utility Manual - UPDATE Utility Manual - UNICHANNEL Software Manual - Software Product Descripton 18.2.1	*



Source Listings on Microfiche

Source listing kits are available to customers who have purchased the corresponding binary kit. A signed source license agreement is required.

PART NUMBER	Title	Price
-------------	-------	-------

PDP8 MICROFICHE SOURCE LISTINGS

Source listing kits are available to customers who have purchased the corresponding binary kit. A signed source license agreement is required.

QFE20-FR	Edusystem 20	*
QFE25-FR	Edusystem 25	*
QF006-FR	OS/8 Extension	*
QF008-FR	OS/8 FORTRAN IV	*
QF014-FR	OS/8 FORTRAN IV Plotter Routines	*
QF018-FR	OS/8 O.S. And Extension	*
QF015-FR	OS/8 V3	*

PDP 11 MICROFICHE SOURCE LISTINGS

QJ830-FR	BASIC Extension/RT-11	*
QJ920-FR	BASIC/RT-11	*
QJ180-FR	CAPS-11	*
QJD62-FR	COMTEX HASP	*
QP680-FR	DECNET-11D	*
QJ680-FR	DECNET-11M	*
QJ690-FR	DECNET-11S	*
QR680-FR	DECNET-IAS VI	*
QJ037-FR	DOS/BATCH FORTRAN	*
QJ271-FR	DOS/BATCH Monitor	*
QJ006-FR	FOCAL/PTS	*
QJ922-FR	FOCAL RT-11	*
QJ925-FR	FORTTRAN IV/RT-11 VOIC	*
QJ980-FR	FORTTRAN/RT-11 Extension	*
QJ721-FR	GAMMA-11 F/B V2	*
QJ940-FR	Lab Applications-11	*
QJ936-FR	LV11	*
QJ921-FR	MU BASIC/RT-11	*
QJ070-FR	MUX 200/RSX	*
QP101-FR	OTS FORTRAN IV Plus	*
QJ191-FR	PDL/RT-11	*
QJ630-FR	Power Demand Control	*
QJ635-FR	Power Management/301	*
QPD10-FR	RSTS/E 2780 (CTS)	*
QR432-FR	RSTS/E Monitor	*

PART NUMBER	Title	Price
QR433-FR	RSTS/E RTS	*
QR430-FR	RSTS/E V6B	*
QPD70-FR	RSX11D/2780	*
QJ585-FR	RSX11D Executive I/O	*
QJ584-FR	RSX11D FORTRAN Compiler	*
QJ583-FR	RSX11D Utility	*
QJ580-FR	RSX11D V6B	*
QJD68-FR	RSX11M/2780	*
QJ641-FR	RSX11M Graphics Extension	*
QJ639-FR	RSX11M V3	*
QJ628-FR	RSX11M V3 Executive I/O	*
QJ638-FR	RSX11M V3 Utility	*
QJD63-FR	RT-11/2780	*
QJ003-FR	RT-11 V02C	*
QJ170-FR	UN1004/RSX	*



Diagnostic Kits

This section contains all available diagnostic kits for the PDP-8, -11, -12, -14 and -15. The kits are listed first by computer family and then by device. Diagnostics contain a code in the last two digits. These codes are as follows:

PB	Papertape Only
RA	Document/Linctape
RB	Document/Papertape
RC	Document/DECtape
RD	9-Track MAGtape
RE	Document/DECpack
RF	7-Track MAGtape
RN	Cassette
RY	Document/Floppy Disk
RZ	Document Only

TITLE

PART NUMBER

PRICE

PDP-8

AA-50 DOC/PT KIT	ZF102-RB	H
AD01-A DOC/PT KIT	ZF104-RB	H
AD8A DOC/PT KIT	ZF216-RB	H
AD8E,AM8E DOC/PT KIT	ZF103-RB	H
AFC-8 DOC/PT KIT	ZF106-RB	H
BM08 DOC/PT KIT	ZF112-RB	L
BM8/L DOC/PT KIT	ZF111-RB	M
BM812-I DOC/PT KIT	ZF202-RB	H
CDP8 DOC/PT KIT	ZF213-RB	H
CL8 BASIC #1 DOC/PT KIT	ZF008-RB	O
CL8 BASIC #1 DOC ONLY KIT	ZF008-RZ	N
CL8 BASIC #1 DOC/PT KIT	ZF008-RB	O
CL8 BASIC #1 DOC/FLP KIT	ZF008-RY	N
CL8 BASIC #1 PT ONLY KIT	ZF008-PB	N
CL8 BASIC #2 DOC/PT KIT	ZF009-RB	M
CL8 BASIC #2 DOC ONLY KIT	ZF009-RZ	K
CL8 BASIC #2 PT ONLY KIT	ZF009-PB	K
CM8-E DOC/PT KIT	ZF113-RB	L
CM8-F DOC/PT KIT	ZF114-RB	K
CM8I DOC/PT KIT	ZF115-RB	L
COS-300 DOC/RK05 KIT	ZF214-RE	N
CR01C DOC/PT KIT	ZF117-RB	K
CR03,CR8I DOC/PT KIT	ZF118-RB	L
CR8-E/CR8-F DOC/PT KIT	ZF116-RB	K
DB8-E DOC/PT KIT	ZF120-RB	H
DC02-F DOC/PT KIT	ZF124-RB	K
DF32D (PDP-8I) DOC/PT KIT	ZF129-RB	L
DH8E DOC/PT KIT	ZF230-RB	L
DK8-E DOC/PT KIT	ZF131-RB	H
DKC8-AA 1K,2K,3K, OPTION 1 DOC/PT KIT	ZF207-RB	K
DKC8-AA 4K OPTION #1 DOC/PT KIT	ZF208-RB	H
DP8-EA/EB DOC/PT KIT	ZF135-RB	H
DR8-EA (PDP-8E) DOC/ DOC/PT KIT	ZF136-RB	H
DR8-EA DOC/PT KIT	ZF137-RB	H
DR8-ED DOC/PT KIT	ZF223-RB	H
FPP-8A DOC/PT KIT	ZF226-RB	K
ICS-8 DOC/PT KIT	ZF221-RB	H
KE-8E DOC/PT KIT	ZF139-RB	L
KG8-EA DOC/PT KIT	ZF141-RB	H
KL8-A DOC/PT KIT	ZF225-RB	H
KL8-E DOC/PT KIT	ZF142-RB	J
KL8-F DOC/PT KIT	ZF143-RB	H
KL8-JA DOC/PT KIT	ZF144-RB	L
KL8-M DOC/PT KIT	ZF145-RB	K
KM8-A 1K,2K,3K OPTION #2 DOC/PT KIT	ZF210-RB	K
KM8-A 4K OPTION #2 DOC/PT KIT	ZF209-RB	L
KM8-E DOC/PT KIT	ZF146-RB	L
KP8-E DOC/PT KIT	ZF147-RB	H
LA180 DOC/PT KIT	ZF224-RB	H
LA36 DOC/PT KIT	ZF215-RB	H
LC8-E DOC/PT KIT	ZF152-RB	H
LE8E,LE8/LP08 DOC/PT KIT	ZF153-RB	H
LP05 DOC/PT KIT	ZF201-RB	H
LP08/F DOC/PT KIT	ZF155-RB	H
LPC8 DOC/PT KIT	ZF154-RB	H
LPD-8 DOC/PT KIT	ZF198-RB	H
LS8E DOC/PT KIT	ZF156-RB	H
LT08,PT08C DOC/PT KIT	ZF157-RB	K
LV12/LV8 DOC/PT KIT	ZF212-RB	H
MC8-L DOC/PT KIT	ZF158-RB	L
MI8-E DOC/PT KIT	ZF159-RB	H
MM8-E 4K DOC/PT KIT	ZF160-RB	H
MM8I,MC8S,MD8S,MC8I,183/184 DOC/PT KIT	ZF161-RB	L
MP8E DOC/PT KIT	ZF130-RB	H
MR8-A ROM DOC/PT KIT	ZF211-RB	J
MR8-E DOC/PT KIT	ZF165-RB	K
MR8-FB 1K DOC/PT KIT	ZF196-RB	J
MR8-SL, (MR8F) DOC/PT KIT	ZF195-RB	J
MR8F-FB 2K DOC/PT KIT	ZF197-RB	J
PA60A/PA63/PA67A/PA68F DOC/PT KIT	ZF166-RB	H
PC01,PC8I,PC8L DOC/PT KIT	ZF168-RB	H
PC02,PR8I,PR8L DOC/PT KIT	ZF169-RB	K

TITLE	PART NUMBER	PRICE
PC03,PP8I PP8L DOC/PT KIT	ZF170-RB	K
PC8-E,PP8-E DOC/PT KIT	ZF171-RB	H
PDP-8 BASIC KIT	ZF001-RB	O
PDP-8 SYSTEM EXERCISER (DEC/X8) FLP KIT	ZF229-RY	P
PDP-8/A 4K BASIC DOC/PT KIT	ZF006-RB	L
PDP-8/A RX01 BASIC DOC ONLY KIT	ZF010-RZ	V
PDP-8/A RX01 BASIC DOC/FLP KIT	ZF010-RY	N
PDP-8/A RX01 BASIC PT ONLY KIT	ZF010-PB	N
PDP-8/A RX01 BASIC DOC/PT KIT	ZF010-RB	O
PDP-8A 1K,2K,3K BASIC DOC/PT KIT	ZF007-RB	L
PDP-8A RX01 EXTERNAL OPTIONS DOC ONLY KIT	ZF012-RZ	V
PDP-8A RX01 EXTERNAL OPTIONS DOC/FLP KIT	ZF012-RY	O
PDP-8A RX01 EXTERNAL OPTIONS PT ONLY KIT	ZF012-PB	N
PDP-8A RX01 EXTERNAL OPTIONS DOC ONLY KIT	ZF012-RZ	V
PDP-8E BASIC DOC/PT KIT	ZF002-RB	V
PDP-8I BASIC DOC/PT KIT	ZF003-RB	O
PDP-8L BASIC DOC/PT KIT	ZF004-RB	O
PDP-8S BASIC DOC/PT KIT	ZF005-RB	O
PDP8 SYSTEM EXERCISER (DEC/X8) DOC/PT KIT	ZF229-RB	P
PDP8 SYSTEM EXERCISER (DEC/X8) FLP KIT	ZF229-RY	P
PDP8 SYSTEM EXERCISER (DEC/X8) DOC ONLY KIT	ZF229-RZ	P
PDP8 SYSTEM EXERCISER (DEC/X8) DT KIT	ZF229-RC	P
PDP8 SYSTEM EXERCISER (DEC/X8) LT KIT	ZK229-RA	P
PDP8 SYSTEM EXERCISER (DEC/X8) DOC/PT KIT	ZF229-RB	P
PDP8 SYSTEM EXERCISER (DEC/X8) DOC/DT KIT	ZF229-RC	P
PTW/8E,EE,EF,EH, & EJ DOC/PT KIT	ZF217-RB	H
RF08 DOC/PT KIT	ZF175-RB	K
RK8 DOC/PT KIT	ZF176-RB	L
RK8-E DOC/PT KIT	ZF177-RB	L
RT01/RT02 DOC/PT KIT	ZF179-RB	H
RX01 INTERNAL OPTIONS DOC/FLOPPY KIT	ZF011-RY	O
RX01 INTERNAL OPTIONS DOC ONLY KIT	ZF011-RZ	O
RX01 INTERNAL OPTIONS PT ONLY KIT	ZF011-PB	O
RX01 INTERNAL OPTIONS DOC ONLY KIT	ZF011-RZ	O
RX01 OPTION #3 LOW VOL OPTIONS & DOC/FLP KIT	ZF013-RY	M
RX01 OPTION #3 LOW VOL OPTIONS & PT ONLY KIT	ZF013-PB	I
RX01 OPTION #3 LOW VOL OPTIONS & DOC ONLY KIT	ZF013-RZ	L
RX8/RX01 DOC/PT KIT	ZF220-RB	K
TA8EA DOC/PT KIT	ZF180-RB	N
TC01/TC08 DOC/PT KIT	ZF181-RB	L
TC58,TU20 DOC/PT KIT	ZF182-RB	M
TD8E DOC/PT KIT	ZF183-RB	L
TM8-E/TS03 DOC/PT KIT	ZF222-RB	M
TM8E DOC/PT KIT	ZF184-RB	M
UDC-8 DOC/PT KIT	ZF187-RB	K
VC8-E DOC/PT KIT	ZF189-RB	H
VK8 DOC/PT KIT	ZF227-RB	H
VT05 DOC/PT KIT	ZF192-RB	H
VT50 DOC/PT KIT	ZF218-RB	K
VT61 PDP-8 DIAG DOC/PT KIT	ZF228-RB	I
VT8-E DOC/PT KIT	ZF193-RB	K
XY8-E DOC/PT KIT	ZF194-RB	H

PDP-11

11-45/55/70 FP11C PT ONLY KIT	ZR112-PB	I
11-45/55/70 FP11C DOC ONLY KIT	ZR112-RZ	I
11-45/55/70 FP11C DOC/PT KIT	ZR112-RB	K
11/04 BASIC DOC/PT KIT	ZJ009-RB	M
11/04 BASIC DOC ONLY KIT	ZJ009-RZ	L
11/04 BASIC PT ONLY KIT	ZJ009-PB	L

TITLE	PART NUMBER	PRICE
11/05,15 MIN BASIC OEM DOC/PT KIT	ZJ201-RB	M
11/05,15 MIN BASIC OEM DOC ONLY KIT	ZJ201-RZ	L
11/05,15 MIN BASIC OEM PT ONLY KIT	ZJ201-PB	L
11/05,15 MIN SYS OEM DOC/PT KIT	ZJ199-RB	O
11/05,15 MIN SYS OEM DOC ONLY KIT	ZJ199-RZ	V
11/05,15 MIN SYS OEM PT ONLY KIT	ZJ199-PB	N
11/34 BASIC DOC ONLY KIT	ZJ010-RZ	M
11/34 BASIC DOC/PT KIT	ZJ010-RB	V
11/34 BASIC PT ONLY KIT	ZJ010-PB	M
11/35 MIN BASIC OEM PT ONLY KIT	ZJ202-PB	M
11/35 MIN BASIC OEM DOC/PT KIT	ZJ202-RB	N
11/35 MIN BASIC OEM DOC ONLY KIT	ZJ202-RZ	M
11/35 MIN SYS OEM DOC/PT KIT	ZJ200-RB	O
11/35 MIN SYS OEM DOC ONLY KIT	ZJ200-RZ	V
11/35 MIN SYS OEM PT ONLY KIT	ZJ200-PB	V
11/W03 DOC ONLY KIT	ZJV02-RZ	L
11/W03 DOC/PT KIT	ZJV02-RB	M
11/W03 PT ONLY KIT	ZJV02-PB	K
AA11 DOC ONLY KIT	ZJ101-RZ	J
AA11 DOC/PT KIT	ZJ101-RB	K
AA11 PT ONLY KIT	ZJ101-PB	H
AA11K DOC/PT KIT	ZJ230-RB	H
ACT-11 RKDP DOC/RK05 KIT	ZJ220-RE	O
AD01 DOC/PT KIT	ZJ103-RB	H
AD02/AD11 DOC/PT KIT	ZJ104-RB	H
AD11K DOC/PT KIT	ZJ229-RB	H
AD11K MCRF ONLY KIT	ZJ229-FR	F
ADF11 DOC ONLY KIT	ZJ102-RZ	J
ADF11 DOC/PT KIT	ZJ102-RB	K
ADF11 PT ONLY KIT	ZJ102-PB	H
AFC11 DOC/PT KIT	ZJ105-RB	H
AR11 DOC ONLY KIT	ZJ181-RZ	J
AR11 DOC/PT KIT	ZJ181-RB	K
AR11 PT ONLY KIT	ZJ181-PB	I
BASIC 11/05 DOC ONLY KIT	ZJ001-RZ	O
BASIC 11/05 DOC/PT KIT	ZJ001-RB	P
BASIC 11/05 PT ONLY KIT	ZJ001-PB	V
BASIC 11/10 DOC ONLY KIT	ZJ002-RZ	O
BASIC 11/10 DOC/PT KIT	ZJ002-RB	Q
BASIC 11/10 PT ONLY KIT	ZJ002-PB	P
BASIC 11/15 OEM DOC/PT KIT	ZJ004-RB	P
BASIC 11/15 OEM PT ONLY KIT	ZJ004-PB	V
BASIC 11/15 OEM DOC ONLY KIT	ZJ004-RZ	O
BASIC 11/20 DOC/PT KIT	ZJ005-RB	Q
BASIC 11/20 DOC ONLY KIT	ZJ005-RZ	O
BASIC 11/20 OEM DOC/PT KIT	ZJ006-RB	P
BASIC 11/20 OEM PT ONLY KIT	ZJ006-PB	V
BASIC 11/20 OEM DOC ONLY KIT	ZJ006-RZ	O
BASIC 11/20 PT ONLY KIT	ZJ005-PB	P
BASIC 11/35 DOC/PT KIT	ZJ007-RB	P
BASIC 11/35 DOC ONLY KIT	ZJ007-RZ	O
BASIC 11/35 PT ONLY KIT	ZJ007-PB	V
BASIC 11/40 DOC/PT KIT	ZP001-RB	P
BASIC 11/40 DOC ONLY KIT	ZP001-RZ	O
BASIC 11/40 PT ONLY KIT	ZP001-PB	V
BASIC 11/45 DOC/PT KIT	ZR001-RB	P
BASIC 11/45 DOC ONLY KIT	ZR001-RZ	O
BASIC 11/45 PT ONLY KIT	ZR001-PB	O
BB11 DOC/PT KIT	ZJ177-RB	H
BM792YA,B,C,D,E,F,H,K DOC/PT KIT	ZJ170-RB	J
BM792YA,B,C,D,E,F,H,K DOC ONLY KIT	ZJ170-RZ	I
BM792YA,B,C,D,E,F,H,K PT ONLY KIT	ZJ170-PB	E
BM873 DOC/PT KIT	ZJ106-RB	H
CB11 DOC ONLY KIT	ZJ107-RZ	J
CB11 DOC/PT KIT	ZJ107-RB	K
CB11 PT ONLY KIT	ZJ107-PB	H
CD11 DOC ONLY KIT	ZJ108-RZ	F
CD11 DOC/PT KIT	ZJ108-RB	K
CD11 PT ONLY KIT	ZJ108-PB	J
CD20 DOC/CD KIT	ZJ208-RB	H
CM11 DOC ONLY KIT	ZJ109-RZ	F
CM11 DOC/PT KIT	ZJ109-RB	K
CM11 PT ONLY KIT	ZJ109-PB	K
CM11-F DOC ONLY KIT	ZJ110-RZ	F
CM11-F DOC/PT KIT	ZJ110-RB	K
CM11-F PT ONLY KIT	ZJ110-PB	K

TITLE	PART NUMBER	PRICE
CR11 DOC ONLY KIT	ZJ111-RZ	F
CR11 DOC/PT KIT	ZJ111-RB	J
CR11 PT ONLY KIT	ZJ111-PB	J
CR11/CM11F DOC/PT KIT	ZJ203-RB	K
DA11 DOC ONLY KIT	ZJ112-RZ	J
DA11 DOC/PT KIT	ZJ112-RB	K
DA11 PT ONLY KIT	ZJ112-PB	H
DC11 DOC ONLY KIT	ZJ113-RZ	K
DC11 DOC/PT KIT	ZJ113-RB	L
DC11 PT ONLY KIT	ZJ113-PB	J
DEC/X11 CT KIT	ZJ128-RN	N
DEC/X11 DOC ONLY KIT	ZJ129-RZ	M
DEC/X11 PT ONLY KIT	ZJ130-PB	L
DECSYSTEM-1080 DOC/PT KIT	ZJ196-RB	H
DFC11-A DOC/PT KIT	ZJ175-RB	H
DFC11-A MCRF ONLY KIT	ZJ175-FR	F
DH11 DOC ONLY KIT	ZJ114-RZ	M
DH11 DOC/PT KIT	ZJ114-RB	N
DH11 PT ONLY KIT	ZJ114-PB	K
DH11A DOC ONLY KIT	ZJ179-RZ	M
DH11A DOC/PT KIT	ZJ179-RB	N
DH11A PT ONLY KIT	ZJ179-PB	K
DJ11 DOC ONLY KIT	ZJ115-RZ	K
DJ11 DOC/PT KIT	ZJ115-RB	L
DJ11 PT ONLY KIT	ZJ115-PB	J
DL11-E C/D DOC ONLY KIT	ZJ116-RZ	I
DL11-E C/D DOC/PT KIT	ZJ116-RB	J
DL11-E C/D PT ONLY KIT	ZJ116-PB	H
DL11E DOC ONLY KIT	ZJ117-RZ	K
DL11E DOC/PT KIT	ZJ117-RB	L
DL11E PT ONLY KIT	ZJ117-PB	K
DL11W DOC ONLY KIT	ZJ235-RZ	I
DL11W DOC/PT KIT	ZJ235-RB	J
DL11W PT ONLY KIT	ZJ235-PB	H
DM11 DOC ONLY KIT	ZJ118-RZ	I
DM11 DOC/PT KIT	ZJ118-RB	J
DM11 PT ONLY KIT	ZJ118-PB	H
DM11B DOC ONLY KIT	ZJ119-RZ	I
DM11B DOC/PT KIT	ZJ119-RB	K
DM11B PT ONLY KIT	ZJ119-PB	H
DMC-11 DOC ONLY KIT	ZJ216-RZ	K
DMC-11 DOC/PT KIT	ZJ216-RB	L
DMC-11 PT ONLY KIT	ZJ216-PB	J
DN11 DOC/PT KIT	ZJ120-RB	H
DP11A DOC/PT KIT	ZJ121-RB	K
DP11A PT ONLY KIT	ZJ121-PB	I
DQ11A DOC ONLY KIT	ZJ122-RZ	M
DQ11A DOC/PT KIT	ZJ122-RB	N
DQ11A PT ONLY KIT	ZJ122-PB	L
DR11A DOC/PT KIT	ZJ123-RB	H
DR11B DOC/PT KIT	ZJ124-RB	H
DR11C DOC/PT KIT	ZJ125-RB	H
DR11K DOC/PT KIT	ZJ187-RB	H
DR11L/M DOC/PT KIT	ZJ205-RB	H
DT11 DOC/PT KIT	ZJ126-RB	H
DU11 DOC ONLY KIT	ZJ127-RZ	M
DU11 DOC/PT KIT	ZJ127-RB	N
DU11 PT ONLY KIT	ZJ127-PB	L
DUP-11 BASIC DOC/PT KIT	ZJ213-RB	L
DUP-11 BASIC DOC ONLY KIT	ZJ213-RZ	K
DUP-11 BASIC PT ONLY KIT	ZJ213-PB	J
DV11 DOC ONLY KIT	ZJ192-RZ	L
DV11 DOC/PT KIT	ZJ192-RB	M
DV11 PT ONLY KIT	ZJ192-PB	K
DX11B DOC ONLY KIT	ZJ131-RZ	L
DX11B DOC/PT KIT	ZJ131-RB	M
DX11B PT ONLY KIT	ZJ131-PB	K
DZ11 DOC ONLY KIT	ZJ223-RZ	I
DZ11 DOC/PT KIT	ZJ223-RB	K
DZ11 PT ONLY KIT	ZJ223-PB	H
FP11 DOC ONLY KIT	ZR101-RZ	N
FP11 DOC/PT KIT	ZR101-RB	O
FP11 PT ONLY KIT	ZR101-PB	N
FP11A DOC ONLY KIT	ZJ233-RZ	J
FP11A DOC/PT KIT	ZJ233-RB	K

TITLE	PART NUMBER	PRICE
FP11A MCRF ONLY KIT	ZJ233-FR	J
FP11A PT ONLY KIT	ZJ233-PB	J
GT40 DOC ONLY KIT	ZJ008-RZ	O
GT40 DOC/PT KIT	ZJ008-RB	Q
GT40 PT ONLY KIT	ZJ008-PB	O
GT44 DOC ONLY KIT	ZP003-RZ	O
GT44 DOC/PT KIT	ZP003-RB	P
GT44 PT ONLY KIT	ZP003-PB	V
ICR11 DOC ONLY KIT	ZJ218-RZ	J
ICR11 DOC/PT KIT	ZJ218-RB	K
ICR11 PT ONLY KIT	ZJ218-PB	H
ICS-11 DOC/PT KIT	ZJ191-RB	H
KD11 DOC/PT KIT	ZP101-RB	H
KD11A DOC/PT KIT	ZP105-RB	H
KE11-A DOC ONLY KIT	ZJ149-RZ	J
KE11-A DOC/PT KIT	ZJ149-RB	K
KE11-A PT ONLY KIT	ZJ149-PB	H
KE11-B DOC/PT KIT	ZJ188-RB	H
KE11E DOC ONLY KIT	ZR102-RZ	K
KE11E DOC/PT KIT	ZR102-RB	L
KE11E PT ONLY KIT	ZR102-PB	K
KE11F DOC ONLY KIT	ZP102-RZ	J
KE11F DOC/PT KIT	ZP102-RB	K
KE11F PT ONLY KIT	ZP102-PB	H
KG11A DOC/PT KIT	ZJ133-RB	H
KIT11-H DOC/PT KIT	ZJ134-RB	H
KJ11 DOC/PT KIT	ZR103-RB	H
KL11 DOC ONLY KIT	ZJ135-RZ	F
KL11 DOC/PT KIT	ZJ135-RB	J
KL11 PT ONLY KIT	ZJ135-PB	I
KL11/DL11-A DOC/PT KIT	ZJ136-RB	H
KT11C DOC ONLY KIT	ZR104-RZ	L
KT11C DOC/PT KIT	ZR104-RB	M
KT11C PT ONLY KIT	ZR104-PB	L
KT11D DOC ONLY KIT	ZP103-RZ	L
KT11D DOC/PT KIT	ZP103-RB	M
KT11D PT ONLY KIT	ZP103-PB	L
KW11 DOC/PT KIT	ZJ137-RB	H
KW11-P DOC/PT KIT	ZJ138-RB	H
KW11K DOC/PT KIT	ZJ217-RB	H
LA180 DOC/PT KIT	ZJ207-RB	H
LA30S DOC/PT KIT	ZJ139-RB	H
LA36 DOC ONLY KIT	ZJ183-RZ	J
LA36 DOC/PT KIT	ZJ183-RB	K
LA36 PT ONLY KIT	ZJ183-PB	H
LAB-11 DOC/PT KIT	ZJ140-RB	H
LC11/LA30 DOC/PT KIT	ZJ141-RB	H
LK11A DOC/PT KIT	ZJ227-RB	H
LP11 DOC/PT KIT	ZJ142-RB	H
LP11/LP05 DOC/PT KIT	ZJ178-RB	H
LP11/LP05 MCRF ONLY KIT	ZJ178-FR	F
LPC-11 DOC/PT KIT	ZJ143-RB	H
LPD11 DOC/PT KIT	ZJ176-RB	H
LPS-11 DOC ONLY KIT	ZJ144-RZ	K
LPS-11 DOC/PT KIT	ZJ144-RB	L
LPS-11 PT ONLY KIT	ZJ144-PB	K
LS11 DOC/PT KIT	ZJ145-RB	H
LSI-11 BASIC DOC/PT KIT	ZJV01-RB	M
LSI-11 BASIC DOC ONLY KIT	ZJV01-RZ	L
LSI-11 BASIC PT ONLY KIT	ZJV01-PB	L
LSI-11/PDP-11/03/V03 BASIC REDUCED	ZJF01-RB	M
FA & T DOC/PT KIT		
LV11 DOC/PT KIT	ZJ146-RB	H
M7298 DOC/PT KIT	ZJ169-RB	H
M9301/M9400 DOC/PT KIT	ZJ232-RB	H
M9301/M9400 MCRF ONLY KIT	ZJ232-FR	F
MA11 DOC/PT KIT	ZR105-RB	H
MF11P DOC ONLY KIT	ZR106-RZ	K
MF11P DOC/PT KIT	ZR106-RB	L
MF11P PT ONLY KIT	ZR106-PB	J
MF11UP DOC/PT KIT	ZJ195-RB	H
MM11 DOC/PT KIT	ZJ147-RB	H
MPG DOC ONLY KIT	ZJ197-RZ	V
MPG DOC/DT KIT	ZJ197-RB	V
MPG DOC/FLOPPY KIT	ZJ197-RY	N

TITLE	PART NUMBER	PRICE
MPG DOC/MT7 KIT	ZJ197-RF	O
MPG DOC/MT9 KIT	ZJ197-RD	O
MPG DOC/RK05 KIT	ZJ197-RE	O
MR11B DOC/PT KIT	ZJ148-RB	H
MS11-CM (BM) DOC/PT KIT	ZR107-RB	H
MS11-CP (BP) DOC/PT KIT	ZR108-RB	K
MS11-CP (BP) DOC ONLY KIT	ZR108-RZ	J
MS11-CP (BP) PT ONLY KIT	ZR108-PB	I
NC11A DOC ONLY KIT	ZJ132-RZ	I
NC11A DOC/PT KIT	ZJ132-RB	J
NC11A PT ONLY KIT	ZJ132-PB	H
PA11 DOC/PT KIT	ZJ150-RB	K
PA11 PT ONLY KIT	ZJ150-PB	H
PC11 DOC ONLY KIT	ZJ151-RZ	F
PC11 DOC/PT KIT	ZJ151-RB	J
PC11 PT ONLY KIT	ZJ151-PB	I
PDM70 DOC/PT KIT	ZJ152-RB	H
PDP-11/03 DOC/FLOPPY KIT	ZJ215-RY	O
PDP-11/04 BASIC REDUCED FA&T DOC/PT KIT	ZJF02-RB	M
PDP-11/05,35 CT ONLY KIT	ZJ198-RN	N
PDP-11/05/10/15/20 BASIC REDUCED FA&T DOC/PT KIT	ZJF03-RB	V
PDP-11/34 BASIC REDUCED FA&T DOC/PT KIT	ZJF04-RB	V
PDP-11/35/40 BASIC REDUCED FA&T DOC/PT KIT	ZJF05-RB	U
PDP-11/45/50/55 BASIC REDUCED FA&T DOC/PT KIT	ZRF01-RB	P
PDP-11/70 BASIC DOC ONLY KIT	ZR002-RZ	O
PDP-11/70 BASIC DOC/FLOPPY KIT	ZR002-RY	P
PDP-11/70 BASIC DOC/RK05 KIT	ZR002-RE	P
PDP-11/70 BASIC DOC/TU16 MT9 KIT	ZR002-RP	P
PDP-11/70 BASIC DOC/MT7 KIT	ZR002-RF	P
PDP-11/70 BASIC REDUCED FA&T DOC/PT KIT	ZRF02-RB	O
PDP-11/70 RWP04 DOC ONLY KIT	ZR110-RZ	M
PDP-11/70 RWS03/04 DOC ONLY KIT	ZR109-RZ	K
RC11 DOC ONLY KIT	ZJ153-RZ	J
RC11 DOC/PT KIT	ZJ153-RB	K
RC11 PT ONLY KIT	ZJ153-PB	I
RF11 DOC ONLY KIT	ZJ154-RZ	J
RF11 DOC/PT KIT	ZJ154-RB	K
RF11 PT ONLY KIT	ZJ154-PB	I
RH11 DOC ONLY KIT	ZJ155-RZ	K
RH11 DOC/PT KIT	ZJ155-RB	L
RH11 PT ONLY KIT	ZJ155-PB	J
RH11 TB TESTER DOC/PT KIT	ZJ214-RB	H
RH11 TB TESTER MCRF ONLY KIT	ZJ214-FR	G
RK06 DOC ONLY KIT	ZJ226-RZ	M
RK06 DOC/PT KIT	ZJ226-RB	N
RK06 PT ONLY KIT	ZJ226-PB	L
RK06 REDUCED FA&T DOC/PT KIT	ZJF13-RB	N
RK11 DOC ONLY KIT	ZJ157-RZ	K
RK11 DOC/PT KIT	ZJ157-RB	L
RK11 MCRF ONLY KIT	ZJ157-FR	K
RK11 PT ONLY KIT	ZJ157-PB	K
RK11/RK05 MCRF ONLY KIT	ZJF06-FR	K
RK11/RK05 REDUCED FA&T DOC/PT KIT	ZJF06-RB	M
RP04 CT ONLY KIT	ZJ190-RN	L
RP04/5/6 DOC ONLY KIT	ZJ180-RZ	M
RP04/5/6 DOC/PT KIT	ZJ180-RB	V
RP04/5/6 PT ONLY KIT	ZJ180-PB	M
RP11 DOC ONLY KIT	ZJ158-RZ	K
RP11 DOC/PT KIT	ZJ158-RB	L
RP11 PT ONLY KIT	ZJ158-PB	J
RP11-E DOC ONLY KIT	ZJ193-RZ	L
RP11-E DOC/PT KIT	ZJ193-RB	M
RP11-E PT ONLY KIT	ZJ193-PB	K
RP11C DOC ONLY KIT	ZJ159-RZ	K
RP11C DOC/PT KIT	ZJ159-RB	L
RP11C PT ONLY KIT	ZJ159-PB	J
RSX-11D USER ENVIRONMENT TEST PACKAGE DOC/MT9 KIT	ZP107-RD	L
RSX-11D USER ENVIRONMENT TEST PACKAGE DOC/MT7 KIT	ZP107-RF	L
RSX-11D USER ENVIRONMENT TEST PACKAGE DOC/RK05 KIT	ZP107-RE	N

TITLE	PART NUMBER	PRICE
RT01/RT02 DOC ONLY KIT	ZJ160-RZ	F
RT01/RT02 DOC/PT KIT	ZJ160-RB	J
RT01/RT02 PT ONLY KIT	ZJ160-PB	H
RX01/RX11 DOC ONLY KIT	ZJ189-RZ	J
RX01/RX11 DOC/PT KIT	ZJ189-RB	K
RX01/RX11 PT ONLY KIT	ZJ189-PB	H
RX01/RX11 REDUCED FAT DOC/PT KIT	ZJF07-RB	J
TA11 DOC ONLY KIT	ZJ161-RZ	L
TA11 DOC/PT KIT	ZJ161-RN	N
TA11 TAPE ONLY KIT	ZJ161-PN	M
TA11/TU60 REDUCED FA&T DOC/PT KIT	ZJF08-RB	M
TC11 DOC ONLY KIT	ZJ162-RZ	L
TC11 DOC/PT KIT	ZJ162-RB	M
TC11 PT ONLY KIT	ZJ162-PB	K
TC11/TU56 REDUCED FA&T DOC/PT KIT	ZJF09-RB	M
TM02/TU16 DOC ONLY KIT	ZJ182-RZ	L
TM02/TU16 DOC/PT KIT	ZJ182-RB	M
TM02/TU16 PT ONLY KIT	ZJ182-PB	K
TM02/TU16 REDUCED FA&T DOC/PT KIT	ZJF10-RB	M
TMAB-11 (TU10) REDUCED FA&T DOC/PT KIT	ZJF12-RB	M
TR79F DOC ONLY KIT	ZJ224-RZ	I
TR79F DOC/PT KIT	ZJ224-RB	J
TR79F PT ONLY KIT	ZJ224-PB	H
TS03 DOC ONLY KIT	ZJ194-RZ	K
TS03 DOC/PT KIT	ZJ194-RB	L
TS03 PT ONLY KIT	ZJ194-PB	J
TS03 REDUCED FA&T DOC/PT KIT	ZJF11-RB	M
UDC-11 DOC ONLY KIT	ZJ166-RZ	I
UDC-11 DOC/PT KIT	ZJ166-RB	J
UDC-11 PT ONLY KIT	ZJ166-PB	H
USER ENVIRONMENT TESTS PACKAGE DOC/ DOC/RK05 KIT	ZP106-RE	N
USER ENVIRONMENT TEST PACKAGE DOC/ DOC/DT KIT	ZP106-RC	M
USER ENVIRONMENT TEST PACKAGE DOC/ DOC/MT9 KIT	ZP106-RD	L
USER ENVIRONMENT TEST PACKAGE DOC/ MT7 KIT	ZP106-RF	L
VS60 DOC ONLY KIT	ZJ211-RZ	K
VS60 DOC/PT KIT	ZJ211-RB	L
VS60 PT ONLY KIT	ZJ211-PB	J
VSV01 DOC/PT KIT	ZJ228-RB	H
VT05 DOC/PT KIT	ZJ167-RB	H
VT05 MCRF ONLY KIT	ZJ167-FR	F
VT06 DOC/PT KIT	ZJ168-RB	H
VT20 DOC ONLY KIT	ZP104-RZ	J
VT20 DOC/PT KIT	ZP104-RB	K
VT20 PT ONLY KIT	ZP104-PB	I
VT50A DOC ONLY KIT	ZJ186-RZ	J
VT50A DOC/PT KIT	ZJ186-RB	K
VT50A PT ONLY KIT	ZJ186-PB	H
VT61 DOC ONLY KIT	ZJ219-RZ	J
VT61 DOC/PT KIT	ZJ219-RB	K
VT61 PT ONLY KIT	ZJ219-PB	H
VT71 DOC ONLY KIT	ZJ231-RZ	J
VT71 DOC/PT KIT	ZJ231-RB	K
VT71 PT ONLY KIT	ZJ231-PB	H


PDP-12 14

A.I.P. DIAG DOC/LT KIT	ZK103-RA	L
AD12M DIAG DOC/PT KIT	ZK102-RB	H
CM12 DIAG DOC/PT KIT	ZK106-RB	K
CM12B,C DIAG DOC/PT KIT	ZK107-RB	K
CM12F DIAG DOC/PT KIT	ZK108-RB	K
CR12 GDI DIAG DOC/PT KIT	ZK109-RB	J
DA14-E DIAG DOC/PT KIT	ZL106-RB	J
DB12 DIAG DOC/PT KIT	ZK110-RB	H
DB14 DIAG DOC/PT KIT	ZL101-RB	J
DC02F DIAG DOC/PT KIT	ZK111-RB	H
DC04 DIAG DOC/PT KIT	ZK112-RB	H
DC14-BA DIAG DOC/PT KIT	ZL102-RB	J
DC14-BE DIAG DOC/PT KIT	ZL108-RB	L
DC14-DA KIT	ZL103-RB	L

TITLE	PART NUMBER	PRICE
DC14-DE DIAG DOC/PT KIT	ZL107-RB	J
DF32 DIAG DOC/PT KIT	ZK113-RB	K
DL-14 DIAG DOC.PT KIT	ZK104-RB	L
DP12-A DIAG DOC/PT KIT	ZK114-RB	H
DP12-B DIAG DOC/PT KIT	ZK115-RB	H
DR12X DIAG DOC/PT KIT	ZK116-RB	H
DV08-N DIAG DOC/PT KIT	ZK117-RB	J
INDUSTRIAL 14 DIAG DOC/PT KIT	ZL109-RB	J
KE12 DIAG DOC/PT KIT	ZK118-RB	M
KF12 DIAG DOC/PT KIT	ZK119-RB	H
KIT B DIAG DOC/PT KIT	ZK104-RB	M
KP12 DIAG DOC/PT KIT	ZK120-RB	F
KT12 DIAG DOC/PT KIT	ZK121-RB	H
KW12-B, KW12-C KIT	ZK123-RB	H
KW12A DIAG DOC/PT KIT	ZK122-RB	H
LP12 645A DIAG DOC/PT KIT	ZK124-RB	H
LV12/LV8 DIAG DOC/PT KIT	ZK125-RB	H
MC12 DIAG DOC/PT KIT	ZK126-RB	L
MM14-A DIAG DOC/PT KIT	ZL105-RB	J
PDP-12 BASIC DIAG DOC/LT KIT	ZK001-RA	P
PDP-12 FPP DIAG DOC/LT KIT	ZK101-RA	O
PDP-14 & 14/L PROGRAM KIT	ZL001-RB	O
RK8E OPTION FOR PDP-12 KIT	ZK127-RA	M
TC12-F DIAG DOC/PT KIT	ZK128-RB	H
VR14, VR20 DIAG DOC/PT KIT	ZK130-RB	H
VT06 DIAG DOC/PT KIT	ZK130-RB	H
VW01 DIAG DOC/PT KIT	ZK131-RB	H
XY12 DIAG DOC/PT KIT	ZK132-RB	J

PDP-15

AA15A DOC/PT KIT	ZM101-RB	H
AA15B DOC/PT ROUTINE KIT	ZM102-RB	H
AD15 DOC/PT KIT	ZM103-RB	H
AF03 DOC/PT KIT	ZM105-RB	H
AF04-B DOC/PT KIT	ZM106-RB	H
AFC DOC/PT KIT	ZM104-RB	H
ASR33/35 DOC/PT KIT	ZM146-RB	K
BD15 DOC/PT KIT	ZM107-RB	H
CR15 DOC/PT KIT	ZM109-RB	J
DC01-E DOC/PT KIT	ZM147-RB	H
DP09A DOC/PT KIT	ZM110-RB	H
DT BASED SYSTEM EXERCISER	ZM141-RC	L
FP15 DOC/PT KIT	ZM111-RB	M
KA15 DOC/PT KIT	ZM112-RB	H
KE15 DOC/PT KIT	ZM113-RB	J
KF15 DOC/PT KIT	ZM114-RB	H
KM15 DOC/PT KIT	ZM115-RB	H
KT15 DOC/PT KIT	ZM116-RB	H
LA30 DOC/PT KIT	ZM117-RB	H
LA36 DOC/PT KIT	ZM139-RB	H
LP15C DOC/PT KIT	ZM118-RB	H
LP15F DOC/PT KIT	ZM119-RB	H
LT09/LT19 DOC/PT KIT	ZM120-RB	H
ME15 DOC/PT KIT	ZM121-RB	L
MK15A DOC/PT KIT	ZM122-RB	L
MP15 DOC/PT KIT	ZM123-RB	K
MX15 DOC/PT KIT	ZM124-RB	H
PC15 DOC/PT KIT	ZM125-RB	K
PDP-15 BASIC DOC/PT KIT	ZM001-RB	O
RF15 BASED SYSTEM EXERCISER	ZM142-RD	L
RF15 BASED SYSTEM EXERCISER	ZM142-RF	L
RF15/RS15 DOC/PT KIT	ZM126-RB	L
RK15 DOC/PT KIT	ZM140-RB	N
RP15 BASED SYSTEM EXERCISER	ZM143-RF	L
RP15 BASED SYSTEM EXERCISER	ZM143-RD	L
RP15 DOC/PT KIT	ZM127-RB	L
RP15SP DOC/PT KIT	ZM128-RB	L
TC02 DOC/PT KIT	ZM129-RB	L
TC59 DOC/PT KIT	ZM130-RB	L
UC15 DOC/PT KIT	ZM131-RB	L
UDC-15 DOC/PT KIT	ZM132-RB	H
VP15 DOC/PT KIT	ZM133-RB	I
VT05 DOC/PT KIT	ZM134-RB	H



Engineering Drawings

DIGITAL is in the process of converting the engineering drawing part numbering system. After some items you will see a code beginning MP _ _ _ _ . If this code is available, please use it as the part number. Otherwise, order by device.

ENGINEERING DRAWINGS

DEVICE	DESCRIPTION	PART NUMBER	PRICE
1090		MP00287	H
11 R20	PROCESSOR		K
11-L-40	PROCESSOR		H
11/03			K
11/04	PROCESSOR	MP00019	J
11/04 (ET AL)			M
11/05			M
11/05-S	PROCESSOR		L
11/15	PROCESSOR		H
11/20	PROCESSOR		H
11/34 VOL 1		MP00044	H
11/34 VOL 2		MP00082	K
1134-A		MP00190	H
1134A		MP00191	H
11/35	PROCESSOR		L
11/35-F	PROCESSOR		L
11/35-S	PROCESSOR		M
11/40	PROCESSOR		K
11/40 (ET AL)			M
11/45	PROCESSOR	MP00039	L
11/55 VOL 1		MP00039	L
11/55 VOL 2		MP00040	H
11/60		MP00166	H
11S60		MP00167	H
11T60		MP00168	H
11/V03		MP00094	H
11V05		MP00066	H
11W03		MP00111	H
11/70	PROCESSOR		I
11R20			M
12 VOL IV			M
14/30			J
14K			J
15 VOL II			M
16M			J
2223 TESTER		MP00120	H
2224			K
224-T			K
2338C		MP00330	H
32K		MP00317	H
7013505		MP00284	H
7013546		MP00263	H
7606844		MP00218	H
7606856		MP00226	H
7607041		MP00217	H
7607092		MP00222	H
7607096		MP00235	H
7607118		MP00220	H
7607406		MP00228	H
7607415		MP00221	H
7607426		MP00285	H
7607463		MP00246	H
7607471		MP00256	H
7607475		MP00194	H
7607478		MP00203	H
7607480		MP00206	H
7607482		MP00209	H
7607485		MP00212	H
7607487		MP00229	H
7607488		MP00230	H
7607489		MP00234	H
7607490		MP00258	H
7607491		MP00240	H
7607576		MP00197	H
8 MEMORY			H
8A		MP00177	K
8/E			J
8/F			J
8/I			I
8/L			H
8/M			J
861			H
8A (PDP)			K
8A400	8/16K CORE MEMORY & PROCESSOR		I

DEVICE	DESCRIPTION	PART NUMBER	PRICE
8A420			H
8A500	8/16K CORE MEMORY & PROCESSORS		L
8A600			H
8A800			H
8A820			H
8E			J
8F			K
8I	TRAINING MANUAL		K
8I (TRAIN)			I
8L			I
8M			K
8S (TRAIN)			H
A124			H
A241			H
A406			H
A407			H
A804			I
AA04			H
AA05			H
AA05-BA			H
AA05-CA			H
AA07			H
AA07-C			H
AA11 (A,B,C)			H
AA11 (ABC)	DISPLAY CONTROL		H
AA11-K		MP00161	H
AA11-D	D/A CONTROL		I
AA11-E	DISPLAY CONTROL FOR VR 20		H
AA15			H
AAV11		MP00186	H
AC01-A			H
AD01-A	A/D CONVERTER		I
AD01-D	A/D CONVERTER		I
AD02-A		MP00251	H
AD02-D		MP00323	H
AD08-A	A/D CONVERTER		H
AD08-B	A/D CONVERTER		H
AD15			H
AD8-A			H
AD8-ES			H
AD8EA	A/D CONVERTER		H
AD8EA-1	A/D CONVERTER		H
AD8EA-2	A/D CONVERTER		H
AD8ES	A/D CONVERTER		H
ADC1-AB	A/D CONVERTER, RACK MOUNTED		H
ADC8	MODULE SET FOR PDP-8 INTERFACE		H
ADC9	MODULE SET FOR PDP-9 INTERFACE		H
ADV11-A		MP00193	H
AF01-A	A/D CONVERTER		I
AF01-B	A/D CONVERTER		H
AF04-A	A/D CONVERTER		H
AF06-A	SYSTEM INTERFACE		H
AF08	A/D MODULE SET		I
AF16			H
AF17			H
AFC11	MASTER FILE A/D CONVERTER		I
AFC15			H
AFC8-T	A/D CONVERTER		K
AG12-A			H
AH02	SAMPLE & HOLD A/D CONVERTER		H
AH03	INPUT AMPLIFIER		H
AH04	SAMPLE & HOLD OPTION		H
AH05	BIPOLAR OPTION		H
AIP12	ANALYTICAL INSTRUMENT PACKAGE		I
AM01-A			H
AM03 (AB)			I
AM04	A/D CONVERTER		H
AM05	A/D CONVERTER		H
AM07	RELAY SYSTEM UNIT		H
AM11-K		MP00090	H
AM8-EA	8 CH MUX.		H
AM8-EC	CONTROL PANEL		H
AM8-ED	2 X 8 CH CONNECTOR		H
AM03-AB			H
AMXPA	MUX., RACK MOUNTED		H
AMXTB	MUX., RACK MOUNTED		H

DEVICE	DESCRIPTION	PART NUMBER	PRICE
AN1Ø		MPØØ326	H
AR11	ANALOG REALTIME SUBSYSTEM		I
AXØ8	SAMPLE & HOLD A/D CONVERTER		H
AXØ8-B	SAMPLE & HOLD A/D CONVERTER		H
BAØ8	PERIPHERAL EXPANSION UNIT		H
BA1Ø			H
BA11	EXTENSION MOUNTING BOX		H
BA11 (EC,ES)			H
BA11-F			H
BA11-K		MPØØ311	I
BA11-L		MPØØØ18	H
BA12			I
BA233			H
BA234	SIGNAL CONDITIONING MODULE		H
BA235			H
BA236			H
BA614	D/A MODULE BIPOLAR		H
BA633	D/A MODULE		H
BA8-AA	EXPANDER BOX WITH SLIDES		H
BA8-AB	EXPANDER BOX WITH SLIDES		H
BA8A			H
BA8-C		MPØØ14Ø	H
BARLL	RUGGED PDP-11 BOX		H
BBØ8-N	BUS INTERFACE		H
BBØ8-P	BUS INTERFACE		H
BB11	SYSTEM UNIT FOR BUS INTERFACE		H
BB11-D	DMA INTERFACE		I
BB11-F			H
BB11-H			I
BB11-K			H
BB11-M	SPC INTERFACE		I
BB15			H
BCØ1-F	CABLE CONNECTOR		H
BCØ1-H	CABLE CONNECTOR		H
BCØ1-L	CABLE ASSY. LAB-8/E		H
BCØ5-H	LINE CORD SET		H
BCØ5-J	LINE CORD SET		H
BCØ8-J	INTERNAL BUS EXPANSION		H
BC98-A			H
BCVIA			H
BCVIB			H
BCV1Ø		MPØØØ72	H
BCV18		MPØØØ7Ø	H
BCV171		MPØØØ71	H
BD15			H
BD5Ø	SERIAL EXPANDER		H
BE8-A	OMNIBUS EXPANDER		H
BMØ8	8K MEMORY EXPANDER BOX		H
BM792	PAPER TAPE LOADER ROM		H
BM8-L	MEMORY EXTENSION CONTROL		H
BM873 YA	RESTART/LOADER		H
BS11-A		MPØØ138	H
BTCH7221		MPØØ327	H
BVØ4			H
CB11	CASSETTE PROGRAMMING SYSTEM	MPØØ2Ø7	J
CCØ3-A			H
CC51	8 CH EXPANSION KIT		H
CC54			H
CCO3-B			H
CD11	DATA BREAK CARD READER CONTROL		I
CD12	H-P CARD READER & CONTROL		H
CD12-D	H-P CARD READER & CONTROL		H
CD12-HE	H-P CARD READER & CONTROL		H
CD12-HF	H-P CARD READER & CONTROL		H
CD2Ø	CARD READER	MPØØØØ7	H
CL8	EDUCATIONAL CLASSIC PDP-8 SYSTEM		H
CL8-Ø			I
CM11	MARK SENSE CARD READER		H
CM8-E	4Ø COL. OPTICAL MARK CARD READER		H
CM8-F	4Ø COL. OPTICAL MARK CARD READER		H
CM8-I	4Ø COL. OPTICAL MARK CARD READER		H
CM8L	4Ø COL. OPTICAL MARK CARD READER		H
CMM11-DP		MPØØØ32	H
CMS11-K		MPØØ225	H
CRØ3	CARD READER & CONTROL		H
CRØ3-B	CARD READER & CONTROL		H

DEVICE	DESCRIPTION	PART NUMBER	PRICE
CR11	CARD READER & CONTROL		H
CR15			H
CR8-E	CARD READER & CONTROL		H
CR8-I	CARD READER & CONTROL		H
CR8-L	CARD READER & CONTROL		H
CRS11-LL		MP000321	H
CSV11-A		MP000150	H
CSV11-B		MP000151	H
CU5		MP000069	H
D500		MP000260	H
DA07			H
DA08-A			H
DA09-A			H
DA09-B			H
DA10-A			H
DA11-B	UNIBUS LINK		I
DA11-F	UNIBUS WINDOW		I
DA27-CF	INTERPROCESSOR BUFFER		H
DA28C		MP000022	L
DA28-J		MP000279	H
DAS-33			M
DAS92		MP000214	H
DB02		MP000286	H
DB08-A	I/O DATA BUFFER		H
DB09-A	I/O DATA BUFFER		H
DB11-A	UNIBUS REPEATER		H
DB12			H
DB8-EB	INTERPROCESSOR BUFFER, 2 CABLES		H
DB8EA	INTERPROCESSOR BUFFER, 1 CABLE		H
DC01-ED			H
DC02			H
DC02-A	SERIAL LINE INTERFACE		H
DC02-F	BUFFERED ASYNC. LINE INTERFACE		H
DC04	INTERFACE		H
DC04-A	BUFFERED RECEIVER		H
DC08-A	SERIAL LINE MUX.		H
DC08-B	TTY/MODEM CONTROL PANEL		H
DC08-C	TELEGRAPH CONVERTER PANEL		H
DC08-CS	TELEGRAPH LINE INTERFACE		H
DC08-D	TELEGRAPH LINE CONNECTION PANEL		H
DC08-EB	TELEGRAPH CURRENT ADJUST. PANEL		H
DC08-F	MODEM INTERFACE CONTROL MUX.		H
DC08-FE	32 CH EXTENSION FOR DC08		H
DC08-FF	32 CH EXTENSION FOR DC08		H
DC08-FX	MODIFIED DC08-F		H
DC08-H	DIAL OUT MUX. FOR 10 LINES		H
DC10-A			I
DC10-A-B-C-D-E			H
DC10-B			H
DC10-C			H
DC10-D			H
DC10-E			H
DC10-F			J
DC11	SERIAL LINE SYSTEM UNIT		I
DC20	DATA CHANNEL COMMUNICATION MUX.	MP000008	M
DD11-A	PERIPHERAL SYSTEM UNIT		H
DD11-B	SYSTEM UNIT PREWIRE		H
DD11-C			H
DD11-D	9-SLOT PERIPHERAL CONTROLLER		H
DD11-K		MP000276	H
DD11-P			H
DDR11-A	RUGGEDIZED DD11-A		H
DDV11-A		MP000097	H
DDV11-B		MP000122	H
DE11-A	EIA LEVEL CONVERTER		H
DF10			I
DF10-A			H
DF10-C			H
DF10-T			H
DF11	TERMINAL MODULE SET		H
DF32	PARITY DECDISK CONTROL		H
DF32-DP	PARITY DECDISK CONTROL		I
DF32-EN	PARITY DECDISK CONTROL		H
DF32-EP	PARITY DECDISK CONTROL		J
DFC11			H
DFC11-A	SYNC. INTERFACE EIA		H

DEVICE	DESCRIPTION	PART NUMBER	PRICE
DH11	16 CH ASYNC. MUX.		L
DHS11-C		MP00195	H
DJ11	16 CH ASYNC. MUX.		K
DK01-A	16 LINE FREQ. INTERRUPT		J
DK10			H
DK10			K
DK8-EA	RTC, LINE FREQ.		H
DK8-EC	RTC, CRYSTAL FREQ.		H
DK8-EF	INPUT PANEL FOR DK8-EP		H
DK8-EP	RTC, PROGRAMMABLE		H
DK8-ES	RTC, PROGRAMMABLE		H
DKC8-A	ASYNC. LINE UNIT		H
DL10			K
DL11			H
DL11-A	ASYNC. LINE UNIT		H
DL11-B	ASYNC. LINE UNIT		H
DL11-W		MP00106	H
DL8I	DATA LINE INTERFACE		H
DLV11	SERIAL INTERFACE UNIT	MP00054	H
DLV11-H		MP00269	H
DM01	DATA CHANNEL MUX.		H
DM04	BUS MUX. DATA BREAK		H
DM09-A			H
DM09-L			H
DM11	16 LINE MUX.		K
DM11-BB	MODEM CONTROL MUX.		H
DM11-D			H
DMC11		MP00076	K
DMS4-0-2		MP00172	H
DN11	AUTO DIAL CONTROL		H
DN78			H
DN80	COMMUNICATION CONCENTRATOR		H
DN81	COMMUNICATION CONCENTRATOR		H
DN82	REMOTE BATCH CONCENTRATOR		H
DN87		MP00068	H
DN87-S		MP00109	H
DN87-V		MP00149	H
DP01-A	BIT SYNC. MODEM INTERFACE		H
DP01-CA			H
DP09-A			H
DP11	SYNC. LINE CONTROL		J
DP12-B			H
DP8E-A	SYNC. MODEM INTERFACE		H
DP8E-B	SYNC. MODEM INTERFACE		H
DQ11	SYNC. LINE CONTROL & NPR		K
DR01-A	OUTPUT DRIVER REGULATOR		H
DR09-A			H
DR09-B			H
DR11-A	PROGRAMMED DEVICE INTERFACE		H
DR11-B	DMA INTERFACE		H
DR11-C	GENERAL PURPOSE INTERFACE		H
DR11-K	GENERAL PURPOSE I/O INTERFACE		H
DR11-L	2 WORD INPUT UNIBUS INTERFACE	MP00003	H
DR11-M	2 WORD OUTPUT UNIBUS INTERFACE	MP00004	H
DR12-X	6 BIT RELAYS BUFFER		H
DR8-EA	BUFFERED I/O INTERFACE		H
DR8-EA1			H
DR8-EB	PATCH PANEL FOR USE IN H945		H
DR8-EB1			H
DR8-EC	DIGITAL I/O PANEL		H
DR8-ED	OMNIBUS INTERFACE	MP00005	H
DR8EA-2	12 BIT BUFFERED DIGITAL I/O		H
DRS11		MP00175	H
DRV11-P		MP00119	H
DRV11-B		MP00055	H
DS10			I
DS11	MULTIPLEXED SYNC. LINE UNIT		K
DS310	PDP-8 BASED DATA SYSTEM	MP00042	N
DS32	SLAVE DISK, 32K, 12 BITS		H
DS32-D7E	SLAVE DISK		H
DS320	PDP-8 BASED DATA SYSTEM		N
DS330	PDP-8 BASED DATA SYSTEM		H
DS340	PDP-8 BASED DATA SYSTEM		H
DS350	PDP-11 BASED DATA SYSTEM	MP00028	J
DS3CB		MP00037	H
DS80A		MP00291	H

DEVICE	DESCRIPTION	PART NUMBER	PRICE
DS8Ø-AA		MPØØ293	H
DS8ØA-AC		MPØØ294	H
DSS11		MPØØ174	H
DSP11-A		MPØØ233	H
DTØ3-D		MPØØ112	H
DTØ3-DT15		MPØØ1Ø1	H
DTØ3-F		MPØØ28Ø	H
DTØ5-D		MPØØ127	H
DTØ5-DT1Ø		MPØØ1Ø1	H
DS3RK	PDP-8 DISK BASED DATA SYSTEM	MPØØØ33	H
DTØ6-A		MPØØ318	H
DS5ØØ			H
DS51Ø			H
DS51Ø VOL 1	PDP-11 BASED DATA SYSTEM	MPØØØ29	J
DS52Ø			H
DS52Ø VOL 2	PDP-11 BASED DATA SYSTEM	MPØØØ3Ø	J
DTØ5-DP		MPØØØ31	L
DT11			K
DT11-C			H
DT62		MPØØ13Ø	H
DUI1	SYNC. INTERFACE		H
DUP11			H
DVØ8-N	DATA VERIFIER		H
DV11	SYNC/ASYN. MUX. CONTROL UNIT	MPØØ297	L
DV11-B		MPØØ295	H
DWØ8-A	I/O BUS CONVERTER POS/NEG		H
DWØ8-B	I/O BUS CONVERTER NEG/POS		H
DW15-A			H
DW8-E	OMNIBUS CONVERTER	MPØØØ12	H
DW8-E			I
DX1Ø			M
DX11-B	36Ø/37Ø CH INTERFACE		L
DZ11 VOL I		MPØØ253	H
DZ11 VOL II		MPØØ254	H
DZ11-Ø-6		MPØØ132	H
DZ11-Ø-1Ø VOLII		MPØØ136	H
FPP12	DOUBLE PRECISION PROCESSOR		I
FM11-U	CONVERSION KIT FOR 16K MEMORY		H
FP11-A		MPØØ189	H
FP11-AU		MPØØ188	H
FP11-B	FLOATING POINT PROCESSOR		I
FP11-C		MPØØØ38	J
FP15			K
FP45-CU		MPØØ165	H
FP7Ø-CU		MPØØØ46	H
FPP12			K
FPP12-A	DOUBLE PRECISION PROCESSOR		K
FPP8A		MPØØØ57	J
G235			H
G653			H
G851			H
GM11			I
GP1Ø-L			H
GP1Ø-M			H
GT4Ø	INTERACTIVE GRAPHIC TERMINAL		M
GT41		MPØØ319	H
GT42			H
GT43		MPØØ133	H
GT44	GRAPHIC DISPLAY SYSTEM		H
GT46-C		MPØØ154	H
GT48-A			H
GT62-M		MPØØ266	H
H2223			H
H3Ø8			H
H3Ø9			H
H312-A			H
H319-A-2		MPØØ184	H
H328		MPØØ185	H
H7Ø4			H
H716 (A,B,C,D)			H
H72Ø			I
H72Ø-F			H
H721			H
H722			H
H7222		MPØØ328	H
H73Ø			H

DEVICE	DESCRIPTION	PART NUMBER	PRICE
H734			H
H740-D			H
H742			H
H7421		MP000283	H
H743			H
H744			H
H7440		MP000085	H
H7441		MP000271	H
H745			H
H746			H
H750			H
H775	BATTERY BACKUP	MP000014	H
H777		MP000309	H
H777-B	11/04 POWER SUPPLY	MP000016	H
H780	11/03 POWER SUPPLY		H
H781		MP000084	H
H783		MP000157	H
H785		MP000272	H
H9270	BACKPLANE/CARD GUIDE ASSEMBLY		H
H9270			H
H9270-A	BACKPLANE/CARD GUIDE ASSEMBLY		H
H9271		MP000045	H
H9280		MP000131	H
H950			H
H9500		MP000058	H
H9501		MP000059	H
H9502		MP000060	H
H9503		MP000061	H
H9514		MP000262	H
H960-B			H
H960-C			H
H960-D			H
H967-AB			H
H9831		MP000299	H
H983		MP000261	H
IBV11-A		MP000274	H
ICR11 (A)			K
ICS11 (M)			I
ICS8			I
IDAC			H
IDC-8	IND. DATA ACQUISITION BASE SYST.		I
IDC-I	MODULE FOR IND. CONTROL SYST.		H
IDC-IA	ISOLATED DC SENSE		H
IMX-I	16 CH A/D MULTIPLEXER		H
IRL	16 OUTPUT RELAYS		H
ISH-I	ANALOG SHIELD		H
KAl0 (SCH)			M
KAl1	16 BIT PROCESSOR		I
KAl1-A			K
KAl1-YA	16 BIT PROCESSOR		I
KAl5			H
KA8-E	BUS INTERFACE FOR PDP-8/E		H
KA8-I	POSITIVE BUS KIT		H
KB11-A	16 BIT PROCESSOR		K
KB11-B	16 BIT PROCESSOR		M
KB11-C			H
KC09-A			H
KC09-C			H
KCl1	16 BIT PROCESSOR		K
KCl1-YA	16 BIT PROCESSOR		I
KC341-B			H
KC8-A	PROGRAMMER'S CONSOLE		H
KC8-E			H
KC8-EA	PROGRAMMER'S CONSOLE 8E		H
KC8M	PROGRAMMER'S CONSOLE 8M		H
KD09-A			H
KD09-C			H
KD11-A	16 BIT PROCESSOR		K
KD11-B	16 BIT PROCESSOR		J
KD11-D	ONE BOARD 11/05	MP000020	K
KD11-E		MP000043	I
KD11-EA		MP000192	H
KD11-F	11/35 - 11/40 PROCESSOR	MP000049	H
KD11-H	11/35 - 11/40 PROCESSOR	MP000050	H
KD11-J	11/35 - 11/40 PROCESSOR	MP000051	H
KD11-K		MP000156	H

DEVICE	DESCRIPTION	PART NUMBER	PRICE
KD11-L	11/35 - 11/40 PROCESSOR	MP00052	H
KD11-M	11/35 - 11/40 PROCESSOR	MP00053	H
KD11-P		MP00264	H
KD11-R		MP00277	H
KD15			H
KD8E	DATA BREAK OPTION		H
KD8L	DATA BREAK OPTION		H
KE09-A			I
KE09-C			H
KE11-A	EXTENDED ARITHMETIC ELEMENT		I
KE11-B	EXTENDED ARITHMETIC ELEMENT		H
KE11-E	EXTENDED INSTRUCTION SET		H
KE11-F	STACK ORIENTED FLOATING POINT		H
KE15			H
KE8-I	EXTENDED ARITHMETIC ELEMENT		H
KE8E	EXTENDED ARITHMETIC ELEMENT		H
KER11-A	EXTENDED ARITHMETIC ELEMENT		H
KEV11	EXTENDED ARITHMETIC ELEMENT		H
KF09-A			H
KG09 (B,C)			H
KG09 B&C			H
KG09-D			H
KG11-A	CRC/LRC ARITHMETIC ELEMENT		H
KG8E	REDUNDANCY CHECK OPTION		H
KH11-A	SYSTEM EXPANSION (LATENCY REDUC.)		K
KI10			M
KI10-MC		MP00278	H
KIT-01-A			I
KIT-11- HT			H
KIT36-A		MP00148	H
KJ11-A	STACK LIMIT REGISTER		H
KK8-E	PROCESSOR FOR PDP-8/E		H
KK8-F		MP00250	H
KL10-PM		MP00234	H
KL10 VOL I		MP00001	H
KL10 VOL II		MP00002	M
KL10-C VOL I		MP00091	H
KL10-C VOL II		MP00092	H
KL10-E VOL I		MP00300	H
KL10-E VOL II		MP00301	H
KL10-U		MP00307	H
KL11 (B,C,D,E,F)			H
KL11-A	TELETYPE CONTROL		H
KL11-B,C,D,E,F	TELETYPE CONTROL		H
KL8-A			H
KL8-E	ASYNC. DATA CONTROL		H
KL8-F	DOUBLE BUFFERED KL8-E		H
KL8-J			H
KL8-M	MODEM CONTROL FOR KL8-JA		H
KL8JA	DOUBLE BUFFERED ASYNC. CONTROL		H
KLR11	RUGGEDIZED KL11-A		H
KM10			H
KM11	MAINTENANCE MODULE		H
KM15			H
KM15			H
KM8-A	MEMORY EXT. TIME SHARE CONTROL		H
KM8E	MEMORY EXT. TIME SHARE CONTROL		H
KMP01			H
KP09-A			H
KP11-A			H
KP8-E	POWER FAIL & AUTO RESTART		H
KP8-I	POWER FAIL OPTION		H
KR01	AUTO RESTART OPTION		H
KT10			H
KT10-A			H
KT11-C	MEMORY MANAGEMENT UNIT		H
KT11-D	MEMORY MANAGEMENT UNIT		H
KT11-E	MEMORY MANGEMENT UNIT		H
KT15			H
KV8-E	ARBITRARY VECTOR DISPLAY CONTROL		H
KV8-I	ARBITRARY VECTOR DISPLAY CONTROL		H
KV8-L	ARBITRARY VECTOR DISPLAY CONTROL		H
KW08-S	RTC		H
KW09-L			H
KW11-L			H
KW11-P			H

DEVICE	DESCRIPTION	PART NUMBER	PRICE
KW11-W			H
KW11-Y		MP00255	H
KW11L	REALTIME CLOCK, LINE FREQUENCY		H
KW11P	PROGRAMMABLE REALTIME CLOCK		H
KW8-I			H
KW8-LA	FIXED INTERVAL RTC - LINE FREQ.		H
KW8-LB	FIXED INTERVAL RTC - VAR. FREQ.		H
KW8-LC	FIXED INTERVAL RTC - CRYSTAL FREQ.		H
KW8-LD,LE	PROGRAMMABLE RTC - LINE FREQ.		H
KW8-LF	PROGRAMMABLE RTC - CRYSTAL FREQ.		H
KWV11			H
KWV11-A		MP00200	H
KX09-A			H
KY09			H
KY11-A	STANDARD 11/20 CONSOLE		H
KY11-B	TURN KEY CONSOLE FOR 11/05		H
KY11-C	PROGRAMMER'S CONSOLE		H
KY11-D	11/0 PROG. & MAINT. CONSOLE		H
KY11-E	STANDARD 11R20 CONSOLE		H
KY11-J			H
KY11-LA	11/04-34 OPERATOR'S CONSOLE	MP00017	H
KY11-LB	11/04-34 PROGRAMMER'S CONSOLE	MP00015	H
LA11			H
LA180			H
LA30	DECWRITER		I
LA35			H
LA36	DECWRITER		H
LA8A-P		MP00268	H
LA8-P		MP00075	H
LAB			H
LAB8E	RACK MOUNTED SYSTEM,8K		H
LASXX		MP00242	H
LASXX-AD		MP00245	H
LASXX-AC		MP00281	H
LAV11		MP00306	H
LAXX-KG	EIA INTERFACE FOR LA36		H
LAXX-KH	MOUNTED KIT FOR DF11 INTERFACE		H
LAXX-KJ			H
LAXX-KK			H
LAXX-KV	FORM FEED OPTION		H
LAXX-KW			H
LAXX-KX			H
LAXX-KY	HT & VT FORMS CONTROL		H
LAXX-KZ			H
LAXX-LA	AUTO LINE FEED/CARRIAGE RETURN		H
LAXX-LB	EXPANDER OPTION MOUNTING KIT		H
LAXX-LF			H
LAXX-LG			H
LAXX-LM			H
LAXX-LN			H
LAXX-LZ			H
LAXX-NW		MP00248	H
LAXX-PK	ROM & KEY CAPS		H
LC11			H
LC11-A	PARALLEL CONTROL FOR LA30-P		H
LC8-0			H
LC8-E			H
LC8E	PARALLEL CONTROL FOR LA30		H
LC8L	DECWRITER PARALLEL INTERFACE		H
LCR11			H
LCR11-A	PARALLEL CONTROL FOR LAR30-P		H
LE8	LINE PRINTER CONTROL		H
LINC-8	LINC & PDP-8 FUNCTIONS		K
LINC-8-O-M			H
LINC-8-O-P			H
LK01	KEYBOARD		H
LK01	KEYBOARD		H
LK02	DEC STANDARD ENCODED KEYBOARD		H
LK03-A			H
LK35-A			H
LP01	356 1PM.PRINTER		H
LP02	245 1PM.PRINTER		H
LP05	300 1PM.PRINTER		H
LP08	INTERFACE LINE PRINTER		H
LP09 (C,D)			H
LP10			H

DEVICE	DESCRIPTION	PART NUMBER	PRICE
LP100		MP00201	H
LP11	LINE PRINTER CONTROL MODULE		H
LP12			H
LP15-A			I
LP15-C			H
LP15-F			H
LP20		MP00006	L
LP200		MP00320	H
LPC-D			H
LPC01	INTERFACE TO PHOTON		I
LPC11-C	INTERFACE TO PHOTON		I
LPC11-D	INTERFACE TO PHOTON PACESETTER		I
LPC11-E	INTERFACE TO HARRIS INTERTYPE		J
LPC8-A	INTERFACE TO PHOTON		H
LPC8-B	INTERFACE TO PHOTON		H
LPC8-C	INTERFACE TO PHOTON		H
LPC8-D	INTERFACE TO PHOTON PACESETTER		H
LPC8-E	INTERFAC T O HARRIS INTERTYPE		H
LPD	UNIVERSAL CONTROL FOR LPC01		H
LPD11			J
LPD8	UNIVERSAL CONTROL FOR LPC01		H
LPS	LABORATORY PERIPHERAL SYSTEM		I
LPS11			K
LPS11-E			I
LPS11-S			K
LS11	LOWSPEED LINE PRINTER		H
LS11/IV		MP00334	H
LSS11F		MP00324	H
LS120		MP00322	H
LS8-E	CENTRONICS PRINTER CONTROL		H
LT08	CONTROL WITH SPACE FOR 5 LT08-B		H
LT15			H
LT19			H
LT19-A			H
LT19-B			H
LT33			H
LT35			H
LT37-A-D			H
LV11	500 LPM. LINE PRINTER		H
LV12	INTERFACE FOR LV01 PRINTER		H
M105			H
M792			H
M792-YA			H
M792-YB			H
M792-YC			H
M792-YH			H
M792-YL			H
M7940			H
M7941			H
M7942			H
M7944			H
M9301		MP00196	H
MA10			K
MA10-T-A			H
MA11-KA		MP00205	H
MA11-KIT		MP00159	H
MA11-KK		MP00173	H
MA20		MP00010	J
MB10			H
MB20		MP00179	H
MB11-S	850 NSEC. MM11-S		H
MC70			H
MC70-B			H
MC71-A			H
MC71-B			H
MC8-IB	4K MEMORY WITH EXTENSION CONTROL		H
MC8-LA	4K MEMORY WITH EXTENSION CONTROL		H
MC8I	4K MEMORY WITH EXTENSION CONTROL		H
MC8I-B			H
MCA-20		MP00267	H
MD10			H
ME09			H
ME09-B			H
ME10			K
ME11-L	8K MEMORY SYSTEM		I
ME15			J

DEVICE	DESCRIPTION	PART NUMBER	PRICE
MF1Ø			K
MF11-L			H
MF11-LP	8K PARITY CORE MEMORY & CONTROL		H
MF11S-K		MPØØ31Ø	H
MF11-U	16K MEMORY & LOGIC		H
MF11-U/UP			I
MF11-W	MF11-U BACKPLANE	MPØØØ34	H
MF11-W/WP			I
MF15-U		MPØØØØ9	H
MG1Ø			L
MH1Ø		MPØØ178	
MI8-E	BOOTSTRAP LOADER		H
MJ11	MEMORY CONTROL & POWER SUPPLY		K
MK15			H
MMØ9			H
MMØ9-B&C			H
MM11 (K,L)			H
MM11-C	8K CORE MEMORY 11/Ø4-34		H
MM11-E	4K MEMORY & CONTROL		H
MM11-EX	8K 16 BIT MEMORY		H
MM11-F	4K 16 BIT MEMORY		H
MM11-FP&FY	4K 18 BIT MEMORY		H
MM11-FX	8K 16 BIT INTERLEAVED MEMORY		H
MM11-L	8K 16 BIT CORE MEMORY		H
MM11-LP	8K PARITY CORE MEMORY		H
MM11-S	8K 16 BIT CORE MEMORY		H
MM11D			H
MM14-A	PDP-14 4K READ/WRITE MEMORY		I
MM15			H
MM15-SW		MPØØ134	H
MM8-A			H
MM8-E	4K CORE MEMORY EXPANSION		I
MM8-EJ			I
MM8-I	ADDITIONAL MEMORY		H
MM8-IC	4K MEMORY MODULE WITH PARITY		H
MM8-ID	8K MEMORY MODULE WITH PARITY		H
MM8-L	4K MEMORY		H
MM8-O			H
MM8EJ	8K CORE MEMORY EXPANSION		H
MMR11	RUGGEDIZED 4K MEMORY		H
MOD-I			M
MOD-II			M
MOPAC		MPØØ211	H
MPØ9-A			H
MP15			H
MP8-E	PARITY OPTION FOR 32K, PDP-8-E		H
MP8-EJ			H
MP8-I	PARITY OPTION, FIRST 4K		H
MR11-A	BOOTSTRAP LOADER		I
MR11-D	BOOTSTRAP LOADER		H
MR11-DB	BOOTSTRAP LOADER		H
MR8-A	BLASTABLE READ ONLY MEMORY		H
MR8-AD			H
MR8-E			H
MR8-EC			H
MR8-F (FB)			H
MR8-SA			H
MR8E	READ ONLY MEMORY 256 WORDS		H
MR8F	READ ONLY MEMORY 512 WORDS RAM		H
MRV11-A			H
MRV11-VA		MPØØ2Ø8	H
MS11-B	MOS MEMORY CONTROL		H
MS11-C	BIPOLAR MEMORY CONTROL		H
MS11-C			H
MS11-E	4K 16 BIT MOS, RAM	MPØØØ21	H
MS11-K		MPØØ325	H
MS8-A	MOS RAM		H
MS8-A			H
MSV11			H
MSV11-B		MPØØØ67	H
MSV11-C		MPØØ259	H
MX1Ø			H
MX15			H
NC11-A			J
NNØ1-A	A/D CONVERTER TRANSFERS		H
NNØ1-AA	A/D CONVERTER INTERFACE		H

DEVICE	DESCRIPTION	PART NUMBER	PRICE
NP02-LA			H
OMD8-S	OPTION MOUNTING HARDWARE		H
PA60-A	PAPER TAPE CONTROL		H
PA60-B	PA60-A CONTROL EXTENSION		H
PA60-C	NON TORE TAPE ALLOTMENT		H
PA61-A	DRIVER FOR 4 READERS 4 PUNCH		H
PA611	READER & PUNCH CONTROL		K
PA63	16 CHANNEL MUX.		I
PA68-A,B	READER & PUNCH CONTROL		H
PA68-CA	READER & PUNCH CONTROL		H
PA68-D	READER & PUNCH CONTROL		H
PA68-DA	READER & PUNCH CONTROL		H
PA68-EA	READER & PUNCH CONTROL		H
PA68-F	READER & PUNCH CONTROL		H
PC01-A	SPARE PT PUNCH/READER		H
PC02	SPARE PT READER		H
PC03	SPARE PT PUNCH		H
PC04			H
PC04-BC	PT PUNCH, READER & POWER SUPPLY		H
PC04/05	PT PUNCH, READER & POWER SUPPLY		H
PC09			H
PC10		MP00316	H
PC11	HIGH SPEED PT READER & PUNCH		H
PC15			H
PC8-E			I
PC8-L			H
PC8E	PT READER & PUNCH		H
PC8E-EA	PT READER & PUNCH		H
PC8I	HIGH SPEED PT READER/PUNCH		H
PC8L	HIGH SPEED PT READER/PUNCH		H
PCR11	PC11 ADAPTED FOR RUGGEDIZED 11		H
PCR11			H
PDM-20			I
PDM70	PROGRAMMED DATA MOVER, BASIC BOX		I
PDM70-V		MP00096	H
PDP11		MP00213	H
PDM70			K
PDP 15 VOL II			K
PDP-8 MEM	MEMORY		H
PDP-8/A	RACK MOUNTABLE PDP-8		I
PDP-8/E	TABLE TOP PDP-8	MP00162	J
PDP-8/F	RACK MOUNTABLE PDP-8/E		J
PDP-8/I	PDP-8-I, 12 BIT, M SERIES MOD.		I
PDP-8/L	PDP-8-L, 12 BIT, M SERIES MOD.		H
PDP-8/M	RACK MOUNTABLE PDP-8/E, PDP-8/M		J
PDP-9			H
PDP15-C			J
PK11		MP00282	H
PL8-0	PUNCH, READER, DECWRITER ASSY.		K
PM301		MP00062	H
PMK01	PORTABLE PT READER		I
PMT11		MP00247	H
PP67-C	6 LEVEL PT PUNCH		H
PP8-E	PT PUNCH		H
PP8-I	PT PUNCH PLUS CONTROL		H
PP8-I-A	PT PUNCH PLUS CONTROL		H
PP8-L	PT PUNCH PLUS CONTROL		H
PR11	HIGH SPEED READER & CONTROL		K
PR68-A	6 OR 8 LEVEL PT READER		H
PR68-B	6 OR 8 LEVEL PT READER		H
PR68-D	6 OR 8 LEVEL PT READER		H
PR68-DA	6 OR 8 LEVEL PT READER		H
PR68-E	6 OR 8 LEVEL PT READER		H
PR8-E	PT READER		I
PR8-I	PT READER		H
PR8-L	PT READER		H
PRS01		MP00232	H
PT08-A	TTY INTERFACE		H
PT08-B	SERIAL LINE INTERFACE		H
PT08-B			H
PT08-BF	TTY INTERFACE		H
PT08-BF			H
PT08-BFX			H
PT08-CF	TTY INTERFACE		H
PT08-CFX	TTY INTERFACE		H
PT08-F	EIA ADAPTER		H

\$22.00 in 1970

DEVICE	DESCRIPTION	PART NUMBER	PRICE
PT09-BFX			H
PTB8-0			H
PTOC-C	DUAL SERIAL LINE INTERFACE		H
PTS8-E			H
PTW8-E			I
RAD8E	RADIOTHERAPY, PLANNING SYSTEM		M
RC10-A			H
RC10-B			H
RC11	CONTROLLER FOR RS64		H
RD10-A			H
REV11		MP00073	H
RF/RS111	16 BIT DECDISK CONTROL/DECDISK		J
RF08	DISK CONTROL		H
RF09			H
RF09-T			H
RF11/RS11			M
RF15/RS09			K
RH10			J
RH11	MASSBUS INTERFACE		J
RH20		MP00056	H
RH70	MASBUS CONTROLLER		J
RHS04-D	FIXED HEAD DISK WITH CABLE		H
RJP04-A	MASSBUS INTERFACE		H
RJP04-B	MASSBUS INTERFACE		H
RJP04-C	DUAL ACCESS KIT		H
RJP05-A		MP00113	H
RJP05-B		MP00114	H
RJP04-C		MP00115	H
RJP06-A		MP00116	H
RJP06-B		MP00117	H
RJP06-C		MP00118	H
RJS03-B	256K FIXED HEAD DISK SYSTEM		M
RJS04-B	512K FIXED HEAD DISK SYSTEM		M
RK01	DISK CARTRIDGE		H
RK01-X	DISK DRIVE		H
RK02	LOW DENSITY DIABLO DISK DRIVE		H
RK03	DISK CARTRIDGE SYSTEM		H
RK05	DISK CARTRIDGE SYSTEM		H
RK05-A			H
RK05-H			H
RK05-J			H
RK06		MP00198	K
RK06-E		MP00237	H
RK06-F		MP00239	H
RK06-TA		MP00187	H
RK08	CONTROL FOR RK05 DISK DRIVE		I
RK11-C	H950 CAB. POWER SUPPLY & CONTROL		K
RK11-D	16 BIT SYSTEM UNIT CONTROL		I
RK15-J		MP00089	H
RK611		MP00105	H
RK85-L		MP00288	H
RK8-E			I
RK8-F			I
RK8-F-L		MP00289	H
RK8J-E	16 BIT WORK DISK		H
RK8J-F	OMNIBUS CONVERTER		H
RK8-L		MP00290	H
RKV11-D		MP00223	H
RL11		MP00153	H
RK611-E		MP00236	H
RK611-F		MP00238	H
RK8-L		MP00290	H
RM08	DRUM AND CONTROL		H
RM09			H
RM10			H
RM10-B			I
RP02			H
RP03			H
RP04	DISK PACK & DRIVE		J
RP04-C	DUAL ACCESS KIT		H
RP04-4		MP00257	H
RP04/05/06			K
RP05/06 (TRAIN)			K
RP09			H
RP09			J
RP10-A			J

DEVICE	DESCRIPTION	PART NUMBER	PRICE
RP1Ø-C			J
RP11	DISK PACK UNIT & CONTROL		L
RP11-C	DISK PACK UNIT & CONTROL		L
RP11-E			M
RP15			H
RP15-O			L
RPR11	CONTROL & LST REBUILT DISK PACK		H
RSØ3	FIXED HEAD DISK DRIVE		I
RSØ4	FIXED HEAD DISK DRIVE		J
RSØ8	262K, 12 BIT DECDISK		H
RSØ8-M	MECHANICAL ASSY.		H
RSØ8-MA	MECHANICAL ASSY.		H
RSØ8-P	POWER CONTROL & LOGIC		H
RSØ8-TA	RSØ8 TIMING TRACK WRITER		H
RSØ9			H
RSØ9-A			H
RSØ9-B			H
RSØ9-C			H
RSØ9-O			H
RSØ9-P			H
RSØ9-TA			H
RS11	FIXED HEAD DISK DRIVE		H
RS11-A	FIXED HEAD DISK DRIVE		H
RS11-C	DECDISK		H
RS11-D	DECDISK		H
RS11-O			H
RS64	FIXED HEAD DISK DRIVE		H
RS64 (A,B)			H
RTØ1	16-KEY REMOTE TERMINAL		H
RTØ1-N	FOUR DIGIT DISPLAY		H
RTØ2	ALPHANUMERIC TERMINAL		H
RTØ2-B	TERMINAL WITH FULL KEYBOARD		H
RTØ2-C	BADGE READER TERMINAL		H
RT48		MPØØ1Ø4	H
RTPØ4		MPØØØ77	H
RTPØ5		MPØØ1Ø3	H
RTPØ6		MPØØ1Ø2	H
RT84		MPØØ124	H
RWPØ5-A		MPØØ141	H
RWPØ5-B		MPØØ142	H
RWPØ5-C		MPØØ143	H
RWPØ6-A		MPØØ144	H
RWPØ6-B		MPØØ145	H
RWPØ6-C		MPØØ146	H
RWSØ3-B	RSØ3 11/7Ø CONTROL		H
RWSØ4-B	RSØ4 11/7Ø CONTROL		I
RXØ1	PACKAGE OF FLOPPY DISKETTES	MPØØ296	H
RX11	CONTROL & SINGLE/DUAL DRIVE		H
RX8	CONTROL & SINGLE/DUAL DRIVE		H
RXV11	CONTROL & DUAL DRIVE	MPØØØ24	J
SP11-PS	SPARE PARTS FOR H72Ø POWER SUPPLY		H
SP8-IA	SPARE PARTS FOR PDP-8/I & TTY		H
SP8-IB	SPARE PARTS FOR PDP-8/I & TTY		H
TA11	DEC CASSETTE 11 CONTROL		J
TA36		MPØØ241	H
TA8-Ø	DEC CASSETTE, 8/E CONTROL		J
TCØ1	DECTAPE CONTROL		H
TCØ2	DECTAPE CONTROL		H
TCØ2-B	DECTAPE CONTROL		H
TCØ2-D	DECTAPE CONTROL		H
TCØ2-E	DECTAPE CONTROL		H
TCØ8-A	POS BUS DECTAPE CONTROL		I
TCØ8-N	NEG BUS DECTAPE CONTROL		H
TCØ8-NA	NEG BUS DECTAPE CONTROL		H
TC11	DECTAPE CONTROL		K
TC15			H
TC5Ø	GENERAL MAGTAPE CONTROL		H
TC58	AUTO MAGTAPE CONTROL		H
TC59			I
TCR1Ø		MPØØ147	H
TD1Ø			J
TD8-E	DECTAPE CONTROL		I
TE16		MPØØ333	H
TEV11		MPØØØ74	H
THU16		MPØØØ93	H
TJU16-E	MAGTAPE SYSTEM 16ØØ/18ØØ		H

DEVICE	DESCRIPTION	PART NUMBER	PRICE
TM02	MAGTAPE FORMATTER		J
TM10-A			I
TM10-B			I
TM10A-0			H
TM10A-A			H
TM11	MAGTAPE CONTROL		J
TM8-E	MAGTAPE CONTROL		I
TM8-M			J
TM8-O			I
TMA	IMPROVED MAGTAPE CONTROL		H
TMA11			J
TMA11-M			K
TMB11		MP000078	H
TR02-0	INCREMENT TAPE CONTROL		H
TR02-N	INCREMENT TAPE CONTROL		H
TR02-P	INCREMENT TAPE CONTROL		H
TR05			I
TR06-E			H
TR07-AC		MP000176	H
TTU16-E		MP000273	H
TTV45-E		MP000088	H
TU10-W		MP000155	H
TU10-N		MP000216	H
TR79-FA	TAPE CONTROL & FORMATTER	MP000026	H
TU16B		MP000087	H
TU16-TA		MP000183	H
TU45-A		MP000100	H
TU45-B		MP000095	H
TU10-10A			K
TU16	SLAVE DISK 9 TRACKS		I
TU20			H
TU30			H
TU40			H
TU55	DECTAPE TRANSPORT		H
TU55-A	50 HZ DECTAPE		H
TU56	DUAL DECTAPE TRANSPORT		H
TU60	DUAL CASSETTE		I
TYPE 8 NEG			K
TYPE 8 POS			K
TYPESET 8 NEG			I
TYPESET 8 POS			J
UC15			J
UC15-F			H
UDC	UNIVERSAL DIGITAL COMPUTER		I
UDC11			K
UDC15			H
UDC8	UNIVERSAL DIGITAL CONTROLLER		K
VC8-E	POINT PLOT DISPLAY CONTROL		H
VC8-I	SCOPE DISPLAY CONTROL		H
VC8-L-A	DISPLAY CONTROL MODULE SET		H
VK8-A		MP000181	H
VK8E	CONTROL FOR VT8-E		H
VL04			H
VM03	MOUNTING HARDWARE FOR TEK.602,604		H
VM08	MULTIPLEXER CONTROL & LINE DRIVER		H
VP09			H
VP10			H
VP10-A			H
VP15			H
VP15-BL			H
VP15-C			H
VP8-IA	563 PLOTTER & CONTROL		H
VP8-IB	565 PLOTTER & CONTROL		H
VP8-LA	563 PLOTTER & CONTROL		H
VP8-LB	565 PLOTTER & CONTROL		H
VR01-A	TEKTRONIX RM03 OSCILLOSCOPE		H
VR14	POINT PLOT DISPLAY, RACK MOUNTED		I
VR17	DISPLAY WITH LIGHT PEN		H
VR20	2 COLOR VR14, RACK MOUNTED		I
VR48			H
VRV01		MP000064	H
VS08	INTERFACE MOUNTING PANEL FOR KV8		H
VS08-P	INTERFACE MOUNTING PANEL FOR KV8		H
VS60			H
VSV01		MP000063	H
VT01	STORAGE TUBE DISPLAY		H

DEVICE	DESCRIPTION	PART NUMBER	PRICE
VT04			H
VT05	ALPHA NUMERIC TERMINAL		J
VT11	DISPLAY PROCESSOR		J
VT14			K
VT15			L
VT20	CRT TERMINAL		J
VT20-B			K
VT48			L
VT50		MP000036	J
VT52	CRT TERMINAL	MP000035	I
VT55		MP000098	H
VT61		MP000107	I
VT62		MP000215	H
VT71-0-2		MP000128	H
VT71-0-3		MP000129	H
VT71-T-02		MP000128	H
VT71-0-3		MP000129	H
VT61-T		MP000110	I
VT8-E	VIDEO DISPLAY - 1 LINE BUFFER		I
VTV01		MP000065	H
VW01	WRITING TABLET CONTROL		J
VW02	GRAFATAN TRACING DEVICE		H
WP102		MP000298	H
WP310		MP000163	H
WS100		MP000164	H
WS102-S		MP000204	H
XY10		MP000312	H
XM15		MP000013	H
XY20		MP000313	H
X604		MP000329	H
X605		MP000332	H
XY15-AA			H
XY8-E	M 842 PLOTTER CONTROL		H

INDEX OF ABBREVIATIONS

A/D	ANALOG TO DIGITAL	LPM.	LINE PER MINUTE
ADJUST.	ADJUSTEMENT	MOD.	MODULE
ASSY.	ASSEMBLY	MUX.	MULTIPLEXER
ASYNCR.	ASYNCHRONOUS	NEG	NEGATIVE
CH	CHANNEL	POS	POSITIVE
COL.	COLUMN	PT	PAPER TAPE
CRT	CATHODE RAY TUBE	RAM	RANDOM ACCESS MEMORY
D/A	DIGITAL TO ANALOG	ROM	READ ONLY MEMORY
EIA	ELECTRONICS INDUSTRY ASSOCIATION	RTC	READ ONLY MEMORY
EXT.	EXTENSION	SYNCR.	SYNCHRONOUS
FREQ.	FREQUENCY	SYST.	SYSTEM
H-P	HEWLETT-PACKARD	TEK.	TEKTRONIC
HT	HORIZONTAL TAB	TTY	TERMINAL DEVICE
IND	INDUSTRIAL	VAR.	VARIABLE
I/O	INPUT/OUTPUT	VT	VERTICAL TAB

digital

SOFTWARE SERVICES

DIGITAL EQUIPMENT CORPORATION, Corporate Headquarters: Maynard, Massachusetts 01754, Telephone: (617)897-5111 — SALES AND SERVICE OFFICES: UNITED STATES — ALABAMA, Huntsville • ARIZONA, Phoenix and Tucson • CALIFORNIA, El Segundo, Los Angeles, Oakland, Ridgecrest, San Diego, San Francisco (Mountain View), Santa Ana, Santa Clara, Stanford, Sunnyvale and Woodland Hills • COLORADO, Englewood • CONNECTICUT, Fairfield and Meriden • DISTRICT OF COLUMBIA, Washington (Lanham, MD) • FLORIDA, Ft. Lauderdale and Orlando • GEORGIA, Atlanta • HAWAII, Honolulu • ILLINOIS, Chicago (Rolling Meadows) • INDIANA, Indianapolis • IOWA, Bettendorf • KENTUCKY, Louisville • LOUISIANA, New Orleans (Metairie) • MARYLAND, Odenton • MASSACHUSETTS, Marlborough, Waltham and Westfield • MICHIGAN, Detroit (Farmington Hills) • MINNESOTA, Minneapolis • MISSOURI, Kansas City (Independence) and St. Louis • NEW HAMPSHIRE, Manchester • NEW JERSEY, Cherry Hill, Fairfield, Metuchen and Princeton • NEW MEXICO, Albuquerque • NEW YORK, Albany, Buffalo (Cheektowaga), Long Island (Huntington Station), Manhattan, Rochester and Syracuse • NORTH CAROLINA, Durham/Chapel Hill • OHIO, Cleveland (Euclid), Columbus and Dayton • OKLAHOMA, Tulsa • OREGON, Eugene and Portland • PENNSYLVANIA, Allentown, Philadelphia (Bluebell) and Pittsburgh • SOUTH CAROLINA, Columbia • TENNESSEE, Knoxville and Nashville • TEXAS, Austin, Dallas and Houston • UTAH, Salt Lake City • VIRGINIA, Richmond • WASHINGTON, Bellevue • WISCONSIN, Milwaukee (Brookfield) • INTERNATIONAL — ARGENTINA, Buenos Aires • AUSTRALIA, Adelaide, Brisbane, Canberra, Melbourne, Perth and Sydney • AUSTRIA, Vienna • BELGIUM, Brussels • BOLIVIA, La Paz • BRAZIL, Rio de Janeiro and Sao Paulo • CANADA, Calgary, Edmonton, Halifax, London, Montreal, Ottawa, Toronto, Vancouver and Winnipeg • CHILE, Santiago • DENMARK, Copenhagen • FINLAND, Helsinki • FRANCE, Lyon, Grenoble and Paris • GERMAN FEDERAL REPUBLIC, Cologne, Frankfurt, Hamburg, Hannover, Munich, Nuremberg, Stuttgart and West Berlin • HONG KONG • INDIA, Bombay • INDONESIA, Djakarta • IRELAND, Dublin • ITALY, ITALY, Milan, Rome and Turin • IRAN, Tehran • JAPAN, Osaka and Tokyo • MALAYSIA, Kuala Lumpur • MEXICO, Mexico City • NETHERLANDS, Utrecht • NEW ZEALAND, Auckland and Christchurch • NORWAY, Oslo • PUERTO RICO, Santurce • SINGAPORE • SWEDEN, Gothenburg and Stockholm • SWITZERLAND, Geneva and Zurich • UNITED KINGDOM, Birmingham, Bristol, Epsom, Edinburgh, Leeds, Leicester, London, Manchester and Reading • VENEZUELA, Caracas •

